

[Manuals.plus](#) /

› [Klarstein](#) /

› Klarstein Blender with Heating Function (Model: KG22-90300-ddci) Instruction Manual

Klarstein KG22-90300-ddci

Klarstein Blender with Heating Function

Model: KG22-90300-ddci

Brand: Klarstein

1. IMPORTANT SAFETY INSTRUCTIONS

Please read this instruction manual carefully before using the appliance and keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not operate the appliance with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Hot Surfaces:** The heating element surface is subject to residual heat after use. Exercise caution when handling hot liquids or ingredients. Do not touch hot surfaces directly.
- **Blades:** The blades are very sharp. Handle them with extreme care, especially during assembly, disassembly, and cleaning.
- **Proper Assembly:** Always ensure the blender jug and lid are correctly assembled and locked in place before operating the appliance. Do not open the lid while the blender is running.
- **Overfilling:** Do not exceed the maximum fill level indicated on the blender jug to prevent spillage and potential injury.
- **Cleaning:** Always unplug the appliance before cleaning. Do not immerse the motor base in water or any other liquid.
- **Intended Use:** This appliance is intended for household use only. Do not use it outdoors or for commercial purposes.

2. PRODUCT OVERVIEW

The Klarstein Blender with Heating Function is a versatile kitchen appliance designed for preparing a variety of beverages and foods, including plant-based milks, smoothies, juices, and soups. It combines powerful blending with integrated heating capabilities.



Deliziosa varietà vegana

Mixer 4 in 1 per preparare facilmente bevande alle noci, sciroppi e succhi

Macchina per
bevande alle noci

Miscelatore

Produttore di
alimenti per

Robot da cucina


KLARSTEIN

Image: The Klarstein Blender with Heating Function, showcasing its sleek design and main components.

Key Features:

- **Super Power:** Equipped with a 300 Watt motor for blending and a 1250 Watt heating element for cooking.
- **Versatile:** Ideal for preparing soy milk, nut milk, smoothies, juices, and soups.
- **Hot & Fine:** Features 360° heating technology and a 4-blade grinder for fine results.
- **High Speed:** Operates at up to 30,000 RPM for efficient processing.
- **User-Friendly:** Intuitive touchscreen control panel with illuminated buttons.
- **Capacity:** Removable water tank with a capacity of 300 - 1200 ml.
- **Hygienic:** Includes high-temperature sterilization and an automatic self-cleaning function.

Fornitura:

1 × Robot da cucina

1 × misurino

1 spazzola per la pulizia
manuale operativo



Image: The Klarstein Blender along with its included accessories: the main kitchen machine unit, a measuring cup, a cleaning brush, and the operating manual.

3. SETUP

Unpacking and Initial Inspection:

1. Carefully remove all components from the packaging.
2. Check for any damage during transit. If any damage is found, do not use the appliance and contact customer support.
3. Remove all packaging materials, stickers, and labels.

Placement:

- Place the blender on a stable, flat, and dry surface.
- Ensure there is sufficient space around the appliance for ventilation.
- Keep the appliance away from heat sources, direct sunlight, and moisture.
- The blender features non-slip feet for stability during operation.

Initial Cleaning:

Before first use, clean all parts that will come into contact with food.

1. Wipe the motor base with a damp cloth. Do not immerse it in water.
2. Wash the blender jug, lid, and measuring cup with warm soapy water. Rinse thoroughly and dry.
3. Ensure all parts are completely dry before assembly.

Utilizzo facile & sicuro

Grande pannello touch
con display digitale

Serbatoio dell'acqua
estraibile da 1,2 litri

Piedi d'appoggio
antiscivolo



Image: The Klarstein Blender positioned on a kitchen counter, demonstrating a typical setup for use.

4. OPERATING INSTRUCTIONS

Basic Operation:

1. Ensure the blender jug is securely placed on the motor base and the lid is properly closed.
2. Plug the power cord into a suitable electrical outlet. The touchscreen display will illuminate.
3. Use the touchscreen panel to select your desired program or manual settings.



Squisiti drink vegani per un risveglio perfetto

Pratico timer da 12 ore
e quantità a scelta per
iniziare al meglio la
giornata


KLARSTEIN

Image: A hand interacting with the digital touchscreen control panel of the Klarstein Blender, showing the timer display.

Using Pre-programmed Functions:

The blender features 8 pre-programmed settings for various preparations. Refer to the display for program options.

- Select the desired program by tapping its icon on the touchscreen.

- The appliance will automatically adjust blending speed and heating time.
- A 12-hour timer function allows for delayed starts, enabling you to prepare ingredients in advance.

Preparing Plant-Based Milk (e.g., Nut Milk):

1. Add the desired amount of nuts (e.g., cashews) and water to the blender jug. Ensure the water tank is filled if heating is required.
2. Close the lid securely.
3. Select the appropriate program for nut milk or use manual settings for blending and heating.
4. The 4-blade grinder and 360° heating technology will process the ingredients into fine, warm nut milk.

**Potente frullatore
per tritare,
macinare
e passare**

**Motore da 300 watt
di potenza**

Macina a 4 lame

**1250 watt di potenza
riscaldante**


KLARSTEIN



Image: A user adding cashew nuts into the top compartment of the Klarstein Blender, illustrating the preparation of nut-based beverages.

Making Smoothies, Juices, and Soups:

- Add your ingredients to the blender jug. For hot soups, ensure the water tank is filled.

- Select the relevant pre-programmed setting (e.g., Smoothie, Soup) or adjust speed and time manually.
- The powerful motor will blend ingredients to your desired consistency.

5. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your Klarstein Blender.

Automatic Self-Cleaning Function:

The blender features an intelligent 4-level automatic cleaning system:

1. **Level 1: Quick Clean** - Removes foam and light residues.
2. **Level 2: Intense Clean** - Targets stubborn deposits.
3. **Level 3: 85 °C Cleaning** - High-temperature sterilization for thorough hygiene.
4. **Level 4: Quadruple Rinse** - Ensures all cleaning agents are removed.

Intelligente pulizia automatica con 4 livelli

1° livello: pulizia rapida per eliminare la schiuma

2° livello: pulizia intensa per eliminare i depositi

3° livello: pulizia a 85 °C

4° livello: quadruplo risciacquo



KLARSTEIN



Image: The Klarstein Blender illustrating its 4-level automatic cleaning process, designed for comprehensive hygiene.

Manual Cleaning of Removable Parts:

- Always unplug the appliance before cleaning.
- The blender jug and water tank are removable for easy cleaning.



Contenitore e serbatoio
rimovibili per una
facile pulizia



Image: A hand demonstrating the removal of the side water tank from the Klarstein Blender, highlighting its easy-to-clean design.

- Wash the blender jug, lid, and measuring cup with warm soapy water. Use the provided cleaning brush for hard-to-reach areas and around the blades (handle with care).
- Rinse all parts thoroughly under running water.
- The container material is plastic, and the blade material is stainless steel. The item is dishwasher safe.
- Ensure all parts are completely dry before reassembling or storing.

Cleaning the Motor Base:

- Wipe the exterior of the motor base with a soft, damp cloth.
- Do not use abrasive cleaners or scourers, as they may damage the surface.
- Never immerse the motor base in water or any other liquid.

6. TROUBLESHOOTING

If you encounter issues with your Klarstein Blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; jug not correctly assembled.	Check power cord connection; test outlet with another appliance; ensure jug and lid are securely in place.
Blender stops during operation.	Overload protection activated; lid opened during operation.	Unplug, remove some ingredients, wait 15-20 minutes for motor to cool, then restart; ensure lid is closed.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients too large.	Add more liquid; reduce ingredient quantity; cut ingredients into smaller pieces.
Leakage from the jug.	Lid not properly sealed; jug overfilled.	Ensure lid is securely closed and sealed; do not exceed maximum fill line.
Heating function not working.	Water tank empty; incorrect program selected.	Fill the removable water tank; select a program that includes heating.

If the problem persists after trying these solutions, please contact Klarstein customer support.

7. SPECIFICATIONS

Detailed technical specifications for the Klarstein Blender with Heating Function:

Feature	Specification
Brand	KLARSTEIN
Model Number	KG22-90300-ddci
Color	Black
Capacity	1.2 Liters
Product Dimensions (D x W x H)	37.5 cm x 17.5 cm x 41 cm
Material (Housing)	Plastic
Recommended Uses	Grinding, Blending, Pureeing, Heating
Country of Origin	China
Power Source	Corded Electric
Motor Wattage	300 Watts
Heating Wattage	1250 Watts

Feature	Specification
Voltage	220 Volts
Control Type	Touchscreen
Item Weight	6.7 Kilograms
Dishwasher Safe	Yes (removable parts)
Blade Material	Stainless Steel
Container Material	Plastic



Image: A diagram illustrating the physical dimensions of the Klarstein Blender: 17.5 cm width, 37.5 cm height, and 41 cm depth.

8. WARRANTY AND SUPPORT

Warranty Information:

This Klarstein Blender comes with a **2-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, alterations, or unauthorized repairs. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your Klarstein Blender, please contact Klarstein customer support through their official website or the retailer where the product was purchased. When contacting support, please have your model number (KG22-90300-ddci) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B09KHHW7BJ>

More documents and user manuals: <https://manuals.plus/>