

[Manuals.plus](#) /

> [Vicco](#) /

> Vicco Sara Shoe Rack, Sonoma, 26.7x110cm Instruction Manual

Vicco 3749

Vicco Sara Shoe Rack Instruction Manual

Model: 3749 | Brand: Vicco

INTRODUCTION

Thank you for choosing the Vicco Sara Shoe Rack. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe storage unit. Please read these instructions carefully before beginning assembly and keep them for future reference.

The 'Sara' shoe rack is a practical solution for any home, designed to organize your footwear efficiently. It features 7 open shelves, providing ample storage space while maintaining a compact footprint.

SAFETY INFORMATION

- Always assemble the product on a clean, soft surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or defective.
- Keep small parts and packaging materials away from children and pets to avoid choking hazards.
- Use appropriate tools as specified in the assembly instructions.
- Do not overtighten screws, as this may damage the material.
- For stability, ensure the shoe rack is placed on a flat, level surface.
- Do not overload the shelves. Refer to the specifications for maximum weight capacity.
- If wall mounting is recommended or desired, use appropriate hardware for your wall type and consult a professional if unsure.

PACKAGE CONTENTS

Before assembly, please verify that all components listed below are included in your package:

- Vicco Sara Shoe Cabinet components
- Assembly Instructions manual

- Mounting hardware (screws, dowels, etc.)

If any items are missing or damaged, please contact customer support immediately.

SETUP AND ASSEMBLY

Assembly of the Vicco Sara Shoe Rack is designed to be straightforward. It typically takes 10-15 minutes with basic tools like a screwdriver or cordless drill.

1. **Unpack and Inspect:** Carefully unpack all components and lay them out on a soft, clean surface. Check for any damage or missing parts against the parts list provided in the separate assembly instructions.
2. **Identify Components:** Familiarize yourself with the different panels and hardware. The main assembly instructions will label each part.
3. **Assemble the Frame:** Begin by connecting the main vertical support panels using the provided hardware. Ensure all connections are secure but do not overtighten.
4. **Attach Shelves:** Insert the 7 open shelves into their designated slots or attach them to the frame using the specified hardware. Pay attention to the orientation of each shelf.
5. **Final Tightening:** Once all components are in place, gently tighten all screws to ensure the structure is firm and stable.
6. **Positioning:** Place the assembled shoe rack in its desired location, ensuring it is on a stable and level surface.



The assembled Vicco Sara Shoe Rack in a hallway, showcasing its practical use for shoe storage and a handbag on the top shelf.



Two Vicco Sara Shoe Racks, illustrating the storage capacity with one unit empty and another displaying various types of footwear and a handbag.

OPERATING INSTRUCTIONS

The Vicco Sara Shoe Rack is designed for straightforward use:

- **Shoe Placement:** Place shoes on the 7 open shelves. The design allows for easy access and visibility of your footwear.
- **Accessory Storage:** The top surface can be used for placing small accessories like keys, wallets, or decorative items.
- **Capacity:** Each shelf is designed to hold one to two pairs of shoes, depending on their size and style.

MAINTENANCE

To ensure the longevity and appearance of your Vicco Sara Shoe Rack, follow these maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the melamine resin coating.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the finish.
- **Moisture:** Keep the shoe rack away from excessive moisture or humidity.
- **Hardware Check:** Periodically check all screws and connections and tighten them if necessary to maintain stability.



A detailed view of the shelves and Sonoma wood finish, highlighting the easy-to-clean melamine resin coating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Parts do not fit together or holes do not align.	Incorrect orientation of parts; manufacturing defect; incorrect parts.	Double-check the assembly instructions for correct part orientation. If parts are defective or incorrect, contact customer support for replacements.

Problem	Possible Cause	Solution
Shoe rack is wobbly or unstable.	Screws are not fully tightened; placed on an uneven surface; overloaded.	Ensure all screws are securely tightened. Move the rack to a flat, level surface. Reduce the weight on the shelves if overloaded.
Scratches or damage during assembly.	Assembly on a hard or rough surface.	Always assemble on a soft, protective surface (e.g., carpet, blanket) to prevent cosmetic damage.

SPECIFICATIONS

Feature	Detail
Brand	Vicco
Model Number	3749
Color	Sonoma
Product Dimensions (D x W x H)	27.7 cm x 26.7 cm x 110 cm
Item Weight	9.9 kg
Maximum Weight Capacity	9.8 kg
Material	Engineered Wood (16 mm particle board)
Finish Type	Melamine Resin Coating
Number of Shelves	7
Shelf Type	Multi-tier Shelf
Mounting Type	Floor Mount
Room Type	Hallway
Style	Modern
Special Feature	Space-saving



Detailed dimensions of the Vicco Sara Shoe Rack, including overall height, width, depth, and individual shelf spacing.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For any questions, missing parts, or support needs, please contact the retailer or manufacturer directly.

Manufacturer: Oskar

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09KLR9H8M>

More documents and user manuals: <https://manuals.plus/>