

Manuals.plus /

- › LIGHTACCENTS /
- › LIGHTACCENTS Honors Paper Floor Lamps (2 Pack Set) - Instruction Manual

## LIGHTACCENTS 26121EW-2PK-20

# LIGHTACCENTS Honors Paper Floor Lamps (2 Pack Set) - Instruction Manual

Comprehensive instruction manual for the LIGHTACCENTS Honors Paper Floor Lamps (2 Pack Set), including assembly, operation, maintenance, and specifications.

## 1. PRODUCT OVERVIEW

The LIGHTACCENTS Honors Paper Floor Lamp is a Japanese-style standing lamp designed to provide diffused lighting. This product comes as a set of two lamps, each featuring a polished chrome metal base and a white paper shade. It is equipped with two E26 sockets per lamp and operates with a convenient foot switch.

- **Brand:** LIGHTACCENTS
- **Model:** 26121EW-2PK-20
- **Dimensions:** 7"D x 7"W x 59"H (each lamp)
- **Shade Material:** Paper
- **Base Material:** Metal (Chrome finish)
- **Bulb Base:** E26 Medium (Bulbs not included)
- **Max Wattage:** 60 watts per socket (LED recommended)
- **Switch Type:** Push Button (Foot Switch)





Image 1.1: The LIGHTACCENTS Honors Paper Floor Lamps (2 Pack Set).

## 2. SAFETY INFORMATION

- Ensure the lamp is unplugged before assembly, bulb replacement, or cleaning.

- Use only bulbs of the specified type and wattage (E26, max 60W). LED bulbs are recommended for energy efficiency.
- Do not expose the lamp to water or excessive moisture. This product is for indoor use only.
- Place the lamp on a stable, level surface to prevent tipping.
- Keep the power cord away from heat sources and sharp edges.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.

### **3. PACKAGE CONTENTS**

---

Verify that all components are present and undamaged before beginning assembly. Each lamp package should contain:

- Lamp Base (Chrome)
- Main Frame Poles (3 sections)
- Light Fixture with Cord and Foot Switch (2 E26 sockets)
- Paper Shade (White)
- Mounting Bolt and Nut
- Shade Retainer (Finial)

# HONORS FLOOR LAMP

Illuminate cherished  
moments.



Image 3.1: Unboxed components of the lamp, including the base, poles, light fixture, and shade.

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your LIGHTACCENTS Honors Paper Floor Lamp. Refer to the assembly video for visual guidance.

Your browser does not support the video tag.

Video 4.1: Assembly instructions for the LIGHTACCENTS Floor Lamp.

1. **Connect the Main Frame Poles:** Carefully connect the three metal pole sections by twisting them together to form a single long pole. Ensure they are securely fastened.



Image 4.1: Connecting the main frame poles.

- 2. Insert Light Fixtures:** Unscrew the retaining ring from each light fixture. Slide the light fixtures onto the assembled pole, ensuring the cord runs along the pole. Re-secure the retaining rings.



Image 4.2: Unscrewing the light fixture retaining ring.

- 3. Run and Clip the Cord:** Use the provided clips to secure the power cord neatly along the main frame pole.



Image 4.3: Clipping the power cord to the pole.

- 4. Install Light Bulbs:** Twist E26 base light bulbs (not included, max 60W each) into the sockets. LED bulbs are recommended.



Image 4.4: Installing light bulbs.

- 5. Mount Frame to Base:** Insert the bottom of the assembled main frame pole into the lamp base. Secure it from underneath the base using the provided bolt and nut.



Image 4.5: Securing the main frame to the base.

6. **Attach the Paper Shade:** Carefully place the paper shade over the top of the main frame. Gently pull it down to extend it fully.



Image 4.6: Attaching the paper shade.

7. **Secure the Bottom Shade:** Screw in the small bolt at the bottom of the shade to clip and secure the paper shade in place.



Image 4.7: Screwing in the bolt to secure the bottom shade.

8. **Attach the Top Finial:** Place the finial (decorative cap) on top of the shade to complete the assembly.



Image 4.8: Attaching the top finial.

## 5. OPERATING INSTRUCTIONS

---

To operate your LIGHTACCENTS Honors Paper Floor Lamp:

1. Plug the lamp's power cord into a standard electrical outlet.
2. Locate the foot switch on the power cord.
3. Press the foot switch to turn the lamp ON.
4. Press the foot switch again to turn the lamp OFF.



Image 5.1: The foot switch for easy operation.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect the power before cleaning. Wipe the metal base with a soft, dry cloth. For the paper shade, use a soft, dry brush or a feather duster to remove dust. Do not use liquid cleaners on the paper shade.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulbs have cooled before attempting to replace them. Twist out the old bulb and twist in a new E26 base bulb (max 60W).
- **Storage:** If storing the lamp, disassemble it carefully and keep the paper shade flat or rolled gently to prevent creases or damage. Store in a dry place.

## 7. TROUBLESHOOTING

| Problem                             | Possible Cause                                                                                | Solution                                                                                                                                                                                          |
|-------------------------------------|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lamp does not turn on.              | Lamp not plugged in.<br>Light bulb is loose or burnt out.<br>Power outlet is not functioning. | Ensure the power cord is securely plugged into a working outlet.<br>Tighten the light bulb or replace it with a new one.<br>Test the outlet with another appliance or check your circuit breaker. |
| Light is dim or flickering.         | Incorrect bulb wattage.<br>Loose bulb connection.                                             | Ensure bulbs meet the specified wattage (max 60W).<br>Tighten the light bulb.                                                                                                                     |
| Paper shade is wrinkled or damaged. | Improper handling during assembly or storage.                                                 | Gently smooth out wrinkles if possible. Handle with care to prevent further damage.<br>Replacement shades may be available from the manufacturer.                                                 |

## 8. SPECIFICATIONS

| Feature                   | Detail                                 |
|---------------------------|----------------------------------------|
| Brand                     | LIGHTACCENTS                           |
| Model Name                | Paper Floor Lamp set of 2              |
| Item Model Number         | 26121EW-2PK-20                         |
| Product Dimensions (each) | 7"D x 7"W x 59"H                       |
| Item Weight (each)        | 5.5 Pounds (approx. 11 lbs for 2-pack) |
| Material                  | Metal (Base), Paper (Shade)            |
| Finish Type               | Chrome                                 |
| Shade Color               | White                                  |
| Bulb Base                 | E26 Medium                             |
| Max Wattage               | 60 Watts per socket                    |
| Light Source Type         | LED, Incandescent compatible           |
| Voltage                   | 120 Volts (AC)                         |
| Switch Type               | Push Button (Foot Switch)              |
| Indoor/Outdoor Usage      | Indoor                                 |
| Assembly Required         | Yes                                    |
| UPC                       | 850017644489                           |




Image 8.1: Dimensional diagram of the lamp.

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact LIGHTACCENTS customer service. Keep your purchase receipt for warranty claims.

You can visit the official LIGHTACCENTS store for more information: [LIGHTACCENTS Store](#)

