

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw TPU Screen Protector User Manual for iTOUCH Sport 3 / i Touch Sport 3 SE

Lamshaw iTOUCH Sport 3

Lamshaw TPU Screen Protector User Manual

For iTOUCH Sport 3 / i Touch Sport 3 SE Smartwatches

INTRODUCTION

This manual provides detailed instructions for the installation and maintenance of your Lamshaw TPU Screen Protector, designed for the iTOUCH Sport 3 and i Touch Sport 3 SE smartwatches. This product offers full coverage, scratch resistance, high transparency, and high sensitivity to protect your device's screen.



Image: Lamshaw TPU Screen Protector packaging and a smartwatch.

PACKAGE CONTENTS

Your Lamshaw TPU Screen Protector package typically includes:

- TPU Screen Protectors (6 pieces)
- Wet Wipes
- Dry Wipes
- Dust Removal Stickers
- Microfiber Cleaning Cloth
- Squeegee Card (for bubble removal)

SETUP: INSTALLATION INSTRUCTIONS

Follow these steps carefully to ensure proper installation and avoid bubbles. It is recommended to perform the installation in a dust-free environment.

Preparation:

1. **Clean the Screen:** Use the wet wipe (labeled "1") to thoroughly clean the smartwatch screen.
2. **Dry the Screen:** Use the dry wipe (labeled "2") to dry the screen completely.
3. **Remove Dust:** Use the dust removal sticker to pick up any remaining dust particles from the screen. Finally, use the microfiber cloth for a final polish.


Installation Instructions



1: Clean the screen: use wet paper first,
second use the dry paper,
last clean the display use the fiber cloth



2: Remove Back stick 1



3: Align the edge of the screen and
stick to one side



4: When installing,
use a card to push from one side to the other,
and tear off the sticker 1 at the same time



5: Press the entire screen with
your hand to the edge



6: Remove the stick 2. If there are bubbles,
please use your hand
to make the bubble disappear

Image: Visual guide showing the step-by-step installation process for the screen protector.

Applying the Screen Protector:

The screen protector consists of three layers: a red "Back 1" layer, the middle TPU protector layer, and a black "Front 2" layer.

TPU Screen Protector




Image: Diagram illustrating the three layers of the TPU screen protector: two plastic films (not the protector) and the TPU screen protector itself.

4. **Peel "Back 1"**: Carefully peel off the red "Back 1" layer from one end of the screen protector.
5. **Align and Apply**: Align the exposed sticky side of the protector with one edge of your smartwatch screen. Slowly lower the protector onto the screen, ensuring precise alignment.
6. **Smooth Out Bubbles**: As you apply, use the provided squeegee card to gently push out any air bubbles from the center towards the edges. Apply firm, even pressure.
7. **Remove "Front 2"**: Once the protector is fully adhered and most bubbles are removed, carefully peel off the black "Front 2" layer.
8. **Final Smoothing**: Use the squeegee card or your fingers to press down on the entire screen, especially around the edges, to eliminate any remaining small bubbles.

Installation Video Guide:

For a visual demonstration of the installation process, please refer to the video below:

Your browser does not support the video tag.

Video: Demonstrates the installation method for the TPU screen protector on a smartwatch.

OPERATING & USAGE TIPS

Your Lamshaw TPU Screen Protector is designed to provide optimal protection while maintaining the functionality of your iTOUCH Sport 3 / i Touch Sport 3 SE. It features:

- **High Transparency:** Ensures clear visibility of your screen.
- **High Sensitivity:** Maintains original touch screen responsiveness.
- **Scratch Resistance:** Protects against daily wear and minor abrasions.
- **Anti-Shatter:** Adds a layer of protection against impacts.




Image: A screen protector demonstrating its flexibility and durability by bending around a pen tip.

MAINTENANCE

To keep your screen protector in optimal condition:

- Wipe the screen protector regularly with a soft, lint-free cloth to remove fingerprints and smudges.
- Avoid using harsh chemicals or abrasive materials, as these can damage the protector's surface.
- If the protector becomes excessively dirty, a slightly damp cloth can be used, followed by a dry cloth.

TROUBLESHOOTING

Bubbles After Installation:

Small bubbles may appear immediately after installation. The Lamshaw TPU screen protector features a "bubble self-healing" property, meaning minor bubbles often disappear within 24-48 hours. For larger or persistent bubbles:

- Use the squeegee card to gently push the bubbles towards the nearest edge.
- If a bubble is large and cannot be removed, you may need to carefully lift the nearest edge of the protector, push the bubble out, and then re-adhere the section. If necessary, remove the protector and re-install a new one from the pack.

Incorrect Layer Peeling:

If you accidentally peel off the "Front 2" layer first, and the side to "Front 2" is not sticky, it means the middle protective layer remained attached to the "Back 1" layer. In this situation, gently wrinkle the red "Back 1" layer to separate it into two layers. Peel off the middle layer and ensure it adheres to the "Front 2" side before attempting re-installation.

SPECIFICATIONS

Brand	Lamshaw
Compatible Devices	iTOUCH Sport 3, i Touch Sport 3 SE
Material	Thermoplastic Polyurethane (TPU)
Special Features	Scratch Resistant, Anti-Shatter, High Transparency, High Sensitivity, Bubble Self-Healing
Clarity	90%
Number of Items	6 Pack

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For any support inquiries, please refer to the seller's contact information on the product's purchase page or contact Lamshaw customer service directly.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09KMWDW21>

More documents and user manuals: <https://manuals.plus/>