

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [UrbanX](#) /

› [UrbanX Q63 Wireless Earbuds Instruction Manual](#)

UrbanX Q63

UrbanX Q63 Wireless Earbuds Instruction Manual

Model: Q63 (TWS530)

INTRODUCTION

Thank you for choosing the UrbanX Q63 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance. The Q63 earbuds feature Bluetooth 5.3 connectivity, IPX7 waterproofing, touch controls, and an ergonomic design with ear hooks for a secure fit.

WHAT'S IN THE BOX

- UrbanX Q63 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable (not explicitly listed but implied for USB-C charging)
- Ear Tips (Multiple Sizes)

Dual LED Digital Display



Image: UrbanX Q63 Wireless Earbuds placed inside their charging case, illustrating the product components.

PRODUCT OVERVIEW

Earbud Components and Controls

Each earbud is equipped with a multi-function button and an ergonomic ear hook for stability.

Dual Audio Controls

The robust battery life enables listening throughout the entire day



Call/hang up(One click)



Rejected(Twice click)



Play Music(One click)



Pause music(One click)



Previous song "+"(Long press 2S)
Next song "-"(Long press 2S)



Power on (long press 3s)
Power off (long press 5s)

Image: Diagram showing the location of controls on the UrbanX Q63 earbuds, detailing functions for calls and music playback.

- **Call/Hang Up:** One click
- **Reject Call:** Twice click
- **Play Music/Pause Music:** One click
- **Previous Song:** Long press (2 seconds) on left earbud
- **Next Song:** Long press (2 seconds) on right earbud
- **Power On:** Long press (3 seconds)
- **Power Off:** Long press (5 seconds)

Charging Case LED Display

The charging case features a dual LED digital display to indicate battery levels.



Image: The UrbanX Q63 charging case open, displaying digital readouts for both the charging case battery capacity and the individual earbud power levels.

- **Charging Case Capacity:** Displays the remaining battery percentage of the charging case.
- **Earbud Power Display:** Shows the individual battery level of each earbud.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- **Charging the Earbuds:** Place the earbuds into the charging case. They will begin charging automatically.
- **Charging the Case:** Connect the USB-C charging cable to the charging port on the case and to a power source. The LED display will show the charging progress. The case also supports wireless charging.
- **Charging Time:** Approximately 80 minutes for a full charge.

200 Hrs Long Playback

The long-lasting battery supports uninterrupted listening for the whole day

20 Hrs
Single charge



200 Hrs
Charging Case

Image: The UrbanX Q63 charging case connected via a USB-C cable, indicating the charging process and highlighting the extended playback time.

2. Pairing with Your Device

The UrbanX Q63 earbuds feature one-step pairing for convenience.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
3. On your device, search for Bluetooth devices and select "YYK-Q63" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

One Step Pairing

To connect to Bluetooth <YYK-Q63>, simply take the earbuds out of the charging case



Image: A hand holding a smartphone displaying Bluetooth settings, with "YYK-Q63" visible in the list of available devices, demonstrating the one-step pairing process.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** One click on either earbud.
- **Next Track:** Long press the right earbud for 2 seconds.
- **Previous Track:** Long press the left earbud for 2 seconds.

Call Management

- **Answer/End Call:** One click on either earbud.
- **Reject Call:** Double click on either earbud.

Power On/Off

- **Power On:** Long press the earbud button for 3 seconds.

- **Power Off:** Long press the earbud button for 5 seconds.

Vibrant sound paired with deep bass undertones



Image: A person wearing UrbanX Q63 earbuds, illustrating comfortable use during music listening.

MAINTENANCE

Cleaning

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Clean the ear tips regularly with a damp cloth and mild soap, then dry thoroughly before reattaching.

Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

Water Resistance

The earbuds are IPX7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30

minutes. They are suitable for workouts and light rain. However, they are not designed for swimming or prolonged submersion. Ensure earbuds are dry before placing them back in the charging case to prevent damage.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are out of the case and fully charged. Turn off and on your device's Bluetooth, then try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again to re-establish the connection.
- **No sound:** Check the volume level on your connected device. Ensure the earbuds are properly paired and selected as the audio output.
- **Charging issues:** Verify the charging cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

SPECIFICATIONS

Feature	Specification
Model Name	Q63 (TWS530)
Brand	UrbanX
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	Up to 18.29 meters (60 feet)
Earbud Playtime (Single Charge)	Up to 20 Hours
Total Playtime (with Charging Case)	Up to 200 Hours
Charging Time	Approximately 80 minutes
Water Resistance Level	IPX7 (Waterproof)
Noise Control	Active Noise Cancellation, CVC Noise Reduction (for calls)
Audio Driver Type	Dynamic Driver (13mm speakers)
Control Method	Touch/Button Control
Compatible Devices	Mobile Phone, Tablet, Laptop, Smartphone, Home and other Bluetooth enabled devices
Item Weight	6.3 ounces
Product Dimensions	3 x 2 x 2 inches
Included Components	Charging Case

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the retailer.

Specific warranty terms may vary by region and point of purchase.

If you encounter any issues or require further assistance, please contact the seller or visit the official UrbanX store on Amazon for support and additional product information. You can typically find seller contact details on your order page.

Visit the UrbanX Store: [UrbanX Amazon Store](#)



© 2026 UrbanX. All rights reserved.