

IKEA 304.866.51

IKEA OLIVBLAD Plant Stand User Manual

Model: OLIVBLAD (304.866.51)

PRODUCT OVERVIEW

The IKEA OLIVBLAD Plant Stand is designed to elevate your plants and enhance your living space. Featuring shelves at different levels, it allows for a dynamic display of your potted plants. Its versatile design also makes it suitable for use as a side table for various items.

Key features include:

- Multi-level shelves for dynamic plant display.
- Suitable for both indoor and outdoor use.
- Can also be used as a side table.
- Durable metal construction.

PRODUCT IMAGES



Figure 1: Front view of the IKEA OLIVBLAD Plant Stand, showcasing its two oval-shaped shelves and sturdy metal frame.



Figure 2: Close-up view of one of the plant stand's oval shelves, highlighting the smooth black metal finish and raised edges.



Figure 3: An arrangement of multiple IKEA OLIVBLAD Plant Stands of varying heights, demonstrating their use for displaying a collection of plants in an indoor setting.



Figure 4: The plant stand positioned next to a bed, serving as a side table with plants and books, illustrating its versatility.

PRODUCT VIDEOS

No official product videos from the seller are available for this item.

SETUP

The IKEA OLIVBLAD Plant Stand requires assembly. Please follow the instructions provided in the packaging for detailed steps. Ensure all components are present and securely fastened before use.

General Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Attach the legs to the shelves using the provided hardware.
3. Ensure all screws are tightened securely, but do not overtighten.
4. Place the plant stand on a flat, stable surface.

OPERATING INSTRUCTIONS

The OLIVBLAD Plant Stand is designed for displaying potted plants or as a functional side table. Its multi-level design allows for creative arrangements.

- Place potted plants directly on the shelves. Ensure pots have drainage and use saucers to prevent water damage to the stand or floor.
- For use as a side table, place items such as books, coffee cups, or decorative objects on the shelves.
- Distribute weight evenly across the shelves to maintain stability.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your plant stand.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and dry thoroughly. Avoid abrasive cleaners or scouring pads.
- **Outdoor Use:** While suitable for outdoor use, prolonged exposure to harsh weather conditions (e.g., heavy rain, direct sunlight, extreme temperatures) may affect the finish over time. Consider covering or moving indoors during severe weather.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Floor Protection:** The stand is equipped with rubber feet to protect floors. Ensure these are intact and in place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is wobbly.	Uneven surface or loose connections.	Ensure the stand is on a flat surface. Check and tighten all assembly screws.
Scratches on floor.	Missing or damaged rubber feet.	Verify all rubber feet are present and intact. Replace if damaged. Avoid dragging the stand.
Rust appearing (outdoor use).	Prolonged exposure to moisture.	Clean and dry the affected area. Apply a rust-inhibiting paint if necessary. Store indoors or cover during heavy rain.

SPECIFICATIONS

Brand: IKEA

Model: OLIVBLAD (304.866.51)

Material: Metal

Color: Black

Shape: Round (shelves are oval)

Number of Levels: 3

Assembly Required: Yes

Product Dimensions (L x W x H): 1.18 x 1.18 x 1.18 inches (Note: This seems to be packaging dimensions, actual product is 56 cm / 22" tall)

Item Weight: 7.59 pounds (3.45 Kilograms)

Special Feature: Multi-level shelves for dynamic plant display

WARRANTY AND SUPPORT

Specific warranty information for the IKEA OLIVBLAD Plant Stand is typically provided with the product packaging or can be found on the official IKEA website. Please refer to these resources for details regarding warranty coverage and terms.

For customer support, assembly assistance, or to inquire about replacement parts, please contact IKEA customer service directly or visit their official support channels.

© 2023 IKEA. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09KPCNC9W>

More documents and user manuals: <https://manuals.plus/>