

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tangkula](#) /

› [Tangkula Acacia Wood Garden Bench Instruction Manual](#)

Tangkula Wood Garden Bench 67675

Tangkula Acacia Wood Garden Bench Instruction Manual

Model: Wood Garden Bench 67675

Brand: Tangkula

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Tangkula Acacia Wood Garden Bench. This outdoor conversation furniture set features a durable acacia wood frame and weather-resistant PE wicker seats, designed for comfort and longevity. Please read all instructions thoroughly before assembly and use to ensure proper function and safety.

SAFETY INFORMATION

- Exercise caution around sharp edges during unpacking and assembly.
- Do not exceed the maximum weight capacity of 90 lbs (40.8 kg) on the middle table.
- Do not exceed the maximum weight capacity of 360 lbs (163.3 kg) per chair.
- The product is not heat-resistant; avoid placing hot items directly on surfaces without protection.
- Ensure all components are present and undamaged before beginning assembly. Do not proceed with assembly if any parts are missing or damaged.
- Always follow the included assembly instructions for safe and correct setup.
- Assemble the bench on a soft, clean surface to prevent scratches.
- Keep children and pets away from the assembly area.

PARTS LIST

Your Tangkula Acacia Wood Garden Bench package includes all necessary components for assembly, along with detailed instructions and tools. Please verify that all labeled parts are present and accounted for before beginning the assembly process.

ASSEMBLY INSTRUCTIONS

The Tangkula Acacia Wood Garden Bench is designed for straightforward assembly. Detailed step-by-step instructions, along with all necessary tools and labeled parts, are included in your package to facilitate a quick and successful setup. Please refer to the separate assembly manual provided for specific guidance.



Image: Product dimensions and weight capacities for assembly reference.

OPERATING INSTRUCTIONS

This garden bench is designed for comfortable outdoor seating for two individuals. The integrated middle table provides a convenient surface for beverages, books, or small items. The table also features a parasol hole, allowing you to insert a patio umbrella (not included) for shade or protection from light rain.

- Ensure the bench is placed on a stable, level surface before use.
- Distribute weight evenly across the seats and table to prevent tipping or damage.
- When using a parasol, ensure it is securely inserted into the hole and properly weighted or anchored to prevent it from falling over in windy conditions.



A 5 cm umbrella hole (umbrella not include)



Convenient

Integral Middle Coffee Table

Provide an extra place for your drinks and snacks



Practical



Image: The integral middle coffee table with a parasol hole for an umbrella (umbrella not included).

Ergonomic Seat and Back

Comfortable to seat on



Curved Armrest

Rest your arm cozily

Image: Ergonomic seat and curved armrest design for comfortable use.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your garden bench.

- **Cleaning:** Wipe the surfaces with a dry cloth for general dusting. For more thorough cleaning, use a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the wood or wicker.
- **Wood Care:** The acacia wood surface may experience drying and fading over time due to sun exposure, temperature variations, and moisture. To maintain its appearance, periodically apply wood polish oil to a soft cloth and gently wipe the wood surfaces. This helps restore its glossy finish and protect the wood.
- **Weather Protection:** While the PE wicker is weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) can affect the product's lifespan. Consider using a furniture cover or storing the bench indoors during harsh weather.
- **Heat:** The product is not heat-resistant. Avoid placing hot items directly on the table or seats.



Image: Instructions for maintaining the wood finish with polish oil.

TROUBLESHOOTING


If you encounter any issues with your Tangkula Acacia Wood Garden Bench, please review the assembly instructions to ensure all steps were followed correctly. For persistent problems or concerns, please contact Tangkula customer support or your retailer for assistance.

SPECIFICATIONS

Model Number	Wood Garden Bench 67675
Material	Acacia Wood, PE Wicker
Overall Product Dimensions (L x W x H)	62" x 22.5" x 35.5" (157.5 cm x 57.2 cm x 90.2 cm)

Seat Height to Ground	18" (45.7 cm)
Armrest Height to Ground	25.5" (64.8 cm)
Middle Table Maximum Capacity	90 lbs (40.8 kg)
Chair Maximum Capacity (each)	360 lbs (163.3 kg)
Net Weight	33 lbs (15 kg)

Selected Material



Breathable Rattan Seat



Solid Acacia Wood Frame



Light-weighted



Beautiful



Easy Maintain



Weather-resistant

Image: Overview of selected materials and their benefits.

WARRANTY INFORMATION

Specific warranty details for the Tangkula Acacia Wood Garden Bench may vary. Please refer to the warranty documentation included with your purchase or contact your retailer or Tangkula customer service for comprehensive information regarding warranty coverage and terms.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Tangkula Acacia Wood Garden Bench, please contact Tangkula customer service. You can typically find contact information on the product packaging, the retailer's website, or the official Tangkula brand store.

© 2023 Tangkula. All rights reserved.