



[Manuals.plus](#) /

> [GERGO](#) /

> GERGO Floor Lamp Instruction Manual

GERGO MF19062

GERGO Floor Lamp Instruction Manual

Model: MF19062

INTRODUCTION

Thank you for choosing the GERGO Floor Lamp. This intelligent floor lamp features a main torchiere light and an adjustable reading lamp, both controllable via a remote. It offers a wide range of color temperatures and brightness levels to suit various environments and activities. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your lamp.



Image: The GERGO Floor Lamp in brushed nickel finish, featuring a main upward-facing light and a flexible gooseneck reading light, with its remote control displayed.

SAFETY INSTRUCTIONS

- Ensure the lamp is placed on a stable, level surface to prevent tipping. The weighted base provides stability.
- This product is designed for indoor use only. Do not expose to water or high humidity.
- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Do not attempt to modify or disassemble the lamp beyond the instructions provided.
- Keep the remote control and small parts out of reach of children and pets.
- Use only the specified bulb type (E26 LED) and wattage to avoid damage or fire hazards.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Floor Lamp components (base, pole sections, lamp heads)
- 2 x Intelligent LED Bulbs (11W + 7W)
- 1 x Remote Control
- 2 x AAA Batteries (for remote control)



Image: A diagram illustrating the dimensions of the GERGO Floor Lamp and its main components, including the two LED bulbs and the remote control.

SETUP INSTRUCTIONS

The GERGO Floor Lamp is designed for easy, tool-free assembly. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Assemble the Pole:** Gently pull any excess cord from the bottom of the pole sections. Screw the pole sections together

clockwise, ensuring they are securely tightened.

3. **Attach to Base:** Connect the assembled pole to the weighted base by screwing it clockwise until firm.
4. **Install Lamp Heads:** Attach the main torchiere lamp head and the adjustable reading lamp head to the top of the pole. Ensure the wiring is not pinched.
5. **Insert Bulbs:** Screw the two intelligent LED bulbs into their respective E26 sockets.
6. **Install Remote Batteries:** Open the battery compartment on the back of the remote control and insert the two AAA batteries, observing the correct polarity (+/-).
7. **Connect to Power:** Plug the lamp's power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

Your GERGO Floor Lamp can be operated using the included remote control or the manual rotary switch on the lamp.

Remote Control Functions

The remote control allows for comprehensive adjustment of your lamp's lighting.

- **Power On/Off:** Press the **Power** button to turn the lamp on or off.
- **Color Temperature Adjustment (CCT):** Use the **CCT+** and **CCT-** buttons to cycle through or fine-tune the color temperature from 3000K (Warm White) to 6000K (Cool White).
- **Brightness Adjustment:** Use the **Brightness Up** and **Brightness Down** buttons to adjust the light intensity from 5% to 100%.
- **Separate Control:** The remote features separate control buttons for the main (mother) lamp and the reading (daughter) lamp, allowing independent operation.

Multiple Switch Modes Lamps



Turning On/Off


Color Temperature Adjust

Brightness Up ▲

Brightness Down ▼



Remote Control



Rotary Switch

Image: A detailed view of the remote control, highlighting buttons for power, color temperature adjustment, and brightness control for both the main and reading lamps.

Manual Rotary Switch

Each lamp head also has a manual rotary switch. This switch provides basic On/Off functionality. For dimming and color temperature adjustments, the remote control must be used.




Image: The GERGO Floor Lamp shown in three different settings, illustrating its ability to provide 3000K Warm White, 5000K Daylight, and 6000K Cool White lighting for various moods and tasks.

MAINTENANCE

To keep your GERGO Floor Lamp in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Dust the lamp regularly with a soft, dry cloth. For more thorough cleaning, wipe with a slightly damp cloth and then dry immediately. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** If a bulb needs replacement, ensure the lamp is unplugged. Allow the bulb to cool completely before unscrewing it. Replace with an E26 base LED bulb of appropriate wattage (as specified in the specifications section). For full remote functionality, ensure the replacement bulb is compatible with the lamp's intelligent control system.
- **Remote Batteries:** Replace the AAA batteries in the remote control when its performance diminishes.

TROUBLESHOOTING

If you encounter issues with your GERGO Floor Lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose bulb, remote batteries dead, manual switch off.	Check power outlet. Ensure bulbs are screwed in tightly. Replace remote batteries. Ensure manual rotary switches on lamp heads are in the 'on' position.
Remote control is unresponsive.	Dead batteries, obstruction, remote not paired.	Replace remote batteries. Ensure no obstructions between remote and lamp. Refer to pairing instructions (if provided with product, otherwise contact support).

Problem	Possible Cause	Solution
Cannot adjust brightness or color temperature.	Using non-intelligent bulbs, remote not paired, manual switch used.	Ensure the included intelligent LED bulbs are used. Confirm remote is paired. Brightness and color temperature adjustments are only available via the remote control.
Lamp flickers or dims unexpectedly.	Loose connection, faulty bulb, power fluctuations.	Check all connections. Try replacing the bulb. If problem persists, consult an electrician or contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	MF19062
Product Dimensions	9.4"D x 9.8"W x 70"H
Item Weight	5 Pounds
Material	Metal
Finish Type	Matte
Shade Material	Polycarbonate
Light Source Type	LED
Number of Light Sources	2
Bulb Base	E26
Wattage	18 KW (Combined)
Brightness	2100 Lumen (Combined)
Color Temperature	3000K-6000K (Adjustable)
Control Method	Remote Control, Push Button
Power Source	Corded Electric
Voltage	120 Volts (AC)
Batteries Required	2 AAA (for remote, included)
Indoor/Outdoor Usage	Indoor
UPC	712236439744

WARRANTY AND SUPPORT

GERGO products are manufactured to high-quality standards. For warranty information or technical support, please refer to the

contact details provided with your purchase documentation or visit the official GERGO website. Please retain your proof of purchase for any warranty claims.

© 2025 GERGO. All rights reserved.