

CHUNGHOP RM-F01

CHUNGHOP Replacement Remote Control Instruction Manual

MODEL: RM-F01, RM-F04, RM-E06

1. Introduction

This manual provides instructions for the CHUNGHOP Replacement Remote Control, designed for use with various Humax Foxsat HDR Freesat Box models. This remote control is a direct replacement and requires no programming or pairing for immediate use.

2. Product Overview

The CHUNGHOP replacement remote control is designed to replicate the functionality of your original Humax Foxsat HDR Freesat Box remote. It features an ergonomic design for comfortable handling.



Figure 2.1: Front, side, and back views of the CHUNGHOP replacement remote control.



Figure 2.2: Dimensions of the remote control, approximately 23.7cm (9.3 inches) in length, 5.1cm (2 inches) in front width, and 2.3cm (0.9 inches) in side thickness.

2.1 Compatible Models

This remote control is compatible with the following Humax Foxsat HDR Freesat Box models:

- RM-F01
- RM-F04
- RM-E06
- FOXSAT-HDR
- HDR-1000GB
- HDR-1TB
- HDR-320GB
- HDR-500GB
- HD-FOX-T2
- HDR-FOX-T2
- HDR-FOX-T2-1TB
- HDR-FOX-T2-500GB
- IHDR-5200C
- IHRD-5050C
- IRHD-5100C

3. Setup

3.1 Battery Installation

To begin using your remote control, you must install two AAA batteries. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: Battery compartment for two AAA batteries.

3.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required. Simply point the remote control towards your Humax Foxsat HDR Freesat Box and operate as you would with the original remote.

4. Operation

The CHUNGHOP replacement remote control functions identically to the original remote for your Humax Foxsat HDR Freesat Box. All buttons are pre-configured to perform their respective actions.

4.1 Basic Functions

- **Power Button:** Turns the device on or off.
- **Number Buttons (0-9):** For direct channel input.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes the television channel.
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** For controlling media playback.
- **Guide Button:** Accesses the electronic program guide.
- **Menu Button:** Opens the main menu.
- **Exit/Back Button:** Returns to the previous screen or exits a menu.

Refer to your Humax Foxsat HDR Freesat Box user manual for specific functions of each button if you require detailed information beyond basic operation.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure that two fresh AAA batteries are correctly installed with the proper polarity (+/-). Weak or dead batteries are the most common cause of remote control malfunction.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the infrared receiver on your Humax Foxsat HDR Freesat Box. Obstructions can block the signal.
- **Distance:** Operate the remote control within a reasonable distance from the device.
- **Interference:** Bright lights or other electronic devices emitting infrared signals can sometimes interfere with the remote control's operation. Try moving away from potential sources of interference.

5.2 Specific Button Not Working

- If only a specific button is not working, try pressing it firmly. If the issue persists, it might indicate a fault with the remote control.

6. Specifications

Feature	Detail
Brand	CHUNGHOP
Compatible Models	Humax Foxsat HDR Freesat Box (RM-F01, RM-F04, RM-E06, FOXSAT-HDR, HDR-1000GB, HDR-1TB, HDR-320GB, HDR-500GB, HD-FOX-T2, HDR-FOX-T2, HDR-FOX-T2-1TB, HDR-FOX-T2-500GB, IHDR-5200C, IHRD-5050C, IRHD-5100C)

Feature	Detail
Connectivity Technology	Infrared
Controller Type	Button Control
Special Feature	Ergonomic Design
Max Number of Supported Devices	1
Batteries Required	2 x AAA (not included)

7. Maintenance


To ensure the longevity and proper functioning of your remote control:

- Keep the remote control clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote control to extreme temperatures, direct sunlight, or moisture.
- Do not drop the remote control or subject it to strong impacts.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.

8. Support

For any questions or assistance regarding your CHUNGHOP Replacement Remote Control, please contact the manufacturer or seller. Support inquiries are typically answered within 24 hours.
You can often find contact information on the product packaging or through the retailer where the item was purchased.



	Chunghop RM-L988 Universal Remote Controller User Manual Comprehensive user manual for the Chunghop RM-L988 Eleven-in-one Universal Remote Controller, detailing setup, functions, and code lists for various home appliances.
Пульт дистанционного управления универсальный Chunghop K-2018E Руководство пользователя Данное руководство предназначено для пользователей универсального пульта дистанционного управления Chunghop K-2018E. В нем описаны функции пульта, методы настройки (ручной ввод, поиск, авто), установка батарей, настройка часов и таймера, а также таблица кодов производителей кондиционеров. Обратите внимание, что пульта дистанционного управления Chunghop K-2018E не следует использовать вблизи огня, воды или других источников влаги. Настройка пульта ДУ Пульт ДУ имеет следующие основные функции: Дистанционный поиск 1. Дистанционный поиск пульта ДУ и включение/выключение кондиционера. 2. Поиск и установка памяти пульта ДУ на канал ДУ пульта Chunghop K-2018E. Вам необходимо нажать на кнопку поиска пульта ДУ, чтобы найти канал пульта Chunghop K-2018E. 3. Установка пульта Chunghop K-2018E на канал пульта Chunghop K-2018E. Пульт ДУ имеет следующие основные функции: 1. Дистанционный поиск пульта ДУ и включение/выключение кондиционера. 2. Поиск и установка памяти пульта ДУ на канал ДУ пульта Chunghop K-2018E. Вам необходимо нажать на кнопку поиска пульта ДУ, чтобы найти канал пульта Chunghop K-2018E. 3. Установка пульта Chunghop K-2018E на канал пульта Chunghop K-2018E.	Chunghop K-2018E Универсальный Пульт Дистанционного Управления - Руководство Пользователя Подробное руководство пользователя для универсального пульта дистанционного управления Chunghop K-2018E. Инструкции по настройке, использованию дополнительных функций, гарантии и утилизации.
	CHUNGHOP K-2098E Universal A/C Remote Operating Instructions This document provides operating instructions for the CHUNGHOP K-2098E Universal A/C Remote. It details setup methods, additional functions, and a comprehensive code table for compatibility with various air conditioner brands.
	CHUNGHOP K-100ES Универсальный пульт ДУ: Инструкция по эксплуатации Полное руководство пользователя для универсального пульта CHUNGHOP K-100ES. Описание функций, панель управления, методы настройки (ручной ввод, поиск, авто), установка батарей, настройка часов и таймера, а также таблица кодов производителей кондиционеров.
	CHUNGHOP K-1028E Universal Air Conditioner Remote Control User Manual User manual for the CHUNGHOP K-1028E universal air conditioner remote control. Learn setup, features, and compatibility with various AC brands.
Univerzális klíma távirányító (UT-002)  Használati és kezelési útmutató	Univerzális klíma távirányító UT-002 Használati és Kezelési Útmutató Ez a dokumentum az Univerzális klíma távirányító (UT-002) használati és kezelési útmutatója. Tartalmazza a biztonsági előírásokat, specifikációkat, használati utasításokat, ápolási és tisztítási útmutatókat, valamint a leselejtezési információkat.