BCB Controllers One Piece-PS5-NM

BCB Controllers Custom PS-5 Wireless Controller - One Piece Edition User Manual

Model: One Piece-PS5-NM

Introduction

This manual provides comprehensive instructions for the BCB Controllers Custom PS-5 Wireless Controller, featuring a unique One Piece Hydro-dip design. This controller is compatible with PlayStation 5 consoles and PC Windows 10 devices. The Hydro-dip painting process ensures a durable, non-fading design that is integrated into the controller's surface, unlike simple skins that may peel or wrinkle. This controller offers dynamic adaptive triggers, haptic feedback, and a built-in microphone, enhancing your gaming experience.



Image: Close-up view of the custom One Piece PS5 controller, highlighting the detailed hydro-dip artwork.

Setup

1. Initial Pairing with PlayStation 5 Console

1. Ensure your PS5 console is powered on.
2. Connect the controller to your PS5 console using a USB-C cable (not included).
3. Press the PS button on the controller. The controller will pair with the console.
4. Once paired, you can disconnect the USB-C cable for wireless use. The controller will automatically connect wirelessly in the future.

2. Pairing with PC (Windows 10)

1. Ensure your PC has Bluetooth enabled.
2. On the controller, press and hold the PS button and the Share button simultaneously until the light bar flashes. This indicates pairing mode.
3. On your PC, go to **Settings** > **Devices** > **Bluetooth & other devices**.
4. Click **Add Bluetooth or other device** > **Bluetooth**.
5. Select the controller (usually named "Wireless Controller") from the list of available devices.
6. Follow any on-screen prompts to complete the pairing process.

3. Charging the Controller

- Connect the controller to your PS5 console or a compatible USB charger using a USB-C cable.
- The light bar on the controller will slowly blink orange while charging and turn off when fully charged.

Operating Instructions

Basic Functions

- **PS Button:** Powers on the controller, accesses the Control Center on PS5, or returns to the home screen.
- **Share Button:** Opens the Create menu for screenshots and video clips.
- **Options Button:** Used for in-game menus and options.
- **Directional Buttons (D-Pad):** Navigation and specific in-game actions.
- **Action Buttons (Triangle, Circle, Cross, Square):** Primary in-game actions.
- **Analog Sticks:** Movement and camera control.
- **L1/R1 Buttons:** Shoulder buttons for various in-game functions.
- **L2/R2 Triggers:** Adaptive triggers provide varying levels of force and tension depending on in-game actions.
- **Touchpad:** Interactive surface for specific game controls.
- **Microphone:** Built-in microphone for voice chat. Mute button located below the PS button.

Haptic Feedback

The controller features advanced haptic feedback, providing immersive tactile sensations that simulate in-game environments and actions. This feature is automatically enabled when supported by the game.



Image: A user holding the custom PS5 controller, actively engaged in gameplay on a television screen.

Maintenance

Cleaning

- Use a soft, dry cloth to wipe the controller's surface.
- For stubborn dirt, slightly dampen the cloth with water or a mild electronic cleaning solution. Avoid harsh chemicals.
- Do not spray cleaning solutions directly onto the controller.
- Ensure no liquid enters the button gaps or ports.

Storage

- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the controller to prevent damage.

Hydro-Dip Printing Care

The custom design is applied using advanced Hydro-dip printing technology, ensuring the colors do not fade and the design does not peel off like a skin. Regular cleaning as described above is sufficient to maintain its appearance.



Image: The custom PS5 controller with text indicating 'WATER TRANSFER PRINTING', demonstrating the durable hydro-dip application.

Troubleshooting

Controller Not Connecting/Responding

- **Re-pair the controller:** Follow the initial pairing steps for your PS5 or PC.
- **Reset the controller:** Locate the small reset button on the back of the controller (inside a small hole near the L2 button). Use a thin tool (like a straightened paperclip) to press and hold the button for 3-5 seconds. Then, attempt to re-pair.
- **Check USB cable:** If connecting via cable, ensure the USB-C cable is functional and securely connected.
- **Console/PC restart:** Restart your PlayStation 5 console or PC.

Battery Not Charging

- **Verify cable and port:** Ensure the USB-C cable is properly connected to both the controller and the charging source (PS5 or wall adapter). Try a different USB-C cable or charging port.
- **Charging source:** Ensure the charging source is providing power.

Buttons/Sticks Not Functioning Correctly

- **Reset controller:** Perform a controller reset as described above.
- **Software updates:** Ensure your PS5 console or PC operating system is up to date, as this can sometimes resolve compatibility issues.

Specifications

Model Number	One Piece-PS5-NM
Brand	BCB Controllers (BABY CUDDLE BOX)
Compatibility	PlayStation 5 Console, PC Windows 10
Connectivity	Wireless (Bluetooth), USB-C
Printing Technology	Hydro-Dip Painting (Water-Transfer Printing)
Features	Adaptive Triggers, Haptic Feedback, Built-in Microphone
Item Weight	15.2 ounces
Package Dimensions	7.52 x 7.52 x 2.8 inches

Warranty and Support

Warranty Information

BCB Controllers adheres to Amazon's after-sales service policy. While a specific warranty duration is not provided, the product is covered by Amazon's return and service policies. The Hydro-dip printing is designed for permanence and resistance to fading or peeling under normal use.

Customer Support

For any inquiries, maintenance questions, or return services, please contact the seller directly through your Amazon order history:

- Access your **Order History** on Amazon.
- Locate your purchase of the BCB Controllers Custom PS-5 Wireless Controller.
- Click on the **Seller Name** (BCB CONTROLLERS).
- Select **Contact the seller** to reach our support team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question