

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Replacement Silicone Band for UMIDIGI Uwatch 5 Fitness Tracker User Manual

Lamshaw UMIDIGI Uwatch 5 Band

Lamshaw Replacement Silicone Band for UMIDIGI Uwatch 5 Fitness Tracker User Manual

1. INTRODUCTION

This manual provides instructions for the installation, use, and maintenance of your Lamshaw Replacement Silicone Band, designed for compatibility with the UMIDIGI Uwatch 5 Fitness Tracker. Please read this manual carefully to ensure proper handling and longevity of your product.



Image 1.1: UMIDIGI Uwatch 5 Fitness Tracker with the blue Lamshaw silicone replacement band.


2. SETUP: INSTALLATION AND REMOVAL

The Lamshaw replacement band features a quick-release design for easy attachment and detachment from your UMIDIGI Uwatch 5 Fitness Tracker.

2.1. Installation

1. Locate the spring bars on the ends of your new Lamshaw silicone band.
2. Align one end of the spring bar with the lug hole on one side of your UMIDIGI Uwatch 5 watch case.

3. Gently push the small lever on the spring bar inwards to retract the pin.
4. While holding the lever, guide the other end of the spring bar into the corresponding lug hole on the opposite side of the watch case.
5. Release the lever, ensuring both ends of the spring bar are securely seated in the lug holes. Gently tug on the band to confirm it is locked in place.
6. Repeat the process for the other half of the band.






Image 2.1: Lamshaw silicone band showing quick-release spring bars.

2.2. Removal

1. To remove the band, locate the small lever on the spring bar at the connection point between the band and the watch case.
2. Push the lever inwards to retract the spring bar pin.
3. Gently pull the band away from the watch case. The band should detach easily.
4. Repeat for the other half of the band.



Image 2.2: Close-up of the band's buckle and texture.

3. OPERATING: WEARING AND ADJUSTMENT

For optimal comfort and performance of your UMIDIGI Uwatch 5, ensure the Lamshaw replacement band is worn

correctly.

- **Wearing Position:** Wear the fitness tracker snugly on your wrist, typically one finger's width above your wrist bone.
- **Adjustment:** Use the stainless steel buckle to adjust the band to a comfortable fit. It should be snug enough not to slide around, but not so tight that it restricts circulation or causes discomfort. The unique slim band design allows your skin to breathe, reducing sweat accumulation.
- **Material Benefits:** The high-quality elastomer material is soft, lightweight, and durable, designed for comfortable daily wear and to prevent skin irritation.

4. MAINTENANCE

Proper care will extend the life and appearance of your Lamshaw silicone band.

- **Cleaning:** Regularly clean the band with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely before reattaching to your device.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the silicone material and the stainless steel buckle.
- **Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

If you encounter any issues with your Lamshaw replacement band, consider the following:

- **Band feels loose or uncomfortable:** Adjust the buckle to a tighter setting. Ensure the band is not worn too high or too low on the wrist.
- **Difficulty attaching/detaching:** Ensure the quick-release spring bar is fully retracted when inserting or removing. Check that the lug holes on your UMIDIGI Uwatch 5 are clear of debris.
- **Skin irritation:** Ensure the band is clean and dry. If irritation persists, try adjusting the tightness or consult a healthcare professional.
- **Buckle issues:** Inspect the stainless steel buckle for any visible damage or obstruction. Ensure it latches securely.

6. SPECIFICATIONS

Feature	Detail
Product Name	Lamshaw Replacement Silicone Band
Compatibility	UMIDIGI Uwatch 5 Fitness Tracker
Material	High-quality Elastomer (Silicone), Stainless Steel Buckle
Color (This Variant)	Blue
Installation	Quick-release spring bars
Manufacturer	Lamshaw
ASIN	B09KX156SB

7. WARRANTY AND SUPPORT

Lamshaw offers a commitment to quality for its products.

- **Warranty:** For 30 days after the date of purchase, Lamshaw addresses all quality-related issues with a replacement or refund.
- **Contact Support:** If you receive a defective item or have any questions or concerns regarding your product, please contact the seller directly through your purchase platform for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09KX156SB>

More documents and user manuals: <https://manuals.plus/>