RUSTOWN PDHX8002

RUSTOWN Farmhouse Wall Cabinet with Sliding Barn Door (Model PDHX8002)

Instruction Manual

Product Overview Safety Information Package Contents Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The RUSTOWN Farmhouse Wall Cabinet (Model PDHX8002) is a versatile storage solution designed for various rooms including bathrooms, kitchens, living rooms, and laundry areas. This wall-mounted cabinet features a rustic farmhouse design with a sliding barn door and adjustable shelving to accommodate diverse storage needs.

Key Features:

- **Vintage Farmhouse Design:** Constructed with a wooden frame and vintage wood grain surface, complemented by rustic metal accents.
- **Flexible Storage:** Features a sliding door for concealed storage. The left side offers two fixed spaces, while the right side includes two racks with six adjustable height options for customized organization.
- **Durable Construction:** Made from high-quality engineered wood and metal components, ensuring a stable and durable structure.
- **Multi-Scene Application:** Suitable for installation in bathrooms, kitchens, living rooms, and laundry rooms. Can be wall-mounted or used as a standalone unit.



Figure 1: RUSTOWN Farmhouse Wall Cabinet (Model PDHX8002) in Washed Oak.

2. Safety Information

Please read and understand all safety instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage to the product.

- **Wall Mounting:** Always mount the cabinet securely to a wall stud or other suitable structural support. Use appropriate hardware for your wall type.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 44 pounds (20 kg) for the entire cabinet. Distribute weight evenly across shelves.
- **Assembly:** Follow all assembly steps carefully. Ensure all fasteners are tightened securely before use.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- **Stability:** Regularly check the cabinet for stability and ensure all mounting hardware remains secure.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present and undamaged. If any items are missing or damaged, please contact RUSTOWN customer support.
The package typically includes:

- Cabinet panels (top, bottom, sides, back, shelves)
- Sliding barn door and associated hardware (track, rollers, handle)
- Adjustable shelf pins
- Assembly hardware (screws, dowels, cam locks, etc.)
- Wall mounting hardware
- Detailed instruction manual

4. Assembly Instructions

Assembly of the RUSTOWN Farmhouse Wall Cabinet is designed to be straightforward. Please follow the detailed instructions provided in your package. A Phillips head screwdriver and a level are typically required.

1. **Prepare Workspace:** Clear a spacious, clean, and flat area for assembly. Lay out all components and hardware.
2. **Assemble Cabinet Frame:** Connect the side panels to the top and bottom panels using the provided hardware. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame.
4. **Install Fixed Shelves:** Secure any fixed shelves as indicated in the manual.
5. **Install Sliding Door Track:** Attach the sliding door track to the top of the cabinet. Ensure it is level and securely fastened.
6. **Attach Door Hardware:** Install the rollers and handle onto the barn door.
7. **Mount Door:** Carefully hang the barn door onto the sliding track. Test its smooth operation.
8. **Install Adjustable Shelves:** Insert shelf pins into the desired height slots on the right side of the cabinet and place the adjustable shelves.
9. **Wall Mounting:** Locate wall studs for secure mounting. Mark the drilling points on the wall, ensuring they are level. Drill pilot holes and install the wall mounting hardware. Carefully lift and secure the cabinet to the wall. It is recommended to have two people for this step.



Figure 2: Cabinet dimensions for planning installation. Overall dimensions: 27.6"H x 21.7"W x 7.8"D.



Figure 3: Detail of adjustable shelf positions on the right side of the cabinet.

5. Operating Instructions

The RUSTOWN Farmhouse Wall Cabinet is designed for simple and functional use.

- **Sliding Door:** To access contents, gently slide the barn door along its track. The door can be positioned to cover either the left fixed shelves or the right adjustable shelves.
- **Adjustable Shelves:** The right side of the cabinet features adjustable shelves. To change shelf height, remove the shelf, reposition the shelf pins into the desired slots, and then place the shelf back onto the pins. Ensure pins are fully inserted and the shelf is stable before placing items on it.
- **Storage:** Utilize the various compartments for organizing toiletries, kitchen items, laundry supplies, or decorative objects. The cabinet is suitable for use in bathrooms, kitchens, living rooms, and laundry rooms.



Figure 4: Cabinet installed above a toilet, demonstrating practical bathroom storage.



Figure 5: Cabinet used for kitchen storage, showcasing its versatility.

6. Maintenance

To ensure the longevity and appearance of your RUSTOWN Farmhouse Wall Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Spills:** Promptly clean up any spills to prevent staining or water damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Sliding Mechanism:** Keep the sliding door track clean and free of debris to ensure smooth operation.

7. Troubleshooting

If you encounter any issues with your RUSTOWN Farmhouse Wall Cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Door does not slide smoothly	Track is dirty or obstructed; rollers are misaligned.	Clean the track of any debris. Check that the rollers are properly seated and aligned on the track.
Cabinet feels unstable after mounting	Not securely mounted to wall studs; mounting hardware is loose.	Ensure the cabinet is mounted into wall studs or appropriate anchors. Retighten all wall mounting hardware. Do not overload the cabinet.
Missing parts or damaged components	Manufacturing error or shipping damage.	Do not proceed with assembly. Contact RUSTOWN customer support immediately for replacement parts.
Shelves are not level	Shelf pins are not inserted correctly or are at different heights.	Ensure all shelf pins are fully inserted into the corresponding holes at the same height level.

8. Specifications

Feature	Detail
Brand	RUSTOWN
Model Number	PDHX8002
UPC	761736129303
Color	Washed Oak
Material	Engineered Wood, Metal (handle)
Product Dimensions (D x W x H)	7.8" x 21.7" x 27.6" (19.8 cm x 55.1 cm x 70.1 cm)
Item Weight	23 pounds (10.4 kg)
Weight Capacity (Maximum)	44 pounds (20 kg)
Number of Shelves	2 (adjustable) + 2 (fixed)
Installation Type	Wall Mount
Door Style	Barn Door (sliding)

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact RUSTOWN directly. Keep your proof of purchase for any warranty claims.

Manufacturer: RUSTOWN

Contact Information: Please refer to the RUSTOWN official website or the contact details provided in your product packaging for support.

© 2026 RUSTOWN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question