



[Manuals.plus](#) /

> [Ultimate Ears](#) /

> Ultimate Ears WONDERBOOM 3 Portable Wireless Bluetooth Speaker User Manual

Ultimate Ears 984-001810

Ultimate Ears WONDERBOOM 3 Portable Wireless Bluetooth Speaker User Manual

Model: 984-001810

1. INTRODUCTION

The Ultimate Ears WONDERBOOM 3 is an ultra-portable Bluetooth speaker designed to deliver a surprisingly bigger 360-degree stereo sound. It is engineered for outdoor use, featuring a durable, waterproof, dustproof, and floatable design. With an extended battery life and impressive wireless range, the WONDERBOOM 3 is your ideal companion for any adventure, from pool parties to camping trips.



Image: Ultimate Ears WONDERBOOM 3 speaker in Joyous Brights Grey, showcasing its compact and robust design.

2. WHAT'S IN THE BOX

- WONDERBOOM 3 wireless portable Bluetooth speaker (bungee attached)
- USB cable
- Documentation (Quick Start Guide)

IN THE BOX



Image: The WONDERBOOM 3 speaker and its accompanying USB charging cable, as found in the product packaging.

3. KEY FEATURES

3.1. Bigger 360-Degree Sound with Outdoor Boost

The WONDERBOOM 3 delivers full stereo audio with boosted sound. Activate the Outdoor Boost button for sound specifically tuned for open-air environments, ensuring clear and powerful audio even outdoors.

BIGGER 360 SOUND WITH OUTDOOR BOOST



Image: A woman paddling in a kayak with a WONDERBOOM 3 speaker attached to her backpack, highlighting the speaker's 360-degree sound and outdoor boost feature.

3.2. Extended 14-Hour Battery Life

Enjoy up to 14 hours of continuous music playback on a single charge, allowing you to keep the party going without frequent recharging.

14 HOURS BATTERY LIFE



Image: Two WONDERBOOM 3 speakers positioned in front of a group of people enjoying an outdoor movie, emphasizing the 14-hour battery life.

3.3. Waterproof, Dustproof, and Floatable (IP67 Rated)

The WONDERBOOM 3 boasts an IP67 rating, meaning it can be submerged in 1 meter of water for up to 30 minutes and is fully protected from dust. Its floatable design makes it perfect for use around pools, beaches, or even in the shower.

WATERPROOF + FLOATABLE



Image: Two WONDERBOOM 3 speakers floating on the surface of water, highlighting their waterproof and floatable capabilities.

3.4. Double Up for Stereo Sound

Pair two WONDERBOOM 3 speakers together for an even louder and more immersive audio experience. Press once to double up the sound, and press again for true stereo playback with distinct left and right channels.

DOUBLE UP FOR STEREO SOUND



Image: Two hands holding two WONDERBOOM 3 speakers, demonstrating the ability to pair them for enhanced stereo sound.

3.5. Durable, Portable, with 131 ft Range

The speaker is drop-tested from 5 feet (1.5 meters) and is dirt resistant, ensuring durability. Its compact size and integrated bungee loop make it highly portable. Enjoy a wireless range of up to 131 feet (40 meters), giving you freedom to move without losing connection.




Image: A group of friends gathered around a campfire, with a WONDERBOOM 3 speaker in the foreground, highlighting its suitability for outdoor and portable use.

3.6. Made with Recycled Materials

Plastic parts in the WONDERBOOM 3 include a minimum of 31% post-consumer recycled plastic by weight, contributing to sustainability efforts.



Image: The 'Certified Recycled Content' logo, indicating the use of sustainable materials in the speaker's construction.

4. SPEAKER OVERVIEW

AVAILABLE IN MULTIPLE COLORS



Image: A detailed diagram of the WONDERBOOM 3 speaker, showing the location of the volume control buttons, Micro USB charging port, Double Up button, and Power On/Off button.

- **Volume Control Buttons:** Large '+' and '-' buttons on the front for adjusting audio volume.
- **Power On/Off Button:** Located on the top surface.
- **Double Up Button:** Circular button on the top surface for pairing with another WONDERBOOM 3.
- **Micro USB Charging Port:** Located at the bottom, protected by a rubber flap.
- **Bungee Loop:** For easy carrying or hanging.

5. SETUP

5.1. Charging Your Speaker

1. Open the rubber flap at the bottom of the speaker to expose the Micro USB port.
2. Connect the provided USB cable to the speaker's Micro USB port.
3. Plug the other end of the USB cable into a USB power adapter (not included) or a computer's USB port.

4. The LED indicator on the top of the speaker will show charging status. A full charge takes approximately 2.6 hours.

5.2. Powering On/Off

- To power on, press the Power On/Off button located on the top of the speaker.
- To power off, press the Power On/Off button again.

5.3. Bluetooth Pairing

1. Turn on your WONDERBOOM 3 speaker.
2. Press and hold the Bluetooth button (small button next to the power button) until you hear a tone and the LED indicator flashes rapidly.
3. On your mobile device (smartphone, tablet), go to the Bluetooth settings.
4. Select 'WONDERBOOM 3' from the list of available devices.
5. Once paired, you will hear a confirmation tone, and the LED indicator will glow solid.

6. OPERATING INSTRUCTIONS

6.1. Adjusting Volume

- Press the large '+' button on the front of the speaker to increase volume.
- Press the large '-' button on the front of the speaker to decrease volume.

6.2. Playing/Pausing Audio

- Press the Ultimate Ears logo button on the top of the speaker once to play or pause the current audio track.

6.3. Activating Outdoor Boost Mode

- To optimize sound for outdoor environments, press the small 'tree' button located on the bottom of the speaker. You will hear a confirmation tone.
- Press the button again to deactivate Outdoor Boost.

6.4. Double Up Mode (Pairing Two WONDERBOOM 3 Speakers)

1. Ensure both WONDERBOOM 3 speakers are powered on and not currently paired with any other device.
2. On the first speaker, press the Double Up button (circular button on the top). The LED will flash.
3. On the second speaker, press the Double Up button.
4. Both speakers will connect, and you will hear a confirmation tone. They will now play audio in unison.
5. To switch to stereo mode (left/right channels), press the Double Up button on either speaker again.
6. To disconnect, press and hold the Double Up button on either speaker until you hear a tone.

7. MAINTENANCE

7.1. Cleaning

- The WONDERBOOM 3 is waterproof. To clean, rinse it with fresh water.
- For stubborn dirt, use a soft brush and mild soap.
- Ensure the Micro USB port cover is securely closed before cleaning.

7.2. Drying After Water Exposure

- After exposure to water, shake the speaker gently to remove excess water.
- Allow the speaker to air dry completely before charging to prevent damage to the port.

7.3. Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

8.1. No Power

- Ensure the speaker is charged. Connect it to a power source using the USB cable.
- Press and hold the Power On/Off button for a few seconds.

8.2. No Sound or Poor Sound Quality

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is within the Bluetooth range (up to 131 ft / 40 m).
- Move the speaker closer to your device and away from other wireless interference sources.
- Try re-pairing the speaker with your device.

8.3. Bluetooth Connection Issues

- Turn off and then turn on Bluetooth on your device.
- Forget the 'WONDERBOOM 3' from your device's Bluetooth list and re-pair.
- Restart both your device and the WONDERBOOM 3 speaker.

9. SPECIFICATIONS

Feature	Specification
Brand	Ultimate Ears
Model Number	984-001810
Speaker Maximum Output Power	10 Watts
Audio Output Mode	Stereo
Connectivity Technology	Bluetooth, USB
Wireless Technology	Bluetooth
Bluetooth Range	40 Meters (131 Feet)
Battery Average Life	14 Hours
Water Resistance Level	Waterproof (IP67)
Drop Tested	5 ft / 1.5 m
Item Dimensions (D x W x H)	4.65"D x 5.2"W x 4.53"H
Recycled Plastic Content	Minimum 31% post-consumer recycled plastic by weight

10. OFFICIAL PRODUCT VIDEOS

FANTASTIC waterproof, Bluetooth speaker!

Your browser does not support the video tag.

Video Description: A seller review highlighting the fantastic waterproof capabilities of the WONDERBOOM 3 Bluetooth speaker, demonstrating its durability and sound quality.

Review- WONDERBOOM 3, Portable Wireless Bluetooth Speaker

Your browser does not support the video tag.

Video Description: A seller review providing an overview of the WONDERBOOM 3, focusing on its portability, ease of use, and sound performance.

Watch this review of the Ultimate Ears Wonderboom 3 speaker

Your browser does not support the video tag.

Video Description: A seller's detailed review of the Ultimate Ears WONDERBOOM 3 speaker, covering its features and user experience.

Ultimate Ears Wonderboom Bluetooth Speaker

Your browser does not support the video tag.

Video Description: A seller's review showcasing the Ultimate Ears WONDERBOOM Bluetooth speaker, highlighting its design and functionality.

11. WARRANTY AND SUPPORT

11.1. Manufacturer's Warranty

The Ultimate Ears WONDERBOOM 3 is covered by a manufacturer's warranty. For detailed information regarding the warranty terms and conditions, please refer to the official Ultimate Ears website or contact customer service.

You can also request warranty information from Amazon customer service: [Amazon Customer Service Warranty Request](#)

11.2. Customer Support

For further assistance, technical support, or inquiries about your WONDERBOOM 3 speaker, please visit the official Ultimate Ears support page or contact their customer service team directly.