

ROTTOGOON ROLP380AB2

ROTTOGOON 27.5 Inch Farmhouse Table Lamps with USB-C and USB-A Charging Ports Instruction Manual

Model: ROLP380AB2

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your ROTTOGOON 27.5 inch Tall Farmhouse Table Lamps. These lamps feature an oil-rubbed bronze finish, dual lighting options, and integrated USB-C and USB-A charging ports for convenience. Please read this manual thoroughly before use to ensure proper installation and safe operation.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 2 x Lamp Bases with USB Charging Ports and Switches
- 2 x Fabric Lampshades (assembly required)
- 2 x T10 4W LED Bulbs (for night light, included)
- 2 x Finials

Note: E26 bulbs for the main light are not included and must be purchased separately.

SPECIFICATIONS

Feature	Specification
Brand	ROTTOGOON
Model Number	ROLP380AB2
Dimensions (Overall)	13"D x 13"W x 27.5"H
Base Material	Metal

Feature	Specification
Finish Type	Oil Rubbed Bronze
Shade Material	Linen
Shade Color	Oatmeal
Main Light Bulb Base	E26 (Max 60W, not included)
Night Light Bulb Type	T10 4W LED (included)
Power Source	Corded Electric
USB Charging Ports	1 x USB-A, 1 x USB-C (5V/2.1A)
Switch Type	Dual Push Button
Voltage	120 Volts
Assembly Required	Yes

The lamp measures 27.5 inches in height, with a shade diameter of 13 inches. The base is 5 inches wide.



Image: Lamp dimensions and bulb specifications.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your ROTTOGOON table lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, flat surface.
2. **Assemble Lampshade:** The fabric lampshade may require assembly. Connect the metal rings to the fabric shade using the provided clips or Velcro, ensuring the shade is taut and circular.
3. **Install Main Light Bulb (Not Included):** Screw an E26 base bulb (maximum 60W) into the upper socket of the lamp base. Do not overtighten.
4. **Install Night Light Bulb (Included):** Screw the provided T10 4W LED bulb into the lower socket within the lamp base.
5. **Attach Lampshade to Base:** Place the assembled lampshade onto the lamp harp (the U-shaped wire frame above the main bulb socket).
6. **Secure Lampshade with Finial:** Screw the finial onto the top of the lamp harp to secure the lampshade in place.



Image: Lamp assembly diagram.



OPERATING INSTRUCTIONS

Powering the Lamp

Plug the lamp's power cord into a standard 120V AC electrical outlet.

Controlling the Lights

The lamp features two independent light sources: a main light (E26 bulb) and a night light (T10 LED bulb). These are controlled by two separate push-button switches located on the lamp base.

- **Left Switch:** Controls the main light (top bulb). Press once to turn on, press again to turn off.
- **Right Switch:** Controls the night light (bottom bulb). Press once to turn on, press again to turn off.

You can operate the lights in three modes:

1. **Top Light Only:** Press the left switch to ON.
2. **Bottom Light Only:** Press the right switch to ON.
3. **Both Lights On:** Press both the left and right switches to ON.



Image: Lamp lighting modes (Top, Bottom, Both On).



Image: Detail of USB ports and push-button switches.

Using the USB Charging Ports

The lamp base includes one USB-A port and one USB-C port, providing 5V/2.1A output for charging electronic devices. These ports function independently of the lamp's lighting status, meaning you can charge devices even when the lamp lights are off.

- Connect your device's charging cable to the appropriate USB-A or USB-C port on the lamp base.
- Ensure the lamp is plugged into a live electrical outlet for the charging ports to function.

Two Built-in USB Charging Ports

Reach out, plug in and your cellphone is powered up



Image: USB charging ports in use.

MAINTENANCE

To ensure the longevity and optimal performance of your ROTTOGOON table lamps, follow these maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe down the lamp base and shade. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Always unplug the lamp before replacing bulbs. Allow bulbs to cool completely before handling. Replace E26 bulbs with a maximum of 60 watts. The T10 LED night light bulb is designed for long life and typically does not require frequent replacement.
- **Cord Care:** Regularly inspect the power cord for any signs of damage. Do not use the lamp if the cord is frayed or damaged.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	<ol style="list-style-type: none"> 1. Lamp not plugged in. 2. Bulb is loose or burnt out. 3. Power outlet is not working. 	<ol style="list-style-type: none"> 1. Ensure the power cord is securely plugged into a live outlet. 2. Check if the bulb is screwed in tightly. Replace the bulb if it is burnt out. 3. Test the outlet with another device.
USB ports are not charging devices.	<ol style="list-style-type: none"> 1. Lamp not plugged in. 2. Device cable is faulty. 3. Device requires more power than supplied. 	<ol style="list-style-type: none"> 1. Ensure the lamp is plugged into a live electrical outlet. 2. Try a different charging cable. 3. The USB ports provide 5V/2.1A. Ensure your device is compatible with this output.
Light flickers.	<ol style="list-style-type: none"> 1. Loose bulb. 2. Incompatible bulb. 	<ol style="list-style-type: none"> 1. Tighten the bulb in its socket. 2. Ensure the bulb wattage does not exceed 60W for the main light.

SAFETY INFORMATION

- Always unplug the lamp from the power outlet before cleaning, replacing bulbs, or performing any maintenance.
- Do not use bulbs exceeding the specified maximum wattage (60W for E26 main light).
- Keep the lamp away from water or other liquids. Do not immerse any part of the lamp in water.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- This lamp is designed for indoor use only.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ROTTOGOON table lamps, please contact the manufacturer directly. Refer to your purchase documentation for specific warranty details and contact information.