



Manuals.plus /

› Tangkula /

› Tangkula 2 Person Swing Glider Chair with Center Table - User Manual

Tangkula op70357tu

Tangkula 2 Person Swing Glider Chair with Center Table - User Manual

Model: op70357tu | Brand: Tangkula

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of **530 lbs (240 kg)**. Exceeding this limit may result in injury or damage to the product.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Place the glider on a flat, stable, and level surface to ensure proper operation and prevent tipping.
- Keep children and pets away from the glider during assembly.
- Do not stand on the glider or use it for purposes other than intended seating.
- Exercise caution when using the tempered glass table. Avoid placing excessively hot items directly on the glass without protection.

2. PRODUCT OVERVIEW

The Tangkula 2 Person Swing Glider Chair is designed for comfortable outdoor relaxation. It features a sturdy steel frame, breathable mesh fabric seats, and a convenient tempered glass table located between the two seats.



Image 2.1: The Tangkula 2 Person Swing Glider Chair in a patio setting, showcasing its design and functionality.

Key Features:

- **Durable Construction:** Powder-coated alloy steel frame ensures stability and longevity.
- **Comfortable Seating:** Breathable, wear-resistant, and quick-drying mesh fabric for optimal comfort.
- **Integrated Table:** Central tempered glass table for drinks, snacks, or personal items.
- **Smooth Gliding Motion:** Designed for a quiet and gentle rocking experience.
- **Ergonomic Design:** Features an inclined backrest, spacious curved seats, and smooth armrests.

Suitable for Various Occasions


Patio



Backyard



Poolside



Weight Capacity: 530 lbs

Image 2.2: Detailed dimensions of the glider chair. Overall size: 57"L x 27.5"W x 37.5"H. Weight capacity: 530 lbs.

3. PARTS LIST

Please ensure all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Part	Description	Quantity
Main Glider Frame	The primary base structure of the glider.	1
Seat/Backrest Units	Two individual seating units with mesh fabric.	2
Center Table	Tempered glass table for placement between seats.	1
Armrests	Supports for the arms on each side.	2
Hardware Pack	Assorted screws, bolts, and tools for assembly.	1

4. SETUP & ASSEMBLY

Assembly requires careful attention to detail. It is recommended to have two people for easier and safer assembly. Do not over-tighten screws until all components are aligned.

Assembly Video:

Your browser does not support the video tag.

Video 4.1: Step-by-step installation guide for the Tangkula 2 Person Swing Glider Chair. This video demonstrates the complete assembly process.

General Assembly Steps:

1. **Assemble the Base Frame:** Connect the main base components using the provided hardware. Ensure all connections are stable but do not fully tighten yet.
2. **Attach Seat/Backrest Units:** Secure the two seat and backrest units to the main glider frame. Pay attention to the correct orientation of each unit.
3. **Install Armrests:** Fasten the armrests to the sides of the seat/backrest units.
4. **Insert Center Table:** Carefully place the tempered glass table into its designated slot between the two seats. Ensure the clips underneath the table align and press down firmly to secure it.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws and bolts. Do not over-tighten to avoid stripping.

Note: If you find hard to reach the frame, loosen upper screws to adjust the distance, then force them together and tighten.

5. OPERATING INSTRUCTIONS

The Tangkula Glider Chair provides a smooth and gentle gliding motion for relaxation. To operate, simply sit comfortably on either seat and gently push off the ground with your feet to initiate the gliding motion. The chair is designed to glide both forward and backward.

Product Display Video:

Your browser does not support the video tag.

Video 5.1: A display video showcasing the gliding motion and features of the Tangkula 2 Person Swing Glider Chair.



Image 5.1: Illustration of the smooth and gentle gliding mechanism, highlighting the sturdy powder-coated steel frame and anti-slip foot pads.

6. MAINTENANCE & CARE

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** The breathable mesh fabric is wear-resistant and quick-drying. Allow it to air dry completely after cleaning or rain.
- **Frame Care:** The powder-coated steel frame is designed for outdoor use. To prolong its lifespan, consider covering the glider during prolonged periods of harsh weather or when not in use.
- **Glass Table Care:** Clean the tempered glass table with a glass cleaner. Avoid dropping heavy objects on the table.
- **Regular Inspection:** Periodically check all nuts, bolts, and connections to ensure they remain tight. Re-tighten as needed to maintain stability and safety.

7. TROUBLESHOOTING

- **Glider not gliding smoothly:**
 - Check if the glider is on a level surface. Uneven ground can impede gliding motion.
 - Inspect the gliding mechanism for any obstructions or debris.
 - Ensure all assembly bolts are properly tightened, but not over-tightened, which could restrict movement.
- **Wobbling or instability:**
 - Verify that all screws and bolts are fully tightened.
 - Confirm the glider is placed on a firm, level surface.
- **Water pooling on seats after rain:**
 - The mesh fabric is designed to be quick-drying. Ensure the glider is exposed to air and sunlight to facilitate drying.
 - Consider using a protective cover during heavy rain or prolonged periods of non-use.

8. SPECIFICATIONS

Brand:	Tangkula
Model Name:	op70357tu
Color:	Turquoise
Material:	Alloy Steel, Fabric (Mesh)
Product Dimensions (L x W x H):	57" x 27.5" x 37.5"
Item Weight:	44 Pounds (20 kg)
Weight Capacity:	530 Pounds (240 kg)
Recommended Use:	Outdoor (Patio, Garden, Backyard, Poolside, Balcony, Porch, Deck, Lawn)
Assembly Required:	Yes

9. WARRANTY & SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Tangkula customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

You can often find support information on the official Tangkula website or through the retailer where the

product was purchased.