

Sogo SS-10495

Sogo SS-10495 30-Liter Air Fryer Oven Instruction Manual

Model: SS-10495



1. INTRODUCTION

Thank you for choosing the Sogo SS-10495 30-Liter Air Fryer Oven. This appliance combines the functionality of an air fryer and a conventional oven, offering a versatile solution for healthy cooking. With its large capacity and multiple cooking programs, you can prepare a wide variety of meals with less oil. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage rating on the appliance matches your local power supply. Do not immerse the cord, plug, or appliance in water or other liquids.
- **Placement:** Place the appliance on a stable, heat-resistant surface, away from walls and other appliances to allow adequate ventilation. Do not place near flammable materials.
- **Hot Surfaces:** The exterior surfaces and interior of the oven become very hot during operation. Always use oven mitts or the cool-touch handle when opening the door or handling hot accessories.
- **Children:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning. Refer to the 'Maintenance and Cleaning' section for detailed instructions.
- **Accessories:** Only use accessories recommended or supplied by the manufacturer.
- **Ventilation:** Do not block any ventilation openings.

3. PRODUCT OVERVIEW

The Sogo SS-10495 is a versatile 30-liter air fryer oven designed for various cooking methods, including air frying, roasting, baking, and dehydrating. It features a digital control panel with an intuitive touchscreen and a rotary knob for easy operation.

3.1 Main Unit and Control Panel



Image: Front view of the Sogo SS-10495 Air Fryer Oven, showcasing the digital control panel and food cooking inside.

The control panel features a digital display for temperature and time, along with touch controls for various functions and 18 preset programs. A rotary knob allows for precise adjustments.

3.2 Included Accessories

Your Sogo SS-10495 Air Fryer Oven comes with a comprehensive set of accessories to enhance your cooking experience:

- **Chrome Steel Fryer Basket:** Ideal for air frying items like fries, chicken wings, and vegetables.
- **Enameled Baking Tray:** Suitable for baking, roasting, or collecting drips.
- **Chrome Steel Cooking Rack:** For general baking, roasting, or placing dishes.
- **Crumb Tray:** Collects crumbs and drips at the bottom for easy cleaning.
- **SUS430 Rotisserie Fork:** For roasting whole chickens or larger cuts of meat.
- **Extractor Handle:** Safely remove hot accessories from the oven.
- **Chrome Steel Rolling Cage:** For tumbling smaller items during air frying, such as nuts or coffee beans.
- **Chrome Steel Kebab Skewers:** For preparing kebabs.

- **30 cm Pizza Stone:** For baking crispy pizzas.
- **Multi-language Recipe Book:** Provides cooking ideas and guidelines.

4. SETUP

4.1 Unpacking

1. Carefully remove the appliance and all accessories from the packaging.
2. Remove any protective films, stickers, or packaging materials from the unit.
3. Inspect the appliance for any damage. Do not use if damaged.

4.2 Initial Cleaning

1. Wipe the exterior of the oven with a damp cloth.
2. Wash all accessories (fryer basket, baking tray, cooking rack, crumb tray, rotisserie fork, etc.) in warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the interior of the oven with a damp cloth.

4.3 Placement

1. Place the oven on a flat, stable, and heat-resistant surface.
2. Ensure there is at least 10-15 cm (4-6 inches) of clear space on all sides and above the oven for proper air circulation.
3. Do not place the oven directly under cabinets or near curtains or other flammable materials.

4.4 First Use (Burn-Off)

Before cooking food, it is recommended to run the oven empty to eliminate any manufacturing odors:

1. Plug the power cord into a grounded electrical outlet.
2. Set the oven to a temperature of 200°C (390°F) and a time of 15-20 minutes.
3. Operate the oven in a well-ventilated area. A slight odor or smoke may be present; this is normal and will dissipate.
4. Allow the oven to cool completely after this initial cycle.

5. OPERATION

The Sogo SS-10495 offers a variety of cooking functions and preset programs for convenience.

5.1 Power On/Off

- To power on, press the power button on the control panel. The display will illuminate.
- To power off, press and hold the power button until the display turns off.

5.2 Using Preset Programs

The oven features 18 preset menus for common dishes. These programs automatically set the optimal temperature and time.

1. Place your food and appropriate accessory inside the oven.
2. Press the 'Menu' button or navigate through the preset icons on the touchscreen.

3. Select the desired preset program (e.g., Air Fry, Chips, Wings, Pizza, Steak, Cookies, Snacks, Veggies, Toast, Bagel, Bake, Broil, Roast, Dehydrate, Ferment, Defrost, Warm, Reheat).
4. The display will show the default temperature and time for that program. You can adjust these settings using the rotary knob if needed.
5. Press the 'Start/Pause' button to begin cooking.

5.3 Manual Cooking

For custom cooking, you can manually set the temperature and time.

1. Place your food and accessory inside the oven.
2. Use the temperature control button and rotary knob to set the desired temperature (range: 30°C to 230°C).
3. Use the timer control button and rotary knob to set the desired cooking time (up to 12 hours).
4. Press the 'Start/Pause' button to begin cooking.

5.4 Specific Functions

- **Air Fry:** Utilizes rapid hot air circulation for crispy results with minimal oil. Use the fryer basket.
- **Roast:** Ideal for meats and vegetables. The oven supports rotisserie roasting for even cooking.
- **Dehydrate:** The ultra-fast dehydrating function operates for 4-5 hours, suitable for fruits, vegetables, and jerky.
- **Ferment:** Allows for controlled low-temperature fermentation, suitable for yogurt or dough proofing.
- **Dual Cook:** This feature allows for multi-phase cooking, combining two different cooking settings sequentially. Consult the recipe book for specific applications.



Image: The Sogo SS-10495 Air Fryer Oven demonstrating the rotisserie function with a whole chicken.

5.5 Using Multiple Cooking Layers

The oven is designed with 4 cooking layers, allowing you to prepare different foods simultaneously. Ensure proper spacing for air circulation and adjust cooking times as needed.



Image: The Sogo SS-10495 Air Fryer Oven showing multiple cooking layers in use, with fries in the top basket and chicken in the middle.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your Sogo Air Fryer Oven.

6.1 General Cleaning

1. Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage surfaces.

6.2 Cleaning the Interior

- Remove all accessories, including the crumb tray.
- Wipe the interior walls with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used.
- Ensure the interior is completely dry before next use.

6.3 Cleaning Accessories

- Wash the fryer basket, baking tray, cooking rack, crumb tray, rotisserie fork, and other accessories in warm,

soapy water.

- For baked-on food, soak the accessories in warm water for a period before cleaning.
- Rinse thoroughly and dry completely before storing or reusing.

6.4 Cleaning the Exterior

- Wipe the exterior housing with a soft, damp cloth.
- Clean the control panel gently with a soft, dry cloth to avoid scratching the touchscreen.
- The cool-touch handle can be wiped clean with a damp cloth.

7. TROUBLESHOOTING

If you encounter issues with your Sogo Air Fryer Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time; food not turned/shaken.	Do not overcrowd the basket/tray. Adjust temperature/time. Turn or shake food halfway through cooking.
White smoke coming from the oven.	Grease/oil residue from previous cooking; fatty food.	Clean the oven interior and accessories thoroughly. For fatty foods, ensure the crumb tray is clean and consider using less oil.
Oven smells during first use.	Manufacturing residue burn-off.	This is normal. Ensure good ventilation. The smell will dissipate after initial uses.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Technical details for the Sogo SS-10495 Air Fryer Oven:

Feature	Specification
Model Number	SS-10495
Capacity	30 Liters
Power	1800 W
Voltage	220-240V~ 50-60Hz
Temperature Range	30°C - 230°C
Timer	Up to 12 hours with auto shut-off
Control Type	Digital Touch Control with Rotary Knob

Feature	Specification
Material	Aluminum housing, Double Glass Door
Noise Level	44 dB
Color	Black
Item Weight	2 Kilograms (Note: This weight may refer to packaging or a specific component, as a 30L oven typically weighs more.)

8.1 Dimensions




Image: External dimensions of the Sogo SS-10495 Air Fryer Oven (approximately 45 cm width, 43 cm depth, 36 cm height).



Image: Internal cooking space dimensions of the Sogo SS-10495 Air Fryer Oven (approximately 36 cm width, 35 cm depth, 18 cm height).

8.2 Product Label



Image: Product label for the Sogo SS-10495, indicating model number, electrical specifications, and certifications.

9. WARRANTY AND SUPPORT

Sogo provides a commitment to quality for its products. Spare parts for the SS-10495 are available for a period of 2 years from the date of purchase.

For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official Sogo website.



© 2024 Sogo. All rights reserved.

Related Documents - SS-10495

	SOGO DIGI FRYER FLEXI DUO 10.5L (SS-10895) - Manual de Instrucciones y Uso Manual completo de instrucciones para la Freidora de Aire SOGO DIGI FRYER FLEXI DUO de 10.5L (SS-10895). Aprenda a usar, limpiar y mantener su electrodoméstico para preparar comidas saludables y deliciosas.
	SOGO Water Flosser SS-12320: User Manual and Operating Instructions This user manual provides detailed instructions for operating the SOGO Water Flosser (Model SS-12320). Learn about safety precautions, how to use the device, its various tips, troubleshooting common issues, and technical specifications for optimal oral hygiene.
	Manual de Instrucciones SOGO SS-10490 Horno Freidora Multifunción Descubra cómo utilizar su Horno Freidora Multifunción SOGO SS-10490 con este completo manual de instrucciones. Incluye guías de seguridad, componentes, especificaciones técnicas y programas de menú preestablecidos para una experiencia culinaria óptima.

	Manual de Instrucciones SOGO SS-10465: Horno Freidora Multifunción Sin Aceite Descubra cómo utilizar su horno freidora multifunción SOGO SS-10465 con este completo manual de instrucciones. Aprenda sobre sus funciones, seguridad y consejos para una cocina saludable y deliciosa.
	Manual de Instrucciones SOGO SS-10900 Freidora de Aire Descarga el manual de instrucciones para la Freidora de Aire SOGO SS-10900. Incluye guías de uso, seguridad, limpieza y solución de problemas.
	Manual de Instrucciones SOGO SS-10465: Freidora de Aire Multifunción Guía completa para la SOGO SS-10465 Air Fryer Oven. Aprenda a usar su freidora de aire multifunción para cocinar comidas saludables y deliciosas con facilidad. Incluye especificaciones, consejos y precauciones de seguridad.



[pdf] User Manual

SOGO SS 10495 CZ SKVýrobky jsou určeny pouze pro nekomerční použití v domácnosti Přístroj nikdy nepoužívejte pokud není bezvadné m stavu a je poškozený Přístroj SOGO SKdwn alza cz manual 142438 |||

SOGO **SS-10495** CZ, SK Nvod k použití, bezpečnostn pokyny a podmnyky použit CZ.

Dkujeme, ze jste zakoupili vrobek značky SOGO. Ped prvnm použitm si prosím pečliv pectte cel nvod k použití a pečliv jej uschovejte. SOGO ani importr nenese zdnou odpovdnost pi pouzvn vrobku v rozporu s nvodem. Bezpečnostn po...

lang:hr **score:37** filesize: 57.63 K page_count: 2 document date: 2024-12-02



[pdf] User Manual Instructions

manual de instrucciones instrucciones for use mode d emploi CÓMO UTILIZAR SU HORNO FREIDORA Enchufe el aparato en la toma corriente y pulse icono encendido para encender freidora aire del horno La SS 10495 MANUAL REVISED sogo es |||

manual de instrucciones / instructions for use mode d emploi / manual de instruoes gebrachsanweisun ... stas importantes instrucciones Caution: please read and preserve these important instructions ref. **SS-10495** 2015 / 863 / EU IMPORTANTE:

1. Lea siempre el libro de instrucciones con atencin antes d...

lang:es **score:37** filesize: 4.5 M page_count: 112 document date: 2022-12-29

[pdf]

HOR SS 10495 Descargar Área de descargas SOGO FI FRE sogo es sogodescarga 1 archivo |||

HORNO FREIDORA DE AIRE DESHIDRATADOR ASADOR 1800W MAX 30L 30230C POTENCIA CAPACIDAD CONTROL DE TEMPERATURA 18 12 h MENS TEMPORIZADOR PREESTABLECIDOS PANTALLA TCTIL RECETARIO INCLUIDO **SS-10495** www.sogo.es TECNOLOGA Tecnologa para cocina Kitchen Technology 1

Producto / Product: 4...

lang:es **score:35** filesize: 1.29 M page_count: 4 document date: 2021-10-01





[\[pdf\]](#) User Manual Instructions


Sogo FRE SS 10495 fryer user manual 2 3 MB mmo 130629261 1744300681 1916 692525 objects

icecat biz |||

manual de instrucciones / instructions for use mode d emploi / manual de instruoes
gebrauchsanweisun ... stas importantes instrucciones Caution: please read and
preserve these important instructions ref. **SS-10495** 2015 / 863 / EU IMPORTANTE:

1. Lea siempre el libro de instrucciones con atencin antes d...

lang:es score:30 filesize: 2.32 M page_count: 112 document date: 2022-12-29



[\[pdf\]](#)

Sogo FRE SS 10495 купить мультипечь цены отзывы характеристики стоимость в магазинах

Украины Киев Днепрпетровск Львов Одесса RECETARIO min sogo es |||

RECETAS RECIPES RECETTES RECEITAS REZEPTE RICETTE Delicious and healthy bites REF: **SS-10495** Horno freidora de aire multifuncin El Horno Freidora de Aire Multifuncin SOGO es uno de los aparatos elctricos innovadores que debe ser una parte esencial de su cocina. Este electrodomstico es una inno...

lang:es score:26 filesize: 2.16 M page_count: 180 document date: 2022-08-03



[\[pdf\]](#) User Manual Instructions

Instrucciones HOR SS 10495 Sogo Opinión y Análisis de sus Freidoras sin Aceite fritoysano |||

manual de instrucciones / instructions for use mode d emploi / manual de instruoes
gebrauchsanweisun ... stas importantes instrucciones Caution: please read and
preserve these important instructions ref. **SS-10495** 2015 / 863 / EU IMPORTANTE:

1. Lea siempre el libro de instrucciones con atencin antes d...

lang:es score:22 filesize: 2.24 M page_count: 112 document date: 2021-07-19



[\[pdf\]](#) Catalog

Descargar Baja Resolución Sogo SOGO CATALOGO COMPLETO LOW sogo es Catalogue 2022 ||| INNOVATING SINCE 1981 CATLOGO CATALOGUE 2022 www.sogo.es Estimados amigos y clientes, Nos enorgul ... R / MASTER BOX: 43.2 x 41.2 x 46.8 cm / 10.5 9.8 kg 12 // COCINA KITCHEN 55 // // // 105 FRE-**SS-10495** BARCODE EAN13 : 8425490137104 1 FREIDORA HORNO DESHIDRATADOR ASADOR HELATHY COOK...
lang:es **score:13** filesize: 21.42 M page_count: 220 document date: 2021-10-25



[\[pdf\]](#) Catalog

CATÁLOGO catalogue SOGO pirms 19 stundâm — pin de limpieza Color Plata negro Boquilla vapor para calentar espumear BLUETOOTH 5KG BÁSCULA DE COCINA ELECTRÓNICA BAMBOOSCALE 5000 CATALOGO 2025 sogo es ||| INNOVATING SINCE 1981 2025 CATLOGO / catalogue www.sogo.es Estimados amigos y clientes, Nos compl ... OX: 43.2 x 41.2 x 46.8 cm / 10.5 9.8 kg video 74 Cocinakitchen INNOVATING SINCE 1981 139 FRE-**SS-10495** EAN13 8425490137104 1 8 FREIDORA HORNO DESHIDRATADOR ASADOR HELATHY COOK PRO ...
lang:es **score:12** filesize: 59.74 M page_count: 256 document date: 2024-08-02



[\[pdf\]](#) Catalog

GERTU print 01 216 sogo page 1 @ HotFolder Catálogo SOGO 2023 Fabricante y Distribuidor de Electrodomésticos en España Catalogo2023 es ||| INNOVATING SINCE 1981 CATLOGO / CATALOGUE 2023 HOME KITCHEN PERSONAL CARE www.sogo.es Estimados am ... R / MASTER BOX: 43.2 x 41.2 x 46.8 cm / 10.5 9.8 kg 12 // COCINA KITCHEN 55 // // // 105 FRE-**SS-10495** BARCODE EAN13 : 8425490137104 1 FREIDORA HORNO DESHIDRATADOR ASADOR HELATHY COOK...
lang:es **score:12** filesize: 47.28 M page_count: 220 document date: 2023-01-27




[\[pdf\]](#) Catalog

CATÁLOGO catalogue SOGO Nos complace presentarle nuestro nuevo Catálogo de Electrodomésticos SOGO 2025 que muestra una amplia gama electrodomésticos innovadores alta CATALOGO low1 1CATALOGO 1sogo es CATALOGO 1 |||

INNOVATING SINCE 1981 2025 CATLOGO / catalogue www.sogo.es Estimados amigos y clientes, Nos compli ... OX: 43.2 x 41.2 x 46.8 cm / 10.5 9.8 kg video 74 Cocinakitchen INNOVATING SINCE 1981 139 FRE-**SS-10495** EAN13 8425490137104 1 8 FREIDORA HORNO DESHIDRATADOR ASADOR HELATHY COOK PRO ...

lang:es score:10 filesize: 24.02 M page_count: 252 document date: 2025-05-08



[\[pdf\]](#) Catalog

CATÁLOGO CATALOGUE 2022 Sogo jarra de leche Inox 460ml cepillo limpieza y pin Color Plata DIGITAL KITCHEN SCALE WITH BLUETOOTH USB INPUT 5V 1A OUTPUT 2 1 A UNIDAD UNIT 14 5 x 7 cm 0 215 kg CAJA INDIVIDUAL GIFT BOX 10 8 3 17 9 300 cooking recetario recipe booklet POTENCIA MÁX MAX POWER 860W arroz rice L para uso profesional en hostelería professional use in restaurants SOGO CATALOGO COMPLETO HIGH sogo es Catalogue Descargar Alta Resolución ||| INNOVATING SINCE 1981 CATLOGO CATALOGUE 2022 www.sogo.es Estimados amigos y clientes, Nos enorgul ... R / MASTER BOX: 43.2 x 41.2 x 46.8 cm / 10.5 9.8 kg 12 // COCINA KITCHEN 55 // // // 105 FRE-**SS-10495** BARCODE EAN13 : 8425490137104 1 FREIDORA HORNO DESHIDRATADOR ASADOR HELATHY COOK...

lang:es score:10 filesize: 55.94 M page_count: 220 document date: 2021-10-11