

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Oakland Living](#) /
- › [Oakland Living White Foldable Wicker Balcony Table \(Model 52-BALCONY-TABLE-WT\) User Manual](#)

Oakland Living 52-BALCONY-TABLE-WT

Oakland Living White Foldable Wicker Balcony Table User Manual

Model: 52-BALCONY-TABLE-WT

PRODUCT OVERVIEW

The Oakland Living White Foldable Wicker Balcony Table is designed for versatile use in indoor or outdoor settings. Its foldable design allows for easy storage, and the adjustable clamps ensure compatibility with various railing widths.

Key Features:

- Foldable design for convenient storage.
- Adjustable clamps fit railings from 0.1 to 5.5 inches wide.
- Constructed from weather-resistant PE rattan and a powder-coated metal frame.
- Suitable for balconies, porches, patios, and decks.



Image: The Oakland Living White Foldable Wicker Balcony Table in its open position, showcasing its semi-circular design and white wicker top.

SETUP INSTRUCTIONS

While the product is largely pre-assembled, minor adjustments are required for secure attachment to your railing. Please follow these steps carefully.

1. **Unfold the Table:** Carefully unfold the table legs and support frame until they lock into place.
2. **Identify Railing Compatibility:** Ensure your railing width is between 0.1 and 5.5 inches.
3. **Position the Table:** Place the table against your railing at the desired height.
4. **Adjust Clamps:** Loosen the adjustable knobs on the clamping mechanism. Position the clamps to securely grip both sides of your railing.



Image: A close-up view of the table's adjustable clamping mechanism, designed to secure it to a railing.

5. **Secure the Clamps:** Tighten the knobs firmly to ensure the table is stable and does not wobble. Do not overtighten to avoid damage to the railing.
6. **Verify Stability:** Gently test the table's stability before placing any items on it.



Image: The foldable balcony table securely attached to a metal railing on a patio, demonstrating its functional placement.

OPERATING INSTRUCTIONS

The Oakland Living Balcony Table is designed for simple operation and convenience.

- **Folding for Storage:** To fold the table, loosen the clamping knobs and carefully detach the table from the railing. Then, fold the support frame and legs inward until the table is compact for storage.



Image: A side view of the balcony table, illustrating its foldable design and the mechanism that allows it to collapse for storage.

- **Unfolding for Use:** Reverse the folding process. Extend the support frame and legs, then attach the table to your railing as described in the Setup Instructions.
- **Weight Capacity:** The table has a maximum weight recommendation of 50 pounds. Do not exceed this limit to prevent damage or injury.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your balcony table.

- **Cleaning:** Clean the table with hot water and a soft rag. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wicker and powder-coated finish.
- **Weather Resistance:** The table is made of weather-resistant PE rattan and a powder-coated metal frame, suitable for outdoor use. However, for prolonged durability, especially in harsh weather conditions, consider storing the table indoors when not in use for extended periods.
- **Inspection:** Periodically inspect the clamping mechanism and frame for any signs of wear or loosening. Tighten any loose components as needed.

TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Table is unstable after installation:**

Ensure the adjustable clamps are tightened securely against both sides of the railing. Verify that the railing width is within the specified range of 0.1 to 5.5 inches. Re-adjust and tighten if necessary.
- **Difficulty folding/unfolding:**

Check for any obstructions in the folding mechanism. Ensure all parts are aligned correctly before attempting to fold or unfold. Do not force the mechanism.

- **Surface appears dirty or stained:**

Refer to the "Maintenance and Care" section for proper cleaning instructions. Use only hot water and a soft rag; avoid chemicals.

SPECIFICATIONS

Feature	Detail
Brand	Oakland Living
Model Number	52-BALCONY-TABLE-WT
Product Dimensions	24"D x 24"W x 13"H
Table Top Dimensions	15.5"L x 24"W (semi-circular)
Item Weight	7 Pounds
Maximum Weight Recommendation	50 Pounds
Color	White
Material Type	PE Rattan (Wicker), Powder-Coated Metal Frame
Railing Compatibility	0.1 to 5.5 inches wide
Foldable	Yes
UPC	730050185098