

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LyxPro](#) /

› [LyxPro CS 39" Electric Guitar Kit User Manual](#)

LyxPro EGST39B

LyxPro CS 39" Electric Guitar Kit User Manual

Model: EGST39B | Brand: LyxPro

INTRODUCTION

This user manual provides comprehensive instructions for the LyxPro CS 39" Electric Guitar Kit. It covers everything from unpacking and setup to operation, maintenance, and troubleshooting. This kit is designed for beginner, intermediate, and professional players, offering a high-quality instrument and essential accessories to start your musical journey.

PACKAGE CONTENTS

Upon opening your LyxPro CS 39" Electric Guitar Kit, please verify that all the following items are included:

- LyxPro CS 39" Electric Guitar
- Amplifier Cable
- 6 Guitar Picks
- Detailed Learner's Guide
- Gig Bag (for transport and storage)
- Strap
- Clip-on Tuner
- Restrung Tools
- Extra Set of Strings
- 20-watt Amplifier (if included in your specific kit variant)

Image: The complete LyxPro CS 39" Electric Guitar Kit, showcasing the guitar, amplifier cable, six picks, and the learner's guide.

Image: A closer look at the included accessories: the guitar starter guide, a set of six guitar picks, and the guitar cable.

PRODUCT OVERVIEW

The LyxPro CS 39" Electric Guitar features a solid wood construction designed for comfort and sound performance. It includes a smooth Paulownia wood body, a durable Rosewood fingerboard, and a polished Canadian Maple neck. The

guitar is equipped with single-coil pickups and a 5-way rhythm/treble pickup switch for versatile tonal options.

Image: Front and back views of the 39-inch LyxPro electric guitar, illustrating its dimensions, rosewood fingerboard, Canadian maple neck, and tuning pegs.

Image: A detailed view of the guitar's body, showcasing the volume and tone control knobs, the 5-way pickup selector switch, and the tremolo bridge.

SETUP

1. Unpacking and Inspection

Carefully remove all components from the packaging. Inspect the guitar and accessories for any signs of damage. Retain the original packaging for future storage or transport.

2. Connecting the Amplifier (if applicable)

If your kit includes an amplifier, connect the guitar to the amplifier using the provided amplifier cable. Ensure both the guitar and amplifier are turned off before making connections. Plug one end of the cable into the guitar's output jack and the other end into the amplifier's input jack.

3. Tuning the Guitar

Use the included clip-on tuner to accurately tune your guitar. Attach the tuner to the headstock. Pluck each string individually and adjust the tuning pegs until the tuner indicates the correct pitch for each string (E, A, D, G, B, E from thickest to thinnest).

OPERATING INSTRUCTIONS

1. Using the Controls

- **Volume Knob:** Controls the overall output volume of the guitar. Turn clockwise to increase volume, counter-clockwise to decrease.
- **Tone Knobs:** Adjust the tonal characteristics, from bright to mellow.
- **5-Way Pickup Selector Switch:** Allows you to select different pickup configurations for varied sounds.
 - Position 1 (Bridge): Brightest tone, ideal for lead playing.
 - Position 2 (Bridge and Middle): Combines pickups for a slightly warmer, quacky tone.
 - Position 3 (Middle): Balanced tone.
 - Position 4 (Middle and Neck): Combines pickups for a warmer, fuller tone.
 - Position 5 (Neck): Warmest tone, suitable for rhythm and blues.
- **Tremolo Arm:** Insert into the bridge to create vibrato effects by raising or lowering the pitch of the strings.

2. Playing Techniques

The included learner's guide provides basic instructions for chords, scales, and fundamental playing techniques. Practice regularly to develop your skills. Experiment with the guitar's controls to discover different sounds and find your preferred tone.

Your browser does not support the video tag.

Video: This video demonstrates various LyxPro electric guitars and highlights their features, including different colors and styles, and shows

individuals playing the instrument. It also briefly mentions the included accessories.

MAINTENANCE

- Cleaning:** Wipe down the guitar body and neck with a soft, dry cloth after each use to remove sweat and oils. For a deeper clean, use a guitar-specific cleaning solution.
- String Changes:** Replace strings regularly, typically every 1-3 months depending on usage, to maintain optimal tone and playability. Use the provided restring tools if needed.
- Storage:** Store the guitar in its gig bag or a hard case when not in use to protect it from dust, humidity changes, and physical damage. Avoid extreme temperatures.
- Fretboard Care:** Periodically clean and condition the rosewood fretboard to prevent drying and cracking.

TROUBLESHOOTING

Issue	Possible Cause	Solution
No sound from amplifier	Cable not connected, amplifier off, volume low, faulty cable/amp.	Ensure cable is securely connected. Turn on amplifier. Increase guitar and amp volume. Test with a different cable or amp if available.
Guitar won't stay in tune	New strings stretching, improper string winding, worn tuning pegs, nut issues.	Stretch new strings thoroughly. Ensure strings are wound correctly on tuning pegs. Consider professional setup if issues persist.
Buzzing sound when playing	Low string action, uneven frets, improper playing technique.	Check string height and adjust bridge saddles if necessary. Practice proper finger placement. Consult a guitar technician for fret leveling.
Controls not working	Loose wiring, faulty potentiometer/switch.	This typically requires professional repair. Avoid attempting electrical repairs without proper knowledge.

SPECIFICATIONS

Feature	Detail
Item Weight	6.89 pounds
Product Dimensions	39 x 4.1 x 11.6 inches
Item Model Number	EGST39B
Back Material	Phoenix wood
Body Material	Wood
Color Name	Black
Fretboard Material	Maple Wood
Guitar Pickup Configuration	S (Single-coil)
Scale Length	39 Inches

Feature	Detail
String Material	Nickel Steel
Top Material	Maple Wood
Neck Material Type	Maple
Number of Strings	6
Guitar Bridge System	Tremolo
Output Wattage (Amp)	20 Watts (if included)
Size	39" Right Handed
Brand	LyxPro
Hand Orientation	Right


WARRANTY AND SUPPORT


For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official LyxPro website. Keep your proof of purchase for any warranty claims.

For additional assistance, you may contact LyxPro customer service through their official channels. Details are typically found on the product packaging or the manufacturer's website.

© 2024 LyxPro. All rights reserved.

Related Documents - EGST39B

	<p>LyxPro 60 Watt Electric Guitar Amplifier User Guide and Warranty</p> <p>Comprehensive user guide and limited warranty details for the LyxPro AGL-60 60 Watt Electric Guitar Amplifier, covering features, specifications, operation, and warranty terms from C&A Marketing.</p>
	<p>LyxPro SPA-5.5 Small PA/Speaker Monitor User Manual - Setup, Specs, and Warranty</p> <p>Comprehensive user manual for the LyxPro SPA-5.5 Small PA/Speaker Monitor. Includes setup instructions, product overview, specifications, safety precautions, and warranty information.</p>



[LyxPro Portable PA Battery-Powered Speaker User Manual](#)

User manual for the LyxPro Portable PA Battery-Powered Speaker (LYXSPA8BAT), covering features, operation, safety instructions, and warranty information.