

[manuals.plus](#) /› [Bialetti](#) /› [Bialetti New Venus Induction Stovetop Coffee Maker Instruction Manual](#)

Bialetti Venus

Bialetti New Venus Induction Stovetop Coffee Maker Instruction Manual

Brand: Bialetti | Model: Venus (0007284/CN)

1. INTRODUCTION

The Bialetti New Venus Induction Stovetop Coffee Maker combines traditional Italian coffee brewing with modern design and functionality. Crafted from high-grade 18/10 stainless steel, this moka pot is suitable for all types of hobs, including induction cooktops. It is designed to prepare an authentically aromatic Italian coffee, offering durability and style.

This manual provides essential information for the safe and effective use of your Bialetti New Venus coffee maker. Please read all instructions carefully before first use.

2. COMPONENTS

Your Bialetti New Venus coffee maker consists of three main parts:

1. **Lower Chamber (Boiler):** Holds the water. Features a patented safety valve.
2. **Filter Funnel:** Holds the ground coffee. Sits inside the lower chamber.
3. **Upper Chamber (Collector):** Collects the brewed coffee. Screws onto the lower chamber.



Figure 1: Disassembled view of the Bialetti New Venus coffee maker, illustrating its three main components: the lower water chamber, the filter funnel for coffee grounds, and the upper chamber where brewed coffee collects.

3. SETUP AND FIRST USE

Before using your Bialetti New Venus for the first time, it is recommended to wash all components with water only, without detergent. Brew coffee three times and discard the resulting coffee to season the pot and remove any manufacturing residues.

1. Unscrew the upper chamber from the lower chamber.
2. Remove the filter funnel from the lower chamber.
3. Wash all three components thoroughly with warm water. Do not use soap or abrasive materials.
4. Dry all parts completely before reassembling.

4. OPERATING INSTRUCTIONS

Follow these steps to brew authentic Italian coffee with your Bialetti New Venus:

1. **Fill the Lower Chamber:** Fill the lower chamber with cold water up to the level of the safety valve. Do not exceed this level.



Figure 2: Filling the lower chamber with water, ensuring the water level is just below the safety valve.

2. **Insert Filter Funnel:** Place the filter funnel into the lower chamber.



Figure 3: Diagram illustrating the correct placement of the filter funnel into the water-filled lower chamber.

3. **Add Ground Coffee:** Fill the filter funnel with ground coffee. Do not tamp the coffee down or press it. Level the coffee gently.




Figure 4: Adding ground coffee to the filter funnel. Ensure not to overpack or tamp the coffee.

4. **Assemble the Pot:** Tightly screw the upper chamber onto the lower chamber. Ensure a secure seal to prevent steam leakage.
5. **Place on Stovetop:** Place the coffee maker on a stovetop over medium heat. If using a gas stove, ensure the flame does not extend beyond the base of the pot. For induction, use a compatible burner.




Figure 5: The coffee maker placed on a stovetop burner, ready for brewing.

6. **Brewing:** As the water heats, it will rise through the coffee grounds and into the upper chamber. You will hear a gurgling sound as the coffee brews.
7. **Serve:** Once the upper chamber is full and you hear the gurgling sound, remove the coffee maker from the heat. Your authentic Italian coffee is ready to serve.



Figure 6: Pouring freshly brewed coffee from the Bialetti New Venus into a cup.

Your browser does not support the video tag.

Video 1: Product Demonstration Video by Amazon Product Imaging. This video illustrates the process of assembling, filling, brewing, and cleaning the Bialetti New Venus coffee maker.

5. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity of your coffee maker and the best coffee taste:

- After each use, allow the coffee maker to cool completely.
- Unscrew the upper chamber and remove the filter funnel.
- Discard used coffee grounds.
- Rinse all components thoroughly with warm water.
- **IMPORTANT: Do not use detergents, abrasive materials, or place the coffee maker in a dishwasher.** This can damage the product and affect the taste of your coffee.
- Dry all parts completely before reassembling and storing. Store disassembled to allow for air circulation.

6. TROUBLESHOOTING

- **Coffee not brewing or slow brewing:** Ensure the pot is tightly screwed together. Check that the coffee grounds are not tamped too tightly, which can restrict water flow.
- **Weak coffee:** Ensure the filter funnel is adequately filled with coffee grounds. Use a medium-fine grind suitable for moka pots.
- **Bitter coffee:** This can occur if the coffee brews for too long or at too high a temperature. Use medium heat and remove the pot from the heat source as soon as the coffee finishes brewing (when gurgling stops). Using pre-heated water in the lower chamber can also reduce brewing time and prevent bitterness.
- **Water leaking from the side:** Ensure the upper and lower chambers are screwed together tightly and the rubber gasket is properly seated and not worn.

7. SPECIFICATIONS

Brand	Bialetti
-------	----------

Model Name	Venus
Item Model Number	0007284/CN
Capacity	4 Cups (5.7 Oz / 160 Milliliters)
Material	18/10 Stainless Steel
Color	Copper Silver
Product Dimensions	4.92"D x 7"W x 7.48"H
Item Weight	1.1 pounds
Compatibility	Induction, Gas, Electric Cooktops
Dishwasher Safe	No (Hand wash recommended)

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the official Bialetti website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Visit the official [Bialetti Store](#) for more products and information.