



Manuals.plus /

› SideKing /

› SideKing 0.5 Gallon Electric Spray Bottle Plant Mister User Manual

SideKing SK-S2LR

SideKing 0.5 Gallon Electric Spray Bottle Plant Mister User Manual

Model: SK-S2LR

Brand: SideKing

INTRODUCTION

Thank you for choosing the SideKing 0.5 Gallon Electric Spray Bottle Plant Mister. This automatic, rechargeable sprayer is designed to simplify your watering, fertilizing, and cleaning tasks. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

PRODUCT FEATURES

- **One-button Operation:** The electric mister activates with a single press and stops with another, eliminating continuous manual pumping.
- **Multiple Spray Modes & Extended Nozzle:** Features an extended long nozzle that rotates 360 degrees for hard-to-reach areas. Easily adjust between an even mist and a water column spray by twisting the spout. The improved nozzle design is leak-free.
- **Versatile Use:** Suitable for plant watering, air humidification, pet cooling, and various cleaning tasks.
- **Durable Construction:** Made from premium HDPE material for the bottle body and comfortable ABS for the handle, ensuring sturdiness and ergonomic grip.
- **Large Capacity:** 2 Liters (0.5 Gallons) capacity reduces the need for frequent refills.

PACKAGE CONTENTS

The following items are included with your SideKing Electric Spray Bottle:

- Electric Spray Bottle

- Extended Nozzle
- USB Cable
- User Manual

SETUP

1. **Initial Charge:** Before first use, ensure the internal Lithium Ion battery is fully charged using the provided USB cable. The power indicator light will change to indicate a full charge.
2. **Attach Nozzle:** Screw the desired nozzle (standard or extended) onto the sprayer head until secure.
3. **Fill Reservoir:** Unscrew the sprayer head from the bottle. Fill the bottle with the desired liquid (water, fertilizer, cleaning solution). Do not overfill.
4. **Secure Head:** Screw the sprayer head back onto the bottle, ensuring it is tightly sealed to prevent leaks.



Image: The USB charging port is located on the handle of the sprayer head. Ensure the port cover is securely closed after charging.



Image: The bottle features clear markings for 2L (0.5 Gallon) capacity and includes an extended nozzle for versatile use.

OPERATING INSTRUCTIONS

- Power On/Off:** Press the power button located on the handle once to start spraying. Press it again to stop.
- Adjust Spray Mode:** To change the spray pattern, twist the nozzle at the end of the spout. Turn it clockwise for a fine mist and counter-clockwise for a direct water column spray.
- Targeting:** Utilize the 360-degree rotatable extended nozzle to direct the spray precisely, especially for hard-to-reach areas or specific plant parts.

Electric Auto Spray Bottle

One Button to Control



Image: The electric spray bottle in action, providing a continuous spray with a single button press, ideal for plant care.




Image: Adjust the spray from a fine atomized mist to a direct stream by twisting the nozzle, as illustrated by the diagram.

Multiple Spray Modes

Adjustable Nozzle




Image: The flexible extended nozzle can be rotated 360 degrees, allowing for precise spraying in various directions.

Your browser does not support the video tag.

Video: This video demonstrates the SideKing Electric Spray Bottle in use, showcasing its automatic spraying function and adjustable nozzle for various gardening tasks.

MAINTENANCE

- **Cleaning After Use:** Always empty the spray bottle and clean the nozzles completely by spraying clean water for at least 20 seconds after using solutions other than water (e.g., fertilizers, cleaning agents). This prevents clogging and extends product life.
- **Hand Wash Only:** The bottle and components should be hand washed. Do not use abrasive cleaners or put in a dishwasher.
- **Battery Care:** To maintain battery life, recharge the batteries every 2 months when storing the sprayer for extended periods.
- **Storage:** Store the sprayer in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your SideKing Electric Spray Bottle, please refer to the following common solutions:

- **Sprayer Not Activating:** Ensure the battery is fully charged. Check if the power button is pressed firmly.
- **Weak Spray or No Spray:** Verify the nozzle is not clogged. Clean the nozzle by spraying clean water for 20 seconds. Ensure the liquid level in the bottle is sufficient.
- **Leaking:** Check that the sprayer head is securely screwed onto the bottle and that the nozzle is properly attached and not damaged.
- **Inconsistent Spray Pattern:** Adjust the nozzle by twisting it to achieve the desired spray mode (mist or stream).

SPECIFICATIONS

Feature	Detail
Brand	SideKing
Model Number	SK-S2LR
Color	0.5Gal Blue
Material	Acrylonitrile Butadiene Styrene (ABS)
Capacity	0.5 Gallons (2 Liters)
Product Dimensions	5.1"W x 10.6"H
Item Weight	1.39 pounds
Special Feature	Portable, Adjustable Nozzle
Battery Type	1 Lithium Ion battery (included)
Recommended Uses	Watering, Cleansing, Indoor, Outdoor

SAFETY INFORMATION

- Do not immerse the sprayer head in water.
- Keep out of reach of children.
- Use only with liquids recommended for spraying. Avoid highly corrosive or flammable substances.
- Do not attempt to modify or repair the device yourself. Contact customer support for assistance.
- Always wear appropriate personal protective equipment (PPE) when spraying chemicals.

SUPPORT

If you have any questions or require further assistance with your SideKing Electric Spray Bottle, please do not hesitate to contact our customer support team. We are committed to providing prompt and helpful responses.

