

Nilkin Airpods 3 Case Cover

Nilkin Airpods 3 Case Cover with Secure Lock - Instruction Manual

Model: Airpods 3 Case Cover | Brand: Nilkin

INTRODUCTION

Thank you for choosing the Nilkin Airpods 3 Case Cover. This protective case is designed to safeguard your Apple AirPods (3rd generation) with military-grade armor, a secure lock mechanism, and convenient features like one-hand auto-pop opening and wireless charging compatibility. This manual provides essential information for proper installation, operation, and maintenance to ensure optimal performance and longevity of your case.

SETUP AND INSTALLATION

Follow these steps to correctly install your Nilkin Airpods 3 Case Cover:

- 1. Prepare the Case:** Take out the case components (top lid and bottom body) and identify the front side of each piece.
- 2. Attach the Lid:** Locate the 3M adhesive strip inside the lid component of the case. Remove the protective film from the adhesive. Carefully place the lid onto the top of your AirPods charging case and press firmly to secure it. Ensure it is aligned correctly.
- 3. Install the Bottom:** Slide the bottom part of your AirPods charging case into the main body of the Nilkin case. Press firmly until it fits snugly and securely.
- 4. Verify Alignment:** After installation, check that the lid aligns perfectly with the top of your AirPods. Press gently to ensure a tight fit.

For a visual guide, please refer to the installation video below:

Video: How to install the Nilkin Bounce Airpods Pro Case. This video demonstrates the installation process for the Nilkin Bounce case, which is similar in design to the Airpods 3 case cover.

Mecha Armor

Soft and hard materials combined to provide corner-to-corner protection



Image: Exploded view of the Nillkin AirPods 3 case, illustrating the separate hard PC and soft TPU components that provide corner-to-corner protection.

OPERATING INSTRUCTIONS

The Nillkin AirPods 3 Case Cover is designed for ease of use and robust protection.

Opening the Case

The case features a patented one-press, auto-pop design. Simply press the designated button on the front of the case, and the lid will automatically open, allowing quick access to your AirPods.

ONE HAND OPERATION
One Press, Auto Pop-out




Image: The Nillkin AirPods 3 case showcasing its one-hand operation and auto pop-out mechanism for easy access.



Image: The case lid opening with a distinct 'click', highlighting the innovative pop-out mechanism for quick and simple access.

Wireless Charging

The Nillkin AirPods 3 Case Cover supports both wireless and wired charging. There is no need to remove the case for charging. The LED indicator on your AirPods charging case will flash, allowing you to monitor the charging status.

Wireless Charging Friendly

Charge as normal with the case on



Image: The Nillkin AirPods 3 case placed on a wireless charging pad, demonstrating its wireless charging friendly design.

Carabiner Clip Usage

The included carabiner clip allows you to easily attach your AirPods case to bags, backpacks, belt loops, or other items for convenient portability and to prevent loss.

Wear&Slip Resistant

Slightly frosted finish repels dirt & oil,
strengthens the grip




Image: The Nillkin AirPods 3 case with its carabiner clip, shown attached to a backpack strap for secure and convenient carrying.

See the product features in action:

Video: Nillkin for AirPods Pro 1 & 2 & 3 Auto Open Protective Case. This video highlights the auto-open feature and compatibility with various AirPods generations.

MAINTENANCE

To keep your Nillkin AirPods 3 Case Cover in excellent condition:

- **Cleaning:** Wipe the case regularly with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material and finish.
- **Storage:** Store the case in a clean, dry environment when not in use.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures or direct sunlight for prolonged periods.

TROUBLESHOOTING

Lid Not Opening Properly

If the lid does not open smoothly or gets stuck:

- **Finger Placement:** Ensure your finger is not blocking the back of the lid when attempting to open it. Blocking this area can prevent the auto-pop mechanism from functioning correctly.
- **Opening Angle:** For optimal opening, it is suggested to tilt the case approximately 30 degrees outward when pressing the open button. Avoid opening vertically or tilting inward, as this may hinder the mechanism.

SPECIFICATIONS

Feature	Detail
Brand	Nillkin
Model	Airpods 3 Case Cover
Color	Yellow
Compatible Devices	Apple AirPods (3rd generation)
Form Factor	Case
Shell Type	Hard
Additional Features	Anti-Slip, Secure Lock, Auto Pop-out Design, Carabiner Clip
Pattern	Solid
Item Dimensions	6.3 x 3.15 x 0.79 inches
Item Weight	150 Grams
Enclosure Material	Silicone, Hard PC

WARRANTY INFORMATION

Nillkin products are manufactured with high-quality standards. This product is covered by the manufacturer's standard warranty against defects in materials and workmanship. Please refer to the official Nillkin website or your purchase documentation for specific warranty terms and conditions.

SUPPORT

For further assistance, product inquiries, or to explore other Nillkin products, please visit the official Nillkin store or contact customer support.

Official Nillkin Store: [Nillkin Store on Amazon](#)

