SENSEA Remix B.120 x H.70 cm

SENSEA Remix LED Bathroom Mirror User Manual

Model: B.120 x H.70 cm

Brand: SENSEA

1. Introduction

Thank you for choosing the SENSEA Remix LED Bathroom Mirror. This manual provides essential information for the safe installation, operation, and maintenance of your new mirror. Please read these instructions carefully before installation and keep them for future reference.

The SENSEA Remix LED Bathroom Mirror is designed to enhance your bathroom experience with its modern design, adjustable LED lighting, touch controls, and anti-fog function. Its IP44 rating ensures suitability for humid environments.

2. Safety Information

WARNING: Electrical installation should only be performed by a qualified electrician in accordance with local wiring regulations.

- Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- This product is rated IP44, meaning it is protected against solid objects over 1mm and splashing water from any direction. It is suitable for use in bathroom zones 2 and 3.
- Do not attempt to modify or repair the mirror. Contact qualified personnel for service.
- Ensure the mounting surface is structurally sound and can support the weight of the mirror.
- Keep packaging materials away from children.
- Avoid using abrasive cleaners or sharp objects on the mirror surface.

3. Package Contents

Carefully unpack the mirror and check for any damage. Ensure all components are present before discarding packaging materials.

- SENSEA Remix LED Bathroom Mirror
- Mounting hardware (screws, wall plugs)
- Instruction Manual



Image: Contents of the SENSEA Remix LED Bathroom Mirror package, including the mirror and mounting accessories.

4. Specifications

Brand	SENSEA
Model Number	localization_B09L4ZGYRQ
Dimensions (L x W x H)	120 cm x 70 cm x 3 cm
Material	Glass
Color	White
Special Features	Anti-fog, LED lighting, Touch control
Power (Max)	80W
Color Temperature	3000K (Warm), 4000K (Neutral), 5000K (Cool)
IP Rating	IP44
Mounting Type	Wall Mount

REMIX




Image: Detailed dimensions of the SENSEA Remix LED Bathroom Mirror (120cm width, 70cm height).



Image: Visual representation of key features: IP44 water resistance, LED illumination, and 80W maximum power.

5. Setup and Installation

Important: Installation must be carried out by a qualified electrician. Ensure the power supply is disconnected before beginning installation.

1. **Preparation:**
    - Choose a suitable location on the wall, ensuring it is structurally sound and free from hidden pipes or electrical wires.
    - Measure and mark the desired mounting points for the mirror brackets. Refer to the dimension diagram in Section 4.
2. **Mounting:**
    - Drill holes at the marked positions.
    - Insert appropriate wall plugs (provided or suitable for your wall type).
    - Secure the mounting brackets to the wall using the provided screws.
    - Carefully lift the mirror and hang it onto the secured brackets. Ensure it is stable and level.
3. **Electrical Connection:**
    - Connect the mirror's electrical wiring to your household electrical supply. This connection must be done by a qualified electrician.
    - Ensure all connections are secure and insulated according to local electrical codes.
4. **Final Check:**

- Once installation is complete, restore power at the main circuit breaker.
- Test all functions of the mirror.



Image: Example of the SENSEA Remix LED mirror installed in a bathroom setting.

6. Operating Instructions

The SENSEA Remix LED Bathroom Mirror features intuitive touch controls located on the mirror surface.



Image: Detailed view of the three touch-sensitive buttons for controlling the mirror's functions.

6.1. Power On/Off

Locate the power icon ( ) on the mirror surface. A single touch will turn the LED lighting on or off.

6.2. Adjusting Brightness

The brightness control icon (☀ or similar sun icon) allows you to adjust the light intensity. Touch and hold this icon to cycle through different brightness levels. Release when the desired brightness is achieved.

6.3. Changing Color Temperature

The color temperature icon (or similar light bulb icon with arrows) allows you to switch between different light color temperatures: 3000K (warm white), 4000K (neutral white), and 5000K (cool white). Each tap will cycle to the next color temperature.

6.4. Anti-Fog Function

The mirror is equipped with an anti-fog function. This feature is typically activated automatically when the mirror is powered on, or it may have a dedicated touch button (often indicated by a mist icon). Refer to the specific icons on your mirror for activation. The anti-fog function helps maintain a clear reflection in humid conditions.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your SENSEA Remix LED Bathroom Mirror.

7.1. Cleaning the Mirror Surface

- Always turn off the power to the mirror before cleaning.
- Use a soft, damp cloth with a mild glass cleaner or water.
- Do not spray cleaner directly onto the mirror. Apply it to the cloth first.
- Avoid abrasive cleaners, scouring pads, or solvents, as these can damage the mirror surface or electronic components.
- Wipe dry with a clean, lint-free cloth to prevent streaks.

7.2. General Care

- Regularly check the electrical connections for any signs of wear or damage. If any issues are found, disconnect power and consult a qualified electrician.
- Ensure the mirror is securely mounted to the wall.

8. Troubleshooting

If you encounter any issues with your mirror, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Mirror lights do not turn on.	No power supply; loose electrical connection; faulty touch switch.	Check circuit breaker. Ensure electrical connections are secure (consult electrician). Contact customer support if touch switch is unresponsive.
Anti-fog function not working.	Function not activated; electrical issue.	Ensure the anti-fog function is activated via its touch control. Check power supply.
Lights flicker or dim unexpectedly.	Unstable power supply; loose connection; internal component issue.	Check power supply stability. Consult a qualified electrician to inspect connections.
Touch controls are unresponsive.	Mirror surface is wet or dirty; electrical fault.	Clean and dry the mirror surface around the touch controls. If issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact SENSEA customer support or a qualified electrician.

9. Warranty and Support

SENSEA products are designed for durability and performance. For information regarding warranty coverage, product support, or spare parts, please refer to the warranty card included with your purchase or visit the official SENSEA website. Keep your proof of purchase for warranty claims.
For further assistance, you may contact ADEO, the manufacturer of SENSEA products, through their official channels.



Image: SENSEA brand logo.

© 2023 SENSEA. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question