

[manuals.plus](#) /› [iJoy](#) /› [iJoy Wireless Karaoke Microphone User Manual](#)

iJoy Open Mic

iJoy Wireless Karaoke Microphone User Manual

Model: Open Mic

INTRODUCTION

Thank you for choosing the iJoy Wireless Karaoke Microphone. This portable Bluetooth microphone and speaker combination is designed to provide an enjoyable singing experience for all ages. It features wireless connectivity, built-in controls, and multiple music playback options. Please read this manual carefully to ensure proper use and maintenance of your device.



Figure 1: iJoy Wireless Karaoke Microphone (Rose Gold) with its retail packaging.

SETUP

1. Charging the Microphone

Before first use, fully charge the microphone. Connect the provided USB charging cable to the $5V$ input port on the microphone and the other end to a standard USB power adapter (not included) or a computer USB port. The charging indicator light will show the charging status.




Figure 2: Detailed view of the microphone's input/output ports, including the USB Micro charging port, TF card slot, AUX output, and USB output.

2. Powering On/Off

Press and hold the power button (usually the Play/Pause button) for a few seconds to turn the microphone on or off.

3. Bluetooth Connection

1. Ensure the microphone is powered on and in Bluetooth pairing mode (a voice prompt or flashing indicator light may confirm this).
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "iJoy Open Mic" (or similar name) from the list.
4. Once connected, you will hear an audible confirmation from the microphone. You can now stream music wirelessly from your device to the microphone's built-in speaker.

4. Alternative Music Playback Options

- **TF Card (MicroSD) Playback:** Insert a TF card loaded with MP3 music files into the TF card slot. The microphone will automatically detect and play the music.
- **AUX Connection:** Use a 3.5mm audio cable (not included) to connect the microphone's AUX port to the audio output of another device (e.g., a non-Bluetooth music player).



Figure 3: Visual representation of the microphone's connectivity options and power source.

OPERATING INSTRUCTIONS

1. Button Controls

The iJoy Wireless Karaoke Microphone features intuitive button controls for managing your music and vocal effects. Refer to the diagram below for button functions:




Figure 4: Layout and functions of the control buttons on the microphone.

- **Play/Pause:** Press to play or pause music.
- **Prev/Next:** Press to skip to the previous or next track.
- **Vol +/-:** Adjusts the music volume.
- **Mic Vol:** Slide to adjust the microphone's vocal volume.
- **Reverb:** Slide to adjust the reverb (echo) effect on your voice.
- **Effects:** Press to cycle through different voice changer effects.

2. Voice Changer Effects

The microphone includes four preset sound effects to alter your voice. Press the "Effects" button to switch between these modes and experiment with different vocal styles.

3. Recording Function

Some models may support recording. If available, connect a recording device to the "REC" port or use the built-in

recording function with a TF card inserted. Refer to the microphone's display or indicator lights for recording status.

4. Usage Tips

- For optimal sound quality, hold the microphone approximately 2-4 inches from your mouth.
- Adjust the music volume and microphone volume independently to achieve a balanced sound.
- The wireless range is up to 32 feet (approximately 10 meters). Maintain this distance for stable connection.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the iJoy Open Mic microphone's features and usage in various settings. This video showcases the microphone's design, controls, and how it can be used for karaoke and entertainment.

MAINTENANCE

1. Cleaning

Wipe the microphone with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface or internal components. Avoid getting moisture into the ports or speaker grille.

2. Storage

Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

3. Battery Care

The microphone contains a built-in Lithium Ion battery. To maximize battery life:

- Avoid fully discharging the battery frequently.
- Do not expose the device to temperatures above 113°F (45°C) or below 32°F (0°C).
- Charge the device regularly, even if not in use, to prevent deep discharge.

TROUBLESHOOTING

If you encounter issues with your iJoy Wireless Karaoke Microphone, please refer to the following common problems and solutions:

| Problem | Possible Solution |
|--------------------------------------|--|
| Microphone does not turn on. | Ensure the battery is charged. Connect to a power source and try again. |
| Cannot connect via Bluetooth. | <ul style="list-style-type: none">• Ensure the microphone is in pairing mode.• Turn off and on Bluetooth on your device.• Forget the device from your Bluetooth list and try pairing again.• Ensure no other devices are currently connected to the microphone.• Move closer to the microphone (within 32 feet). |
| No sound from microphone or speaker. | <ul style="list-style-type: none">• Check if the microphone volume (Mic Vol) and music volume (Vol +/-) are turned up.• Ensure the music source is playing and its volume is adequate.• If using TF card, ensure files are in a compatible format (e.g., MP3) and the card is inserted correctly.• If using AUX, ensure the cable is fully inserted and functional. |

| Problem | Possible Solution |
|--|---|
| Sound is distorted or unclear. | <ul style="list-style-type: none">Reduce the microphone volume or music volume.Ensure you are not too close to the microphone or speaking too loudly.Check for interference from other electronic devices.If using Bluetooth, ensure you are within range. |
| Voice changer effects are not working. | Press the "Effects" button repeatedly to cycle through the available voice modes. Ensure the microphone is active. |

SPECIFICATIONS

| Feature | Detail |
|-----------------------------|---|
| Model Name | Open Mic |
| Brand | iJoy |
| Microphone Form Factor | Handheld |
| Connectivity Technology | Bluetooth, Auxiliary |
| Wireless Range | Up to 32 feet (approx. 10 meters) |
| Power Source | Battery Powered (1 AA Lithium Ion battery included) |
| Playtime | Up to 5 hours on a single charge |
| Item Dimensions (L x W x H) | 3 x 3 x 8 inches |
| Item Weight | 1.23 pounds |
| Compatible Devices | Smartphone, Laptop, Personal Computer, Tablet, Karaoke Machine, Speaker |
| Included Components | Built-in Speaker, 6-inch Cable |
| Color | Rose Gold |
| UPC | 842700128475 |

WARRANTY AND SUPPORT

iJoy stands by the quality of its products. This iJoy Wireless Karaoke Microphone comes with **no-questions-asked warranty**, ensuring your satisfaction and confidence in your purchase. For any product-related inquiries, technical support, or warranty claims, please contact iJoy customer service through their official website or the retailer where the product was purchased.

For more information, visit the official [iJoy Store on Amazon](#).

| | |
|--|---|
|  | <p>iJoy Open Mic Karaoke Microphone User Manual and Features</p> <p>Get detailed instructions, specifications, and safety information for the iJoy Open Mic Bluetooth karaoke microphone. Learn how to connect, record, and use its features. Includes warranty details.</p> |
|  | <p>IJOY OPEN MIC Bluetooth Karaoke Microphone User Manual</p> <p>Comprehensive user manual for the IJOY OPEN MIC Bluetooth Karaoke Microphone, detailing its functions, specifications, wireless and recording instructions, battery safety, and disposal guidelines.</p> |
|  | <p>iJoy Open Mic Speaker and Karaoke Microphone User Manual</p> <p>User manual for the iJoy Open Mic Speaker and Karaoke Microphone, detailing device functions, specifications, instructions for wireless karaoke and recording, safety information, and warranty details.</p> |
|  | <p>iJOY KARAOKE CLUB Wireless Bluetooth Speaker and Microphone User Manual</p> <p>User manual for the iJOY KARAOKE CLUB wireless Bluetooth speaker and microphone, detailing device functions, instructions for pairing, charging, safety precautions, and warranty information.</p> |
|  | <p>IJOY KARAOKE YAY Bluetooth Karaoke Machine and Speaker User Manual</p> <p>User manual for the IJOY KARAOKE YAY Bluetooth karaoke machine and speaker, covering device functions, setup, safety, and warranty information.</p> |
|  | <p>iJoy Mini+ Massage Chair: Use, Care, and Maintenance Manual</p> <p>Comprehensive user manual for the iJoy Mini+ robotic massage chair, covering setup, operation, safety guidelines, maintenance, and warranty information for optimal relaxation and well-being.</p> |