Balsam Hill 2800862

Balsam Hill BH Balsam Fir Full Artificial Christmas Tree Instruction Manual

Model: 2800862 (7.5ft Clear Incandescent)

Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and storage of your Balsam Hill BH Balsam Fir Full Artificial Christmas Tree. Please read these instructions carefully before setting up your tree to ensure proper use and longevity.



Image: The Balsam Hill BH Balsam Fir Full Artificial Christmas Tree, 7.5ft, with clear incandescent lights, fully assembled and decorated.

Product Features

- **Realistic Balsam Fir Design:** This 7.5-foot artificial Christmas tree features over 5750 realistic branch tips with semi-flat needles and upward-sloping branches, replicating the appearance of real balsam firs.
- **Clear Incandescent Lighting:** Equipped with 1050 clear incandescent lights for a traditional warm glow. These lights are designed for longevity, with an estimated lifespan of up to 3,000 hours.
- **Full Silhouette:** The tree offers a luxurious 5-foot width, creating a substantial presence suitable for showcasing ornaments.
- **Easy Assembly:** Features hinged branches and an Easy Plug system where light connections are integrated within the tree trunk, simplifying setup.
- **Complete Accessory Kit:** Includes a premium tree stand with scratch-proof rubber feet, protective gloves for branch shaping, extra bulbs and fuses, and an off-season storage bag.
- **Flame Resistant Material:** Constructed from Polyvinyl Chloride (PVC) with flame-resistant properties for enhanced safety.



Image: A close-up view of the tree's True Needle foliage, showing the realistic texture and color of the artificial branches.



Image: A detailed view of the hand-strung clear incandescent lights integrated into the tree branches.

Setup Instructions

Follow these steps for proper assembly of your artificial Christmas tree:

1. **Prepare the Stand:** Unfold the premium tree stand into an X-shape on a flat, stable surface. Ensure the scratch-proof rubber feet are positioned correctly.
2. **Insert Bottom Section:** Carefully insert the bottom section of the tree into the stand. Secure it using the provided eye bolts, tightening them until the section is stable.
3. **Initial Fluffing (Bottom Section):** Wear the included protective gloves. Begin fluffing and shaping the branches of the bottom section, working from the trunk outwards to the tips. Spread out individual branch tips to create a full appearance.
4. **Add Middle Sections:** Continue by adding the subsequent tree sections in order (typically from largest to smallest). As each section is inserted, the Easy Plug system will automatically connect the lights.

5. **Fluff Remaining Sections:** After inserting each section, immediately fluff its branches. This helps achieve a balanced and full look. For the first-time setup, thorough shaping may take over an hour to achieve desired fullness.
6. **Connect Power:** Once all sections are assembled and fluffed, connect the tree's power cord to a wall outlet. Use the included foot pedal to turn the lights on and off.



Image: A close-up demonstrating the Easy Plug system, where tree sections connect automatically for lighting.

Size Guide

Generally speaking, you want 6 inches between the ceiling and the top of your tree or tree topper, and your space should have 12 inches of clearance beyond the width of your tree.

Choosing the right height

All heights include tree stands.

UNDER 6'
For cozy rooms and secondary spaces (kitchens, dens).

6' - 6.5'
For homes with low to average ceiling height.

7' - 7.5'
For homes with 8' to 9' ceiling heights.

8' - 9'
For rooms with 10' to 11' ceiling heights.

10' - 14'
For 2-story living rooms and other rooms with very high ceiling heights, as well as commercial spaces.

15' - 30'
For churches, malls, office buildings, and other large public spaces.

Choosing the right shape and style

REGULAR (FULL)
Lush profiles and sturdy branches make these our most popular trees.

SLIM
Our most slender profile for tight spaces, corners, and foyers.

WIDE
Fill up a room and have plenty of space for ornaments and presents beneath.

SPARSE
Branches spaced so your ornaments become the star of the show.

FLATBACK
Space-savers that appear full from the front, but rest flat against a wall or corner.

7.5' BH BALSAM FIR® TREE: 90" X 60" (INCLUDES TREE STAND) | FULL

Image: Visual guide illustrating the five steps for easy assembly and shaping of the artificial Christmas tree.

What's in the Box:

- Premium Tree Stand with no-scratch rubber feet
- Durable storage bag(s) for off-season storage
- Cotton gloves for fluffing and styling
- Extra bulbs and fuses for light maintenance
- On/off foot pedal for lit trees




Image: The tree stand and a list of included components such as storage bags, gloves, and extra lights.

Operating Instructions

Your Balsam Hill BH Balsam Fir tree features pre-installed clear incandescent lights for convenience.

- **Power Connection:** Ensure the tree is fully assembled and all sections are securely connected. Plug the main power cord into a standard electrical outlet.
- **Light Control:** Use the included foot pedal switch to turn the tree lights on or off. Press the pedal once to turn the lights on, and press it again to turn them off.
- **Safety:** Always unplug the tree from the power outlet when not in use or before performing any maintenance.

Maintenance and Storage

Proper care and storage will help maintain the quality and appearance of your artificial Christmas tree for many years.

- **Cleaning:** Dust the tree branches periodically with a soft cloth or a feather duster. For deeper cleaning, use a damp cloth with mild soap and water, then allow to air dry completely. Do not use harsh chemicals or abrasive cleaners.
- **Light Maintenance:** If a light bulb burns out, replace it promptly with one of the extra bulbs provided in your kit. Ensure the tree is unplugged before replacing any bulbs. If an entire section of lights goes out, check the fuses in the plug and replace if necessary.
- **Off-Season Storage:** Before storing, remove all ornaments and decorations. Gently compress the branches to reduce their volume. Disassemble the tree sections from top to bottom. Place each section into the provided storage bag(s). Store the tree in a cool, dry place away from direct sunlight and extreme temperatures.



Image: A red storage bag designed for off-season storage of the artificial Christmas tree.

Troubleshooting

If you encounter issues with your tree, refer to the following common solutions:

Problem	Possible Cause	Solution
Lights are not turning on.	Power cord not plugged in, foot pedal off, loose section connection, burnt-out bulb, blown fuse.	Ensure power cord is securely plugged into a working outlet. Press the foot pedal to turn lights on. Check that all tree sections are properly connected. Inspect and replace any burnt-out bulbs or blown fuses using the provided spares.
Tree appears sparse after assembly.	Insufficient branch fluffing.	Dedicate more time to fluffing each branch, working from the trunk to the tips. Spread out individual branchlets to fill gaps and achieve desired fullness.
Tree is wobbly.	Stand not fully open, section not secured.	Ensure the tree stand is fully extended and stable. Tighten the eye bolts on the bottom section of the tree stand.

Specifications

- **Brand:** Balsam Hill
- **Model Number:** 2800862
- **UPC:** 196041202593
- **Tree Height:** 7.5 feet (90 inches)
- **Tree Width:** 5 feet (60 inches)
- **Tip Count:** 5768
- **Lighting Type:** Clear Incandescent
- **Number of Lights:** 1050
- **Material:** Polyvinyl Chloride (PVC)
- **Item Weight:** 43.2 pounds
- **Special Features:** Flame Resistant, Prelit, Easy Plug System
- **Included Components:** Premium tree stand, off-season storage bag(s), cotton gloves, extra bulbs and fuses, on/off foot pedal

Warranty and Support

Your Balsam Hill BH Balsam Fir Artificial Christmas Tree comes with a**3-year product warranty**. This warranty covers manufacturing defects and ensures the quality of your tree.

For warranty claims, technical assistance, or any questions regarding your product, please refer to the contact information provided on your product packaging or visit the official Balsam Hill website for customer support details.

Online Resources: For additional tips and guides, visit the Balsam Hill Store on Amazon.

© 2025 Balsam Hill. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question