ChooChoo ET2109/10

ChooChoo Farmhouse End Table (Model ET2109/10) User Manual

Brand: ChooChoo | Model: ET2109/10

Safety Information

Warning: This product requires assembly. Follow the provided instructions carefully to avoid injury. Do not overload the table. The maximum recommended weight is 17 pounds (7.7 kg). Overloading may cause the table to tip over, leading to injury or damage.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not use power tools for assembly; a Phillips head screwdriver is sufficient.
- Keep small parts away from children during assembly.
- Place the table on a flat, stable surface.

Product Overview

The ChooChoo Farmhouse End Table is a narrow side table designed for small spaces, offering a rustic farmhouse aesthetic. It features a two-tone design with a brown top and white base, and includes a decorative slatted bottom shelf for additional storage.

Key Features:

- **Farmhouse Design:** Two-tone mix of brown and white, with an A-frame structure.
- **Storage Shelf:** Decorative slatted bottom shelf for organization.
- **Compact Size:** Narrow design suitable for living rooms, bedrooms, and small spaces.
- **Sturdy Construction:** Made from strong MDF board with an A-frame for stability.



Image: The ChooChoo Farmhouse End Table, featuring a white base with an A-frame design and a contrasting brown top. A slatted shelf is visible at the bottom.

Package Contents

Before beginning assembly, ensure all components are present and undamaged. Refer to the included assembly guide for a detailed list of parts and hardware.

- Table Top (1)
- Side Frames with A-frame design (2)
- Bottom Slatted Shelf (1)
- Connecting Bars (2)
- Hardware Pack (screws, dowels, etc.)
- Assembly Guide (1)

Setup and Assembly Instructions

Assembly is required for this product. It is recommended for 1 person and typically takes a short amount of time with clear instructions provided.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Identify each part by comparing it to the parts list in the included assembly guide.
2. **Attach Side Frames:** Connect the two side frames to the connecting bars using the provided hardware. Ensure the orientation of the frames is correct as per the assembly guide to avoid visible screw holes on the exterior.
3. **Install Bottom Shelf:** Secure the slatted bottom shelf to the assembled frame using the designated hardware.
4. **Attach Table Top:** Place the table top onto the assembled base and secure it with the remaining screws.
5. **Tighten All Connections:** Once all parts are in place, gently tighten all screws to ensure stability. Do not overtighten.
6. **Final Placement:** Carefully move the assembled table to its desired location.

Tools Recommended: Phillips Head Screwdriver (included).



Image: Dimensional diagram of the end table, showing its length (23.6"), width (11.8"), and height (23.6").

Operating Instructions

This end table is designed for indoor use in living rooms, bedrooms, or home offices. It provides a stable surface for items and additional storage on its lower shelf.

- **Weight Capacity:** Do not exceed the maximum recommended weight of 17 pounds (7.7 kg) on the table top or lower shelf.
- **Placement:** Position the table on a level surface to prevent wobbling.
- **Storage:** Utilize the slatted bottom shelf for books, magazines, small baskets, or decorative items.



Image: The end table positioned beside a light-colored sofa, displaying a phone, books, and a decorative item on its top surface.

Maintenance

Proper care will ensure the longevity and appearance of your ChooChoo Farmhouse End Table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat:** Use coasters under hot items to protect the table top.
- **Tighten Hardware:** Periodically check and tighten all assembly hardware to maintain stability.

Troubleshooting

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Wobbly Table:**
  - Ensure all screws are securely tightened.
  - Verify the table is placed on a flat, even surface.
  - Check if any parts were assembled incorrectly (e.g., upside down or backward).
- **Missing Parts:**
  - Double-check all packaging materials.
  - Contact ChooChoo customer support for assistance.
- **Difficulty Assembling:**
  - Review the assembly guide carefully, paying attention to diagrams and part numbers.
  - Ensure you are using the correct hardware for each step.
  - Do not force parts together; if they don't fit, re-check the instructions.

Specifications

Feature	Detail
Brand	ChooChoo
Model Number	ET2109/10
Product Dimensions (L x W x H)	23.6" x 11.8" x 23.6" (60 cm x 30 cm x 60 cm)
Item Weight	14.6 Pounds (6.6 kg)
Maximum Weight Recommendation	17 Pounds (7.7 kg)
Frame Material	Engineered Wood
Color	White (Base) / Brown (Top)
Assembly Required	Yes
Recommended People for Assembly	1
Tools Included	Yes (Screwdriver)
Indoor/Outdoor Usage	Indoor

Warranty and Support

For any questions, missing parts, or support needs, please contact ChooChoo customer service. Refer to your purchase documentation for specific warranty details.
We are committed to ensuring your satisfaction before and after your purchase.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question