

## PUSOKEI B09L8HYR45

# PUSOKEI USB Bluetooth 5.0 Adapter Instruction Manual

Model: B09L8HYR45

[Contents](#)   [Setup](#)   [Operation](#)   [Specifications](#)   [Introduction](#)   [Package](#)   [Troubleshooting](#)   [Maintenance](#)   [Warranty & Support](#)

## 1. INTRODUCTION

---

This manual provides instructions for the installation, operation, and maintenance of your PUSOKEI USB Bluetooth 5.0 Adapter. This device enables Bluetooth connectivity for your computer, allowing wireless communication with various Bluetooth-enabled peripherals such as headphones, speakers, keyboards, mice, and more.

## Electronic Supplies

The wireless 5.0 dongle is suitable for 32/64-bit for Windows 10/8/7, etc.

It does not need to be disassembled and will not block the surrounding USB ports



Figure 1: PUSOKEI USB Bluetooth 5.0 Adapter. This image highlights the adapter's compatibility with 32/64-bit Windows 10/8/7 and its compact design that does not obstruct adjacent USB ports.

## 2. PACKAGE CONTENTS

---

Please check the package contents upon opening. If any items are missing or damaged, contact customer support.

- 1 x PUSOKEI USB Bluetooth Adapter
- 1 x CD Disc (for driver installation)
- 1 x User Manual (this document)

## 3. SETUP INSTRUCTIONS

---

### 3.1 Driver Installation

1. **Insert the CD Disc:** Place the included CD disc into your computer's CD/DVD drive.
2. **Run the Installer:** Navigate to the CD drive in "My Computer" or "This PC" and run the setup file (e.g., "setup.exe" or "install.exe").
3. **Follow On-Screen Prompts:** Follow the instructions provided by the installer to complete the driver installation. This may require administrator privileges.

4. **Restart Computer (if prompted):** If prompted, restart your computer to ensure the drivers are correctly loaded.
5. **Alternative Driver Download:** If your computer lacks a CD/DVD drive, drivers may be available for download from the official PUSOKEI support website.

### 3.2 Connecting the Adapter

1. **Locate an Available USB Port:** Identify an open USB 2.0 or 3.0 port on your computer.
2. **Insert the Adapter:** Gently insert the PUSOKEI USB Bluetooth Adapter into the USB port. Ensure it is fully seated.



Figure 2: The USB Bluetooth adapter connected to a laptop. The adapter's compact size ensures it does not interfere with other ports.



Figure 3: A close-up view of the PUSOKEI USB Bluetooth adapter securely inserted into a laptop's USB port.

Once connected, your operating system should recognize the adapter. You may see a Bluetooth icon appear in your system tray.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Pairing with Bluetooth Devices

1. **Enable Bluetooth on Your Computer:** Ensure Bluetooth is turned on in your computer's settings. This is usually found in "Settings" > "Devices" > "Bluetooth & other devices" on Windows.
2. **Put Your Device in Pairing Mode:** Refer to your Bluetooth device's manual to put it into pairing mode. This often involves holding a button until an indicator light flashes.
3. **Add a Device:** On your computer, click "Add Bluetooth or other device" and select "Bluetooth".
4. **Select Your Device:** Your computer will scan for nearby Bluetooth devices. Select your device from the list when it appears.
5. **Confirm Pairing:** Follow any on-screen prompts to confirm pairing. This might involve entering a PIN (e.g., "0000" or "1234") if required by the device.



Figure 4: A user operating a laptop with the Bluetooth adapter, demonstrating active use for wireless connectivity.

## 4.2 Data Transfer and Audio Transmission

Once paired, you can use your Bluetooth devices as intended:

- **Audio Devices:** Select your paired Bluetooth headphones or speakers as the audio output device in your sound settings.
- **Input Devices:** Paired Bluetooth keyboards and mice should function automatically.
- **File Transfer:** For file transfer between your computer and a Bluetooth-enabled phone or tablet, use the "Send or receive files via Bluetooth" option in your computer's Bluetooth settings.

## 5. SPECIFICATIONS

---

The PUSOKEI USB Bluetooth 5.0 Adapter features advanced technology for reliable wireless connectivity.

- Wireless 5.0+EDR adapter
- Interface: USB 2.0
- Small size, easy to carry
- The 24K gold plated design can effectively prevent the oxidation of the USB interface
- High data transfer rate
- Supported by Enhanced Data Rate (EDR)
- Greatly improve the data transmission rate of wireless technology to 3Mbps
- Enhanced anti interference ability, more stable signal, less frequent disconnection
- Transmission range Approx. 10-20m/32-65in
- Can cover longer distances



Figure 5: Key features and specifications of the PUSOKEI USB Bluetooth 5.0 adapter, including its gold-plated USB interface and EDR support.

Feature	Description
Model	USB Bluetooth Adapter
Material	ABS
Color	Black
Chip	For Realtek 8761
Interface	USB 2.0
Bluetooth Version	Bluetooth V5.0 + EDR
Data Transfer Rate	Up to 3Mbps (with EDR)
Frequency Band	2.400-2.480GHz
Receiving Range	Approx. 10-20m (32-65ft) in open environments
Operating System Support	Windows 7 / 8 / 10 / 2000 / 98 / Me / XP
Does Not Support	Windows Vista, Linux, OS X

## 6. TROUBLESHOOTING

---

Problem	Possible Solution
<b>Adapter not recognized</b>	<ul style="list-style-type: none"><li>• Ensure the adapter is fully inserted into the USB port.</li><li>• Try a different USB port.</li><li>• Reinstall the drivers from the included CD or manufacturer's website.</li><li>• Restart your computer.</li></ul>
<b>Cannot pair with a device</b>	<ul style="list-style-type: none"><li>• Ensure Bluetooth is enabled on your computer.</li><li>• Make sure the device you are trying to pair is in pairing mode.</li><li>• Ensure the device is within the operating range (10-20m).</li><li>• Remove previous pairings of the device from your computer and try again.</li><li>• Check if your operating system is supported (Windows Vista, Linux, OS X are NOT supported).</li></ul>
<b>Poor connection or frequent disconnections</b>	<ul style="list-style-type: none"><li>• Reduce the distance between the adapter and the Bluetooth device.</li><li>• Remove any obstacles (walls, large metal objects) between the devices.</li><li>• Avoid sources of strong interference (e.g., Wi-Fi routers, microwave ovens).</li><li>• Ensure your computer's drivers are up to date.</li></ul>

## 7. MAINTENANCE

---

The PUSOKEI USB Bluetooth Adapter requires minimal maintenance to ensure optimal performance and longevity.

- **Cleaning:** Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the adapter or subjecting it to strong impacts.
- **USB Port:** The 24K gold-plated USB interface is designed to resist oxidation. Avoid touching the gold contacts directly to prevent contamination.

## 8. WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official PUSOKEI website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, please contact PUSOKEI customer service through their official channels.

