

[Manuals.plus](#) /

› [Hotpoint](#) /

› Hotpoint 9kg Freestanding Heat Pump Tumble Dryer - User Manual

Hotpoint H8 D94WB UK

Hotpoint 9kg Freestanding Heat Pump Tumble Dryer

Model: H8 D94WB UK

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Hotpoint H8 D94WB UK 9kg Freestanding Heat Pump Tumble Dryer. Please read it thoroughly before installation and use, and keep it for future reference.

Your Hotpoint tumble dryer features a 9kg load capacity, ideal for medium to large households. It incorporates advanced heat pump technology for highly efficient drying, contributing to its A+++ energy efficiency rating. Special cycles like Anti-allergy and Pro-Iron are designed to enhance fabric care and user convenience.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Do not allow children to play on or in the appliance. Close supervision is necessary when the appliance is used near children.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not dry unwashed items in the tumble dryer.
- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.
- Remove all objects from pockets such as lighters and matches.
- The appliance must be properly earthed.
- Ensure the power cord is not trapped or damaged during installation.

SETUP

Unpacking

Carefully remove all packaging materials from the dryer. Inspect the appliance for any damage incurred during transit.

Report any damage to your retailer immediately.

Placement

Place the dryer on a firm, level floor. Ensure there is adequate ventilation around the appliance. Do not install the dryer in a room where the temperature is likely to fall below 5°C, as this may affect the performance of the heat pump.



Image: Angled view of the Hotpoint H8 D94WB UK Tumble Dryer, showing its compact design suitable for various placements.

Electrical Connection

Connect the dryer to a properly earthed electrical outlet. The voltage and frequency requirements are 220V. Do not use extension cords or multiple socket adapters.

First Use Preparation

Before the first use, wipe the drum interior with a damp cloth to remove any dust or residues from manufacturing. Ensure the lint filter and water container are correctly installed.

OPERATING INSTRUCTIONS

Control Panel Overview

The control panel features a program selector knob, various function buttons, and a digital display. Refer to the diagram below for a general layout.



Image: Front view of the Hotpoint H8 D94WB UK Tumble Dryer, highlighting the intuitive control panel and large loading door.

Loading Laundry

Open the dryer door and load laundry into the drum. Do not overload the dryer; ensure clothes can tumble freely. For optimal results, sort laundry by fabric type and desired dryness level.



Image: The Hotpoint H8 D94WB UK Tumble Dryer with its large door open, revealing the spacious 9kg capacity drum.

Selecting a Program

Turn the program selector knob to choose the desired drying program. Available programs include:

- **Eco Cotton:** Energy-efficient program for cotton items.
- **Synthetics:** For synthetic and mixed fabrics.
- **Mixed:** Suitable for a mixed load of cotton and synthetics.
- **Refresh:** A short cycle to refresh clothes without washing.
- **Rapid 30':** Quick drying for small loads.
- **Anti-allergy:** Helps remove common allergens and bacteria from fabrics.
- **Pro-Iron:** Reduces creases, making ironing easier.
- **Jeans:** Specific program for denim.
- **Wool:** Gentle drying for wool items.
- **Silk:** Delicate drying for silk garments.
- **Baby:** For baby clothes and delicate items.

Starting a Cycle

Press the Start/Pause button to begin the selected drying cycle. The display will show the remaining time.

End of Cycle

The dryer will signal when the cycle is complete. Remove laundry promptly to minimize creasing. Turn the program selector to the 'Off' position.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your tumble dryer.

Cleaning the Lint Filter

Clean the lint filter after every cycle. Pull out the filter, remove accumulated lint, and rinse under running water if necessary. Ensure it is dry before reinserting.

Emptying the Water Container

The water container collects condensation during the drying process. Empty it after each cycle to prevent the dryer from stopping prematurely. Pull out the container, empty the water, and push it back in until it clicks.

Cleaning the Condenser

For heat pump dryers, the condenser requires periodic cleaning (approximately every 3-6 months, depending on usage). Refer to the appliance's specific instructions for accessing and cleaning the condenser unit. This typically involves removing the lower cover and rinsing the condenser fins.

Cleaning the Drum

Wipe the inside of the drum with a damp cloth periodically to remove any residue or lint that may have accumulated.

External Cleaning


Clean the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not start	No power; Door not closed; Program not selected	Check power supply; Close door firmly; Select a program and press Start
Clothes not drying properly	Lint filter clogged; Water container full; Overloaded; Incorrect program	Clean lint filter; Empty water container; Reduce load size; Select appropriate program
Excessive noise	Unbalanced load; Foreign objects in drum	Redistribute laundry; Check drum for objects
Water leaking	Water container not inserted correctly	Ensure water container is fully pushed in

SPECIFICATIONS

Feature	Specification
Brand	Hotpoint
Model	H8 D94WB UK
Type	Freestanding Heat Pump Tumble Dryer
Load Capacity	9 kg
Energy Efficiency Rating	A+++
Dimensions (H x W x D)	84.9 cm x 59.7 cm x 64.9 cm
Weight	50.5 kg
Voltage	220V
Noise Level	62 dB (as per energy label)






Image: The official energy label for the Hotpoint H8 D94WB UK, indicating its A+++ energy rating, 9kg capacity, and 62 dB noise level.

WARRANTY AND SUPPORT

Your Hotpoint H8 D94WB UK Tumble Dryer comes with a **10-year parts and 1-year labour warranty**, providing peace of mind. For warranty claims or technical support, please contact Hotpoint customer service or your retailer. Keep your purchase receipt as proof of purchase for warranty purposes.

© 2024 Hotpoint. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09L8LB6G4>

More documents and user manuals: <https://manuals.plus/>