



Manuals.plus /

› **UpStart Components** /

› UpStart Components Snap-On Zig Zag Presser Foot Instruction Manual for Janome JD1804 Sewing Machine (Part #5011-4)

## UpStart Components SM-5011-4-2PK-DL280

# UpStart Components Snap-On Zig Zag Presser Foot Instruction Manual

FOR JANOME JD1804 SEWING MACHINE (PART #5011-4)

## 1. Introduction

---

Thank you for choosing the UpStart Components Snap-On Zig Zag Presser Foot. This manual provides essential information for the proper installation, operation, and maintenance of your new presser foot. Designed as a replacement part, it ensures compatibility and enhances the functionality of your Janome JD1804 sewing machine.

Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

## 2. Product Overview

---


The UpStart Components Snap-On Zig Zag Presser Foot is a durable, metal replacement accessory designed for Janome JD1804 sewing machines. It facilitates various sewing applications, improving efficiency and ensuring professional-looking results. This package includes two (2) presser feet.



**Figure 2.1:** Two UpStart Components Snap-On Zig Zag Presser Feet. These are the primary components included in the package, ready for installation on a compatible sewing machine.

## Key Features:

- **Easy Installation:** Designed for quick snap-on attachment, making replacement simple.
- **Enhanced Efficiency:** Helps your sewing machine operate smoothly, contributing to faster project completion.
- **Versatile Use:** Suitable for a wide range of sewing applications, including zig-zag stitching.
- **Professional Results:** Aids in achieving neat and consistent stitches for a polished finish.
- **Compatibility:** Specifically designed for Janome JD1804 sewing machines and compatible with Part #5011-4.




**Figure 2.2:** A single UpStart Components Snap-On Zig Zag Presser Foot, showcasing the brand's logo. This image highlights the design and branding of the individual presser foot.

## 3. Setup and Installation

Installing the Snap-On Zig Zag Presser Foot is a straightforward process. Ensure your sewing machine is turned off and unplugged before beginning installation.

## Installation Steps:

1. **Prepare the Machine:** Turn off and unplug your Janome JD1804 sewing machine for safety. Raise the presser foot lifter to its highest position.
2. **Remove Existing Foot (if applicable):** Locate the small lever or button at the back of the presser foot holder. Press it to release the current presser foot.
3. **Position the New Foot:** Place the UpStart Components Snap-On Zig Zag Presser Foot directly under the presser foot holder, aligning the crossbar of the foot with the groove on the holder.
4. **Attach the Foot:** Lower the presser foot lifter slowly until the holder snaps onto the crossbar of the new presser foot. You should hear a click, indicating it is securely attached.
5. **Verify Attachment:** Gently try to pull the presser foot off to ensure it is firmly in place. If it moves, repeat step 4.



**Figure 3.1:** Top view of the Snap-On Zig Zag Presser Foot. This perspective shows the attachment mechanism, specifically the crossbar that snaps into the sewing machine's presser foot holder.

## 4. Operating Instructions

Once installed, the Snap-On Zig Zag Presser Foot functions like your original zig-zag foot. It is designed to accommodate the needle's side-to-side movement during zig-zag stitching and other decorative stitches.

### General Usage Tips:

- **Fabric Placement:** Always place your fabric flat under the presser foot before lowering it and beginning to sew.
- **Needle Position:** Ensure the needle is correctly positioned within the foot's opening to avoid striking the foot, especially when performing zig-zag or other wide stitches.
- **Stitch Selection:** Select the appropriate stitch type (e.g., zig-zag, straight stitch, decorative stitch) on your Janome JD1804 machine. The wide opening of this foot supports various stitch patterns.
- **Test Stitching:** Before sewing on your main project, always perform a test stitch on a scrap piece of fabric to check tension and stitch quality.

## 5. Maintenance

Proper maintenance will extend the life of your presser foot and ensure consistent sewing performance.

## Cleaning and Care:

- **Regular Cleaning:** Periodically remove the presser foot from your machine and use a soft brush or cloth to remove any lint, dust, or thread buildup.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or solvents, as these can damage the metal finish. A damp cloth with mild soap is sufficient if needed.
- **Storage:** Store the presser foot in a dry, clean place when not in use, preferably in a sewing accessory box to prevent damage or loss.



**Figure 5.1:** Bottom view of the Snap-On Zig Zag Presser Foot. This view shows the smooth underside designed to glide over fabric and the wide opening for needle movement.

## 6. Troubleshooting

If you encounter issues while using your presser foot, consider the following common solutions:

Problem	Possible Cause	Solution
Foot does not snap on securely.	Incorrect alignment or debris in the holder.	Ensure the crossbar is perfectly aligned with the holder's groove. Clean the holder if necessary.
Needle strikes the presser foot.	Incorrect needle position or stitch width setting.	Verify the needle is centered for straight stitches or that the zig-zag width is appropriate for the foot's opening. Adjust stitch settings on your machine.
Fabric not feeding smoothly.	Lint buildup or incorrect presser foot pressure.	Clean the underside of the foot and the feed dogs. Check your machine's manual for adjusting presser foot pressure.

## 7. Specifications

- **Product Type:** Snap-On Zig Zag Presser Foot
- **Quantity:** 2 per pack
- **Compatibility:** Janome JD1804 Sewing Machine, Part #5011-4

- **Material:** Metal
- **Manufacturer:** UpStart Components
- **Model Number:** SM-5011-4-2PK-DL280
- **ASIN:** B09LBLL1YD

## 8. Warranty and Support

---

This product is a replacement part manufactured by UpStart Components. Any warranties for this product are offered solely by UpStart Battery, the parent company of UpStart Components.

For warranty claims, technical support, or further assistance, please contact the seller or UpStart Battery directly through their official channels. Please refer to your purchase documentation for specific contact information.

This product is not affiliated with Janome or any original equipment manufacturers (OEMs). All brand names and logos mentioned are registered trademarks of their respective owners and are used strictly to illustrate compatibility.