

CHUWI CHUWI H7 Stylus Pen

CHUWI Hipen H7 Stylus Pen User Manual

Model: CHUWI H7 Stylus Pen

PRODUCT OVERVIEW

The CHUWI Hipen H7 is an active stylus designed for precise and accurate interaction with compatible devices. It features 4096 levels of pressure sensitivity, palm rejection, and an ergonomic design for comfortable use, making it ideal for writing, drawing, and navigating.





Image: The CHUWI Hipen H7 Stylus Pen, a sleek black pen with a blue and green line drawn beneath it, illustrating its writing capability.

SETUP

Battery Installation

The Hipen H7 stylus is powered by a single AAAA battery.

1. Unscrew the top cap of the stylus.
2. Insert one AAAA battery into the battery compartment, ensuring correct polarity.
3. Screw the top cap back on securely.

The stylus is designed for long battery life, offering up to 1000 hours of use.

Compatibility

The CHUWI Hipen H7 stylus supports the MPP (Microsoft Pen Protocol) protocol. It is compatible with:

- CHUWI UBook

- CHUWI UBook XPro
- CHUWI Hi10 X
- CHUWI FreeBook
- CHUWI 10.8in MiniBook X

Note: This stylus is not compatible with: Hipad Xpro, Hipad X, Hipad max, Hipad plus, UBook X, 10.51in Minibook X.

Compatible with Microsoft Surface PC series

Not only for Surpad (Hi10 XR/Ubook X).HiPen H7 also compalible with MPP scheme Microsoft's tablets and laptops



Image: The CHUWI Hipen H7 Stylus shown alongside various compatible Microsoft Surface PC series devices, illustrating its broad compatibility with MPP scheme tablets and laptops.

OPERATING INSTRUCTIONS

Basic Usage

The Hipen H7 stylus allows for natural writing, drawing, and navigation on your compatible device. Simply touch the pen tip to the screen to begin interaction.



**Accurate writing
real time display**



Automatic sleep function

Image: A hand holding the CHUWI Hipen H7 Stylus, writing on a tablet screen, demonstrating accurate writing and real-time display.
The image also highlights the automatic sleep function.

Pressure Sensitivity

The stylus features 4096 levels of pressure sensitivity, allowing for varying line thickness and opacity based on the pressure applied. This provides a natural and responsive drawing and writing experience.




Image: A diagram of the CHUWI Hipen H7 Stylus highlighting its key features: 4096 pressure levels, ergonomic design, Wacom Chip, and 180 days of battery life.

Buttons Functionality

The Hipen H7 is equipped with two buttons on its side:

- **Right Click Button:** Press this button to activate the right-click function, similar to a mouse.
- **Eraser Button:** Press this button to activate the eraser function. *Note: The eraser function is only available for Intel devices.*

Specification



Length: 144mm

Pressure Sensitivity Level: 4096

Battery Type: AAAA Battery

Tip Size: 1.9mm

Weight: 16g

Diameter: 9.5mm

Image: A detailed specification diagram of the CHUWI Hipen H7 Stylus, labeling its components including the AAAA Battery compartment, Clip, Right Click Button, Eraser Button, and tip. It also lists key specifications like length, pressure sensitivity, battery type, tip size, weight, and diameter.

Palm Rejection

The stylus features palm rejection technology, allowing you to rest your hand naturally on the screen while writing or drawing without causing unintended marks.

Automatic Sleep Function

To conserve battery life, the Hipen H7 will automatically enter a sleep state within 60 seconds if there is no external stimulus. This eliminates the need for frequent manual switching.

MAINTENANCE

Battery Replacement

When the stylus performance degrades or it stops responding, it may be time to replace the AAAA battery. Follow the

battery installation steps in the "Setup" section.

Tip Replacement

The stylus tip is designed for durability. If the tip becomes worn or damaged, it can be replaced.

1. Gently pull the old tip straight out from the stylus.
2. Insert a new replacement tip firmly into the stylus until it clicks into place.

A fine tip for even finer ideas



Image: A close-up view of the CHUWI Hipen H7 Stylus tip, with a detached replacement tip shown next to it, emphasizing its fine tip design.

Cleaning

To clean the stylus, wipe it gently with a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse the stylus in water.

TROUBLESHOOTING

Stylus Not Responding

- Check if the AAAA battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- Ensure your device is compatible with the MPP protocol and the CHUWI Hipen H7 stylus. Refer to the compatibility list in the "Setup" section.
- Restart your device.
- If the issue persists, try resetting the stylus by removing and reinserting the battery.

Inaccurate or Lagging Input

- Ensure the stylus tip is clean and free of debris.

- Check if the stylus tip is worn and needs replacement.
- Verify that your device's display is clean.
- Close any unnecessary applications on your device that might be consuming system resources.

Eraser Function Not Working

- Confirm that your device has an Intel processor, as the eraser function is specifically designed for Intel devices.
- Ensure the application you are using supports the eraser function.

SPECIFICATIONS

Feature	Detail
Model	CHUWI H7 Stylus Pen
Pressure Sensitivity	4096 Levels
Tip Size	1.0mm (fine tip)
Battery Type	AAAA (1 included)
Battery Life	Up to 1000 hours
Material	Metal
Item Weight	1.76 ounces (approx. 50g)
Package Dimensions	6.38 x 2.09 x 0.75 inches
Protocol	MPP 2.0

WARRANTY AND SUPPORT

CHUWI provides professional support for its products to ensure customer satisfaction.

Service Period

For CHUWI tablets, laptops, and Mini PCs, the standard service period is 1 year from the date of purchase.







Customer Support

CHUWI offers lifetime factory professional support and 24 hours of online support to help resolve any issues as soon as possible.

For further assistance or inquiries, please visit the official CHUWI website or contact their customer service.

CHUWI Official Website: <https://www.chuwi.com>

Related Documents - CHUWI H7 Stylus Pen

	<p>CHUWI UBook XPro User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the CHUWI UBook XPro tablet, covering setup, instructions, and product details.</p>
	<p>CHUWI UBook XPro User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the CHUWI UBook XPro tablet, covering setup, features, and regulatory information.</p>
	<p>CHUWI HiPad XPro User Manual</p> <p>User manual for the CHUWI HiPad XPro tablet, providing instructions, technical specifications, safety information, and regulatory details.</p>
	<p>CHUWI FreeBook User Manual</p> <p>This document provides the user manual for the CHUWI FreeBook laptop, detailing its features, specifications, and usage instructions.</p>
	<p>CHUWI Hi10 XPro Tablet User Manual</p> <p>Comprehensive user manual for the CHUWI Hi10 XPro tablet, covering setup, features, and specifications. Includes multilingual support.</p>
	<p>CHUWI HeroBox Mini PC User Manual</p> <p>Official user guide for the CHUWI HeroBox Mini PC, covering specifications, setup, operation, and troubleshooting. Learn how to get the most out of your compact computing device.</p>