

[Manuals.plus](#) /

> [Goood](#) /

> Goood B09LCC11QT Dog Clippers Grooming Kit and Paw Trimmer Instruction Manual

## Goood B09LCC11QT

# Goood B09LCC11QT Dog Clippers Grooming Kit and Paw Trimmer Instruction Manual

Model: B09LCC11QT | Brand: Goood

## INTRODUCTION

---

Thank you for choosing the Goood Dog Clippers Grooming Kit. This all-in-one clipper set is designed to provide an excellent and comfortable grooming experience for your pets, whether at home or in a professional salon. Featuring a low-noise design, long-lasting battery, and sharp blades, this kit is suitable for various pet hair types, including thick coats. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

## PACKAGE CONTENTS

---

Your Goood Dog Clippers Grooming Kit includes the following items:

- 1x Pet Hair Clipper (Cordless, Rechargeable)
- 1x Type A Cutter Head (Narrow Blade for paw, face, ear, beard, mustache)
- 1x Wide Blade (for thick coats)
- 4x Limit Combs (various lengths)
- 1x Stainless Steel Pet Comb
- 1x Scissors
- 1x Pet Nail File
- 1x Pet Nail Scissors
- 1x Cleaning Brush
- 1x USB Data Cable
- 1x Toolkit/Organizer Bag
- 1x Manual



Image: All components of the Gooad Dog Clippers Grooming Kit, including the clipper, various comb attachments, scissors, nail clippers, nail file, cleaning brush, USB cable, and organizer bag.

For a visual overview of the kit contents, please watch the video below:

Video: An overview of the Gooad dog clippers and included accessories, demonstrating the contents of the grooming kit.

## SETUP

### Blade Installation and Removal

The clipper comes with detachable blades for easy cleaning and replacement. To install or remove a blade:

1. Ensure the clipper is turned off.
2. To remove: Hold the upper part of the product and push the blade upward with your thumb until it detaches.
3. To install: Fit the bottom of the desired blade into the groove correctly. Press the bottom of the blade with your left index finger and press the top half of the blade with your right thumb until it clicks into place.

# WATERPROOF DESIGN-2 WASHING METHODS



## Disassemble And Install Blade



Image: Step-by-step visual guide for disassembling and installing the clipper blades, showing how to push and click them into place.

For a detailed demonstration of blade installation, please refer to the video below:

Video: Demonstrates the installation and use of the Gooad dog clippers, including how to attach and detach blades and comb guides.

### Attaching Limit Combs

Select the appropriate limit comb for your desired hair length. Align the comb with the clipper blade and slide it on until it securely locks into place. The kit includes 4 limit combs for various cutting lengths.

## OPERATING INSTRUCTIONS

### General Grooming Tips

- Ensure your pet's coat is clean, dry, and free of tangles before grooming. Use the included stainless steel comb to detangle if necessary.
- For pets with long and thick hair, it is recommended to use scissors to cut the hair shorter initially to prevent the clippers from jamming.

- Always move the clippers in the direction of hair growth for a smooth and even cut.
- Use the narrow blade (Type A cutter head) for delicate areas such as paws, around the rump, face, ears, beard, and mustache. The wide blade is suitable for thick coats and larger body areas.



Image: A diagram illustrating different areas of a pet's body (face, ear, claw, body, rump) that can be groomed with the clippers, highlighting the powerful motor and small machine head for versatile use.

### Adjusting Blade Length

The clipper features a 5-size fine-tuning knob (0.8mm-2.0mm) allowing you to adjust the blade length for versatility. Rotate the knob to select your desired cutting length. When using the smaller blade for paw trimming, ensure the knob is turned to 0.8mm for smooth operation.

**Turn to 2.0 mm to install the blade and guard**  
**The smaller blade can groom smoothly only by turning to 0.8mm.**



Image: The clipper with its 5-size fine-tuning knob (0.8mm-2.0mm) for adjusting blade length, alongside various comb guides (3mm, 6mm, 9mm, 12mm) and illustrations of different animals that can be groomed.

### **Paw Trimming**

For precise paw trimming, use the narrow blade attachment. Gently spread your pet's paw pads to access the hair between them. The cordless design and low noise level help keep pets calm during this process.

Video: Demonstrates how to trim paw hair on a long-haired dog using the Gooad clippers, highlighting the ease and effectiveness for sensitive areas.

### **Full Body Grooming**

For full body grooming, select the wide blade and an appropriate limit comb. Start from the neck and work your way down, ensuring even strokes. The Q-SUS Low-Noise-Tech helps keep the noise below 60dB, making the experience more comfortable for your pet.

## ULTRA QUIET DESIGN



Durable and Powerful



Ergonomic Design



Low Noise and Low Vibration



40 dB

50 dB

< 60 dB

Working Sound Lower Than **60dB**



Image: The clipper with headphones, emphasizing its ultra-quiet design (below 60dB) for a comfortable grooming experience, alongside features like durability, powerful motor, and ergonomic design.

Video: Shows the Gooad clippers being used to shave a long-haired dog, demonstrating its effectiveness for full body grooming.

## CHARGING AND BATTERY

The Gooad Dog Clipper is equipped with a 2200mA high-capacity Li-ion battery, offering extended cordless operation.

- **Charging Time:** Approximately 2-3 hours for a full charge.
- **Operating Time:** A full charge can sustain use for up to 250 minutes.
- **Charging Indicator:** The clipper features an LCD display to show the remaining power and charging status.
- **USB Chargeable:** The clipper can be charged using the included USB data cable with various USB devices such as laptops, adapters, or power banks.

# SUITABLE FOR CHARGING ALL KINDS OF USB DEVICES



Image: The clipper connected via USB cable, illustrating its compatibility with various USB charging devices like laptops, adapters, and power banks.

## MAINTENANCE

### Cleaning the Blades

Regular cleaning ensures optimal performance and longevity of your clippers.

1. After each use, turn off the clipper and remove the blade.
2. Use the included cleaning brush to remove any trapped hair from the blades and the clipper head.
3. The blades are detachable and waterproof. You can rinse them under running water. Ensure they are completely dry before reattaching.
4. Apply a few drops of the provided lubricating oil to the blades regularly to keep them sharp and reduce friction.

# WATERPROOF DESIGN-2 WASHING METHODS



## Disassemble And Install Blade



Image: Demonstrates the waterproof design of the clipper and two methods for cleaning: brushing off hair and rinsing the detachable blades under water.

## TROUBLESHOOTING

### Clipper Jams or Doesn't Work Properly

- **Thick Hair:** If your pet has long and thick hair, the clippers may jam. It is essential to use scissors to cut the hair shorter at first before using the clippers.
- **Dirty Blades:** Ensure the blades are clean and free of hair buildup. Refer to the Maintenance section for cleaning instructions.
- **Lack of Lubrication:** Regularly apply lubricating oil to the blades to ensure smooth operation.
- **Low Battery:** Check the LCD display for battery level. Recharge the clipper if the battery is low.

## SAFETY INFORMATION

- Always ensure the clipper is turned off before attaching or detaching blades or comb guides.
- Keep the clipper and all accessories out of reach of children and pets when not in use.

- Do not immerse the main body of the clipper in water. Only the detachable blades are waterproof.
- Avoid using the clipper on wet hair, as this can damage the blades and motor.
- If the clipper makes unusual noises or becomes excessively hot, discontinue use immediately and contact customer support.

## SPECIFICATIONS

---

Feature	Detail
Input Power	100V-240V 50/60Hz
Working Mode	Cordless or with Charging Cable
Dimensions	17.5 x 4.5 CM (6.89 x 1.77 inches)
Net Weight	650g (1.43 lbs)
Charging Time	2-3 hours (2200MA battery)
Operating Time	Up to 250 minutes
Noise Level	Below 60dB (Q-SUS Low-Noise-Tech)
Blade Material	33-tooth Titanium and Ceramic Movable Blade
Fine Tuning Knob	0.8mm-2.0mm
Power Source	Battery Powered (1 Lithium Ion battery included)

## SUPPORT

---

For any questions, concerns, or assistance with your Goad Dog Clippers Grooming Kit, please refer to the contact information provided with your purchase or visit the official Goad website. We are committed to providing support whenever you need it.