

[Manuals.plus](#) /

> [MACTREM](#) /

> MACTREM iPhone iPad Tripod Stand User Manual

## MACTREM KT65 Tripod

# MACTREM iPhone iPad Tripod Stand User Manual

Model: KT65 Tripod | Brand: MACTREM

## PRODUCT OVERVIEW

---

The MACTREM KT65 Tripod is a versatile and portable stand designed for smartphones, tablets, and lightweight cameras. Constructed from durable aluminum alloy, it offers superior stability and adjustable height for various photography and videography needs. Key features include a 2-in-1 phone and tablet holder, a wireless Bluetooth remote shutter, and a 360° rotatable 3-way pan head.



Figure 1: Overview of the MACTREM KT65 Tripod Stand and its components.

## PACKAGE CONTENTS

---

- Tripod Stand
- Phone/iPad Holder
- Wireless Remote (CH-3) (Battery included)
- Portable Tripod Storage Bag

## SETUP INSTRUCTIONS

---

### 1. Unfolding the Tripod

1. Place the tripod on a flat, stable surface.

2. Gently spread the three legs outwards until they are fully extended and stable.
3. Adjust the leg spread for desired stability and height.

## **2. Adjusting Height and Angle**

1. To extend the tripod legs, open the quick flip locks on each section of the legs. Extend the leg sections to the desired height.
2. Close the quick flip locks securely to lock the legs in place.
3. The center column can be extended further by loosening the Center Column Lock Knob and pulling the column upwards. Tighten the knob to secure.
4. Use the 3-way pan head handle to adjust the horizontal and vertical tilt. Loosen the handle to move, then tighten to lock.
5. The tripod head can rotate 360 degrees. Loosen the 360° Rotating Lock Knob to adjust the panoramic angle, then tighten.
6. Utilize the built-in bubble view level to ensure the tripod is perfectly level for accurate shots.



## Portable Carrying Bag

Perfect for outdoor activities.

## 6-Section Highly Adjustable Tripod



NET WEIGHT

**0.7kg/1.5lbs**

170cm/67in

117cm/46in

40cm/15.7in

43cm/16.9in



Figure 2: The tripod's adjustable height and portability.



Figure 3: Key features and adjustment points of the tripod head and legs.

### 3. Attaching Phone/Tablet Holder or Camera

1. The tripod features a standard 1/4-inch universal screw for direct attachment of cameras.
2. For smartphones and tablets, attach the provided 2-in-1 holder to the tripod head using the 1/4-inch screw.
3. The holder is spring-loaded and can accommodate devices from 4 to 12.9 inches wide. Gently pull the holder to expand and insert your device. Ensure a secure grip.



**2 in 1**

**One Clamp for  
All Phones & Tablets**

Compatible with All  
**4-12.9"** Devices

**For All Phones**



**For 4-12.9" Tablet**



Figure 4: The versatile 2-in-1 holder for phones and tablets.

## OPERATING INSTRUCTIONS

### Using the Wireless Remote Shutter (CH-3)

1. Ensure the remote has a CR2032 battery installed (included).
2. Turn on the Bluetooth remote shutter.

3. On your smartphone or tablet, go to Bluetooth settings and pair with "AB Shutter3" (or similar name).
4. Once paired, you can use the remote to capture photos or start/stop video recording from up to 33 feet (10 meters) away.
5. The remote is compatible with both iOS and Android devices and does not require any app downloads.

# 33FT/ 10M HAND-FREE PHOTOGRAPHY

Shoot whenever you want, wherever you want



7:16 Bluetooth

Bluetooth

Now discoverable as "iPhone":

MY DEVICES

AB Shutter3  Connected

40:EF:4C:75:64:27 Not Connected

Blueodio Not Connected

TJS-BT Not Connected

OTHER DEVICES

To pair an Apple Watch with your iPhone, use the Watch app.

MY DEVICES

AB Shutter3

40:EF:4C:75:64:27

Blueodio

Compatible with both iOS and Android systems

ID Name: AB Shutter3

Note: Only for phone

Figure 5: The wireless Bluetooth remote shutter for convenient operation.

## Capturing Photos and Videos

- Position your device or camera on the tripod.
- Adjust the tripod height and head angle as needed using the pan head and leg locks.
- Use the remote shutter for hands-free operation, especially for group shots, selfies, or stable video recording.
- The 360° rotatable 3-way pan head allows for versatile shooting angles, including portrait, landscape, high-angle, and low-angle shots.



Record your beautiful life and wonderful moments



Figure 6: Examples of free angle adjustment for diverse photography needs.

## MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals.
- **Storage:** When not in use, fold the tripod to its minimum size (17.7 inches) and store it in the provided portable carry bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Lubrication:** Periodically check the moving parts (leg locks, pan head mechanisms) for smooth operation. If needed, apply a small amount of silicone-based lubricant.
- **Inspection:** Regularly inspect the tripod for any signs of wear or damage, especially on the leg locks, rubber feet, and device holder.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Tripod is unstable.	Leg locks are not fully secured; legs are not spread wide enough; uneven surface.	Ensure all leg locks are firmly closed. Spread legs wider for a larger footprint. Use the bubble level to find a level surface or adjust leg lengths accordingly.
Device holder does not grip securely.	Device is outside the supported width range (4-12.9 inches); worn rubber pads.	Verify your device's width is within the specified range. Ensure the device is centered and fully seated in the holder. Contact customer support if rubber pads are worn.
Bluetooth remote not connecting.	Remote is off; battery is low/dead; not in pairing mode; interference.	Turn on the remote. Replace the CR2032 battery. Ensure Bluetooth is enabled on your device and the remote is discoverable. Move closer to the remote or away from other Bluetooth devices.
Pan head movement is stiff or loose.	Locking knobs are too tight/loose; dirt/debris in mechanism.	Adjust the tension of the locking knobs. Clean the pan head area. If persistent, apply a small amount of silicone lubricant.

## SPECIFICATIONS

Feature	Detail
Model Name	MACTREM Tripod (KT65 Tripod)
Material	Aluminum Alloy
Color	Black
Product Dimensions (Folded)	3.94 x 2.76 x 15.75 inches (17.7 inches folded size)
Item Weight	2.11 pounds (approx. 1.6 lbs mentioned in feature bullet, using spec data)
Maximum Height	67 Inches
Minimum Height	15.7 Inches

Feature	Detail
Leg Diameter	0.75 inches
Compatible Devices	Smartphones (4-12.9 inches wide), Tablets (e.g., iPad Pro 9.7"/10.5"/11", iPad Mini, Samsung Galaxy series), Lightweight Cameras
Special Features	2-in-1 Universal Clamp, Foldable, Lightweight, Wireless Remote Control, Superior Stability, Built-in Bubble View Levels, 360° Rotatable 3-Way Pan Head
Remote Battery	1 CR2032 battery (included)

## WARRANTY AND SUPPORT

---

MACTREM offers a **12-month warranty** for this product. For any questions, concerns, or to utilize the free return service within 1 year for problems, please contact MACTREM customer support. We are committed to promptly delivering satisfactory solutions.

For further assistance, please visit the [MACTREM Store on Amazon](#).