

Goad B09LCKBC1V

Goad Dog Clippers Grooming Kit and Paw Trimmer (Red)

Model: B09LCKBC1V

INTRODUCTION

The Goad Dog Clippers Grooming Kit is designed to provide a safe, efficient, and comfortable grooming experience for your pets. This all-in-one clipper set is suitable for both home and professional use, featuring a low-noise design to help pets feel at ease during grooming. It includes various tools and limiting combs to ensure a safe and easy haircut.

Key features include:

- **2 Blades in 1 Set:** A wide blade for thick coats and a narrow blade for delicate areas like paws, rump, face, ears, beard, and mustache.
- **Long-Lasting Battery & LCD Display:** Equipped with a 2200mA high-capacity Li-ion battery, providing up to 250 minutes of use after a 3-hour charge. The LCD display indicates battery level.
- **Safe and Sharp Blade:** High-quality 33-tooth titanium blade and ceramic movable blade ensure excellent cutting performance and durability. Blades are detachable for easy cleaning.
- **Low Noise & Strong Power:** Q-SUS Low-Noise-Tech keeps noise below 60dB. Features a silver Pd-alloy 3-speed motor for heavy-duty use.
- **5-Size Fine Tuning Knob:** Adjust hair lengths from 0.8mm to 2.0mm for versatility.

PACKAGE CONTENTS

Your Goad Dog Clippers Grooming Kit includes the following items:

- 1x Pet Hair Clipper (Red)
- 1x Wide Cutter Head (installed)
- 1x Narrow Cutter Head (for paw/face trimming)
- 1x USB Data Cable
- 1x Cleaning Brush
- 1x Pet Steel Comb
- 1x Scissors
- 4x Limit Combs (3mm, 6mm, 9mm, 12mm)
- 1x Pet Nail File

- 1x Pet Nail Scissors
- 1x Toolkit (carrying case)
- 1x Manual



Image: Contents of the Gooad Dog Clippers Grooming Kit, showing the main clipper unit, various comb attachments, scissors, a metal comb, nail clippers, a nail file, cleaning brush, and oil, all neatly arranged in a black carrying case.

Video: A detailed review of the Gooad Dog Grooming Kit, showcasing all included accessories and the main clipper unit. The video highlights the compact carrying case and the various tools provided for comprehensive pet grooming.

PRODUCT OVERVIEW

The Gooad Dog Clipper is designed for ease of use and pet comfort. Its ergonomic design and low noise level make grooming less stressful for your animal.



Image: The main Gooad Dog Clipper unit in red, illustrating its key components such as the titanium and ceramic blades, USB charge port, power switch, remaining power LED display, 2200 mAh 18650 battery, and 5 adjustable blade distances (0.8-2.0 mm).



Image: A diagram illustrating the various body parts of a dog where the clippers can be used, including face, ear, body, rump, and claws, emphasizing the powerful 3.7V motor and the dual blade system for whole body use and small machine head for detailed areas.



Image: A graphic highlighting the ultra-quiet design of the Gooad Dog Clippers, showing a working sound level below 60dB, with a sleeping puppy and kitten, indicating its low noise and vibration for pet comfort.

SETUP

1. **Charge the Clipper:** Before first use, fully charge the clipper. Connect the USB data cable to the clipper's charge port and a compatible USB power source (e.g., laptop, adapter, power bank). Charging takes approximately 2-3 hours for a 2200mA battery, providing up to 250 minutes of use. The LCD display will show the charging progress.

SUITABLE FOR CHARGING ALL KINDS OF USB DEVICES



Image: A diagram illustrating the versatility of the USB charging feature, showing the clipper being charged via a laptop, a wall adapter, and a power bank.

2. **Select and Attach Blade:** The kit includes a wide blade (pre-installed) for general grooming and a narrow blade for detailed work. To change blades, ensure the clipper is off. Push down on the blade to detach it, then align the new blade with the head groove and press firmly until it clicks into place.
3. **Adjust Blade Distance:** Use the fine-tuning knob on the clipper to adjust the blade distance from 0.8mm to 2.0mm, allowing for precise hair length control.
4. **Attach Limit Comb (Optional):** For specific hair lengths, attach one of the four provided limit combs (3mm, 6mm, 9mm, 12mm) over the blade. Ensure it is securely fastened.

Turn to 2.0 mm to install the blade and guard
The smaller blade can groom smoothly only by turning to 0.8mm.



Image: A diagram illustrating the adjustable blade distance (0.8mm, 1.4mm, 2.0mm) and the four limit comb sizes (3mm, 6mm, 9mm, 12mm), with examples of different pets that can be groomed.

OPERATING INSTRUCTIONS

For best results and to ensure your pet's comfort, follow these guidelines:

1. **Prepare Your Pet:** Ensure your pet's coat is clean, dry, and free of tangles. If your pet has long and thick hair, it is recommended to use scissors to cut it shorter first to prevent the clippers from jamming.
2. **Acclimate Your Pet:** Turn on the clippers near your pet to let them get used to the sound and vibration before starting to groom.
3. **General Body Grooming:** Use the wide blade and appropriate limit comb for general body trimming. Move the clipper smoothly against the direction of hair growth.
4. **Detailed Grooming (Paws, Face, Ears):** Switch to the narrow blade for sensitive and hard-to-reach areas. Use caution and gentle strokes.

Video: Demonstrates how to trim paw hair on a long-haired dog using the Gooad clippers, highlighting the ease and effectiveness of the tool for detailed grooming.

Video: A user demonstrates trimming a poodle's face and feet with the Goad clippers, showcasing its quiet operation and precision for sensitive areas.

5. **Nail Trimming:** Use the included nail clippers and file for paw care. Be careful not to cut the quick of the nail.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your clippers:

1. **Cleaning the Blades:** After each use, turn off the clipper and detach the blade. Use the cleaning brush to remove any hair from the blades and the clipper head. The blades are waterproof and can be rinsed under running water.
2. **Oiling the Blades:** Apply a few drops of the provided lubricating oil to the blades after cleaning and drying. This helps maintain sharpness and smooth operation.
3. **Storage:** Store the clipper and all accessories in the provided toolkit in a dry, safe place.

WATERPROOF DESIGN-2 WASHING METHODS



Disassemble And Install Blade



Image: A step-by-step guide on disassembling, washing, and installing the clipper blade, demonstrating the waterproof design and ease of maintenance.

TROUBLESHOOTING

- **Clippers Jamming:** If the clippers jam, it is often due to long or thick hair. Ensure you pre-trim your pet's hair with scissors before using the clippers, especially for dense coats. Clean the blades thoroughly to remove any trapped hair.
- **Reduced Performance:** If the clippers are not cutting effectively, ensure the blades are clean and properly oiled. Check the battery level and recharge if necessary.
- **Battery Not Charging:** Verify that the USB cable is securely connected to both the clipper and the power source. Ensure the power source is active. If issues persist, try a different USB port or adapter.

SPECIFICATIONS

Input Power	100V-240V 50/60Hz
Working Mode	Cordless working or working with Charging
Dimension	17.5 x 4.5 CM
Charging Time	2-3 hours (2200MA battery)
Net Weight	650 Grams
Blade Material	Titanium, Ceramic
Noise Level	Below 60dB
Adjustable Blade Lengths	0.8mm - 2.0mm
Included Components	Pet Hair Clipper, USB Cable, Cleaning Brush, Pet Steel Comb, Scissors, 4 Limit Combs, Pet Nail File, Pet Nail Scissors, Toolkit

WARRANTY AND SUPPORT

Gooad is committed to providing quality products and customer satisfaction. For any questions, concerns, or support needs regarding your grooming kit, please refer to the contact information provided in your product packaging or visit the official Gooad store online. Gooad aims to assist you whenever needed.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question