

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [UrbanX](#) /
- › [UrbanX Street Buds Plus R175 True Wireless Earbuds User Manual](#)

UrbanX R175

UrbanX Street Buds Plus R175 True Wireless Earbuds User Manual

Model: R175 | Brand: UrbanX

1. INTRODUCTION

Thank you for choosing the UrbanX Street Buds Plus R175 True Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with convenient hands-free controls and a wireless charging case. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds.



Image 1.1: UrbanX Street Buds Plus R175 True Wireless Earbuds and Charging Case (Blue color variant).

2. SETUP

2.1 Unboxing and Initial Charge

Upon opening the package, ensure all components are present:

- UrbanX Street Buds Plus Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- User Manual

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB charging cable to the case and a power source, or place the case on a compatible wireless charging pad. The indicator light on the case will show charging status.



Image 2.1: The UrbanX Street Buds Plus earbuds resting inside their open charging case, ready for charging or pairing.

2.2 Pairing with a Device

The UrbanX Street Buds Plus feature one-step auto-pairing for convenience.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
4. Search for available devices and select "Buds Plus" from the list.
5. Once connected, the earbuds will automatically pair with this device when the case is opened in the future.

ONE STEP PAIRING

Auto Pairing When Open the Charging Case After First Connection.
Easy Connection with Bluetooth <Buds Plus>
Compatible with iOs/ Android/ Windows etc.




Image 2.2: Visual guide demonstrating the one-step pairing process for the earbuds with a mobile device's Bluetooth settings.

3. OPERATING THE EARBUDS

3.1 Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears. Gently insert each earbud and twist slightly until it feels secure and comfortable. A proper fit helps with sound isolation and bass response.




Image 3.1: Diagram illustrating the correct and comfortable fit of the earbuds in the ear for optimal performance.

3.2 Hands-Free Controls

The UrbanX Street Buds Plus feature intuitive touch controls for managing audio playback and phone calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

3.3 Sound Quality and Features

Experience studio-quality sound with fine-tuned 12mm speakers and enhanced bass. The earbuds are designed for clear audio reproduction across various genres.




Image 3.2: Representation of the earbuds' sound quality with abstract sound wave graphics.

3.4 Battery Life and Charging

The earbuds provide long-lasting battery life, with the charging case extending usage significantly. The case supports both wired (USB) and wireless charging.

- Up to 22 hours of total music playback with the charging case.
- Approximately 15 hours of talk time.
- Quick charging feature provides hours of playback with a short charge.

22 HOURS OF SERIOUS SOUND

Breakthrough battery technology
changes everything

22 hours
Music play back

15 hours
Talk time

1 hours
Quick charging


Wireless charging



Image 3.3: Infographic detailing the battery performance, including music playback, talk time, quick charging, and wireless charging capabilities.

3.5 Device Compatibility

The UrbanX Street Buds Plus are compatible with a wide range of Bluetooth-enabled devices, including smartphones, tablets, and laptops running iOS, Android, and Windows operating systems.

ANDROID & IOS COMPATIBLE

Compatible with all phone models and all operating systems.
iOS, android, windows pc, tablets and more.



Image 3.4: Visual confirmation of compatibility with both Android and iOS devices.

4. MAINTENANCE

4.1 Cleaning Your Earbuds

To maintain optimal performance and hygiene, regularly clean your earbuds:

- Use a soft, dry, lint-free cloth to wipe the exterior of the earbuds and charging case.
- For earwax or debris in the ear tips, use a small, soft brush or cotton swab. Avoid using sharp objects.
- Do not use abrasive materials, alcohol, or chemical cleaners.

4.2 Water Resistance

The UrbanX Street Buds Plus are rated IP7 water resistant, making them suitable for sports and exercise. This means they can withstand sweat and light splashes. However, they are not designed for swimming or submersion in water. Ensure earbuds are dry before placing them back in the charging case.

BUILT FOR SPORTS

IP7 waterproof and sweat resistant



IP7 waterproof




Image 4.1: An active individual wearing the earbuds, highlighting their IP7 waterproof and sweat-resistant design for sports use.

4.3 Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.

5. TROUBLESHOOTING

If you encounter issues with your UrbanX Street Buds Plus, refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing	Low battery, Bluetooth off, out of range, previously paired to another device.	Ensure earbuds are charged. Turn Bluetooth on/off on your device. Move closer to your device. Forget "Buds Plus" from your device's Bluetooth list and re-pair.

Problem	Possible Cause	Solution
No sound or low volume	Volume too low on device, earbuds not properly seated, connection issue.	Increase volume on your device. Adjust earbuds for a secure fit. Disconnect and reconnect Bluetooth.
Earbuds not charging	Charging cable/pad issue, dirty charging contacts, earbuds not seated correctly.	Check charging cable/pad. Clean charging contacts on earbuds and case with a dry cotton swab. Ensure earbuds are correctly placed in the case.
One earbud not working	Individual earbud connection issue, low battery.	Place both earbuds back in the case, close, then reopen. Ensure both are charged. Re-pair if necessary.

5.1 Resetting the Earbuds

If troubleshooting steps do not resolve the issue, you may need to reset your earbuds. Refer to the specific reset procedure in the full product manual or contact customer support.

6. SPECIFICATIONS

Feature	Detail
Model Name	R175
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Compatible Devices	Lenovo Tab M8 (3rd Gen), Mobile Phone, Tablet, Laptop, Smartphone
Control Type	Call Control (Hands-Free)
Water Resistance Level	Water Resistant (IP7)
Special Features	Carrying case included, Enhanced bass, Microphone Included, Sports-and-exercise, Wireless
Item Weight	2 ounces
Product Dimensions	2.75 x 1.04 x 1.52 inches
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Sound Isolation
UPC	734046162926

7. WARRANTY AND SUPPORT

7.1 Warranty Information

UrbanX provides a **90-day money-back guarantee** for your satisfaction. Additionally, a **12-month replacement** policy is offered for defective earbuds from the date of purchase.

7.2 Customer Support

For further assistance, technical support, or warranty claims, please visit the official UrbanX store or contact their customer service department. You can find more information and contact details on the [UrbanX Store Page](#).