

VEIKK VK1560 Pro

VEIKK VK1560 Pro Drawing Monitor User Manual

Comprehensive instructions for setup, operation, and maintenance of your VEIKK VK1560 Pro Pen Display.

[Introduction](#)

[Package
Contents](#)

[Setup](#)

[Operation
Warranty &
Support](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your VEIKK VK1560 Pro Drawing Monitor. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your creative experience. The VK1560 Pro is a 15.6-inch full-laminated pen display designed for digital artists, designers, and educators, offering a high-definition display and precise pen input.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- VEIKK VK1560 Pro Drawing Monitor
- Battery-Free Stylus (Digital Pen)
- Adjustable Stand
- Detachable Pen Holder
- USB-C to USB-C Cable (for Android device connection)
- Power Adapter
- HDMI Cable
- USB Cable
- Pen Nibs and Nib Remover
- Cleaning Cloth
- Quick Start Guide

VEIKK

Windows | Mac



Image: Contents of the VEIKK VK1560 Pro package, including the monitor, stylus, stand, and various cables.

3. SETUP GUIDE

3.1 Connecting the Monitor to Your Computer

Follow these steps to connect your VK1560 Pro to your computer:

1. **Connect Power:** Plug the power adapter into the monitor's power port and then into a wall outlet.
2. **Connect Video:** Connect one end of the HDMI cable to the monitor's HDMI port and the other end to your computer's HDMI port. If your computer does not have an HDMI port, you may need an adapter (not included).
3. **Connect USB:** Connect one end of the USB cable to the monitor's USB port and the other end to an available USB port on your computer. This connection enables pen input and data transfer.
4. **Power On:** Press the power button on the side of the monitor to turn it on.
5. **Install Driver:** Visit the official VEIKK website to download and install the latest driver for your operating system (Windows or macOS). Ensure any previous tablet drivers are uninstalled before installing the VEIKK driver.
6. **Configure Display Settings:** After driver installation, configure your display settings (e.g., extend or duplicate display) and pen calibration through your operating system's display settings and the VEIKK driver software.

How to connect




Image: Diagram illustrating how to connect the VEIKK VK1560 Pro to a computer using HDMI, USB, and power cables.

3.2 Connecting to Android Devices

The VK1560 Pro can be connected to compatible Android devices using the included full-featured USB-C to USB-C cable. Ensure your Android device supports display output via USB-C.

1. Connect one end of the USB-C to USB-C cable to the monitor's USB-C port.
2. Connect the other end of the USB-C to USB-C cable to your Android device's USB-C port.
3. The monitor should automatically detect and display content from your Android device.

3.3 Adjustable Stand Installation

Attach the adjustable stand to the back of the VK1560 Pro for comfortable viewing and drawing angles. The stand allows for various tilt adjustments.



Image: The VEIKK VK1560 Pro drawing monitor shown with its adjustable stand, demonstrating various viewing angles.

4. OPERATION

4.1 Using the Battery-Free Stylus

The VK1560 Pro comes with a battery-free stylus that offers 8192 levels of pressure sensitivity and tilt support for a natural drawing experience.

- **Drawing:** Use the stylus directly on the monitor's screen to draw, paint, and edit.
- **Buttons:** The stylus features programmable buttons. Customize their functions (e.g., right-click, eraser) through the VEIKK driver software.
- **Pen Holder:** Store the stylus in the detachable pen holder when not in use to prevent loss or damage.



Image: A user actively drawing on the VEIKK VK1560 Pro screen using the battery-free stylus, demonstrating its use in creative applications.

4.2 Using the Quick Dial and Shortcut Keys

The VK1560 Pro features an upgraded Quick Dial and customizable shortcut keys for efficient workflow.

- **Customization:** Access the VEIKK driver software to assign specific functions (e.g., zoom, brush size, undo) to the Quick Dial and shortcut keys.
- **Efficiency:** Utilize these features to quickly access frequently used tools and commands, reducing reliance on keyboard shortcuts.

Industry-leading Color Displays



Customize Your Workflow

Image: A close-up view of the VEIKK VK1560 Pro's Quick Dial and programmable shortcut keys, highlighting their ergonomic placement for workflow customization.

4.3 Display Features

The 15.6-inch Full HD IPS display offers a vibrant visual experience:

- **Resolution:** 1920x1080 Full HD for clear and detailed visuals.
- **Color Accuracy:** Supports 16.7 million display colors and 92% NTSC color gamut for accurate color reproduction.
- **Anti-Glare:** The anti-glare film reduces reflections and provides a paper-like drawing surface.
- **Viewing Angle:** Wide 178° viewing angles ensure consistent image quality from various perspectives.



Image: The VEIkk VK1560 Pro screen showcasing its 1920x1080 FHD IPS display, 92% NTSC color gamut, and 16.7 million colors.

5. MAINTENANCE

5.1 Cleaning the Monitor

- Always power off and unplug the monitor before cleaning.
- Use a soft, lint-free cloth (preferably the included cleaning cloth) to gently wipe the screen and body.
- For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaning solution. Do not spray liquid directly onto the screen.
- Avoid using harsh chemicals, abrasive cleaners, or alcohol-based solutions, as these can damage the screen surface.

5.2 Stylus Nib Replacement

Over time, the stylus nib may wear down. Replace it when it becomes too short or feels rough.

1. Use the nib remover tool to gently pull out the old nib from the stylus.
2. Insert a new nib firmly into the stylus until it clicks into place.

5.3 Storage

- Store the monitor in a cool, dry place away from direct sunlight and extreme temperatures.
- Protect the screen from scratches by using a soft cover or returning it to its original packaging when transporting.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No display on monitor	Power cable not connected HDMI cable not connected or loose Incorrect display settings on computer	Ensure power cable is securely connected and power outlet is active. Check HDMI cable connection on both monitor and computer. Try a different HDMI port or cable if available. Adjust computer's display settings to extend or duplicate the display to the VK1560 Pro.
Pen not working or no pressure sensitivity	USB cable not connected or loose Driver not installed or corrupted Conflicting tablet drivers Worn out pen nib	Ensure USB cable is securely connected to both monitor and computer. Reinstall the latest VEIKK driver from the official website. Uninstall all other tablet drivers before installing the VEIKK driver. Replace the pen nib.
Cursor offset or inaccurate	Screen calibration required Incorrect display mapping	Perform screen calibration through the VEIKK driver software. Ensure the pen is mapped to the correct display in the driver settings.
Quick Dial or shortcut keys not responding	Driver not installed or running Incorrect key assignments	Verify the VEIKK driver is installed and running in the background. Check and reconfigure key assignments in the VEIKK driver software.

7. SPECIFICATIONS

Feature	Detail
Brand	VEIKK
Model Number	VK1560 Pro
Screen Size	15.6 Inches
Native Resolution	1920x1080 (Full HD)
Display Type	IPS LCD with Anti-Glare Film
Color Support	16.7 Million Colors, 92% NTSC Color Gamut

Feature	Detail
Pen Technology	Battery-Free Stylus
Pen Pressure Levels	8192
Tilt Support	Yes
Connectivity	USB, HDMI, USB-C
Operating System Compatibility	Windows 7 or later, MacOS 10.12 or later, Android (via USB-C)
Built-In Media	Digital Pen, Stand, Stylus
Color	Black
Specific Uses	Designing, Drawing, Online Education

8. PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: An official overview of the VEIKK VK1560 Pro drawing tablet, showcasing its features, design, and functionality. This video demonstrates the product's components, setup, and usage in various creative tasks.

9. WARRANTY AND SUPPORT

The VEIKK VK1560 Pro Drawing Monitor comes with a **1-year warranty** from the date of purchase. VEIKK also provides **lifetime technical support** for this product.

For technical assistance, driver downloads, or warranty claims, please visit the official VEIKK website or contact their customer support directly. Keep your purchase receipt as proof of purchase for warranty services.

Official VEIKK Website: www.veikk.com