

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [neabot](#) /

> [neabot P1 Pro Pet Grooming Kit & Vacuum Replacement Parts User Manual](#)

neabot P1B

neabot P1 Pro Pet Grooming Kit & Vacuum Replacement Parts User Manual

Model: P1B

[Introduction](#)

[Components](#)

[Installation](#)

[Maintenance](#)

[Specifications](#)

[Troubleshooting](#)

[Warranty & Support](#)

1. INTRODUCTION

This user manual provides essential information for the proper installation, use, and maintenance of the neabot P1 Pro Pet Grooming Kit & Vacuum replacement parts. These parts are designed to ensure the continued optimal performance of your neabot P1 Pro grooming system. Please read this manual thoroughly before replacing any components.

2. PRODUCT COMPONENTS

The neabot P1 Pro replacement parts package includes the following items:

- **Clipper Blades:** Two (2) replacement clipper blades for the grooming tool.
- **HEPA Filter:** One (1) High-Efficiency Particulate Air filter for the vacuum unit.
- **Sponge Filter:** One (1) sponge filter, which works in conjunction with the HEPA filter.



Figure 2.1: Contents of the neabot P1 Pro Replacement Parts package.

3. INSTALLATION INSTRUCTIONS

Before beginning any installation, ensure the neabot P1 Pro Pet Grooming Kit & Vacuum is turned off and unplugged from the power source to prevent accidental operation.

3.1. Replacing the Clipper Blade

1. Locate the clipper head on your neabot P1 Pro grooming tool.

2. Gently press the release button or slide the locking mechanism to detach the old clipper blade. Refer to your main P1 Pro manual for specific instructions if needed.
3. Carefully remove the old blade.
4. Align the new clipper blade with the attachment points on the grooming tool.
5. Press firmly until the new blade clicks securely into place.




Figure 3.1: A single neobot P1 Pro replacement clipper blade.

3.2. Replacing the HEPA Filter

1. Locate the filter compartment on the main vacuum unit of your P1 Pro. This is typically found by opening a cover or panel.
2. Remove the existing HEPA filter. Note its orientation for correct installation of the new filter.
3. Insert the new HEPA filter into the compartment, ensuring it sits flush and securely.
4. Close the filter compartment cover until it locks.




Figure 3.2: A neobot P1 Pro replacement HEPA filter.

3.3. Replacing the Sponge Filter

1. The sponge filter is usually located directly beneath or adjacent to the HEPA filter.
2. Remove the old sponge filter.
3. Place the new sponge filter into its designated slot, ensuring it is properly seated.
4. Reassemble the filter compartment.



Figure 3.3: A neabot P1 Pro replacement sponge filter.

4. MAINTENANCE

Regular maintenance of these replacement parts is crucial for the longevity and efficiency of your neabot P1 Pro Pet Grooming Kit & Vacuum.

4.1. Clipper Blade Care

- **Cleaning:** After each use, remove hair from the clipper blade using the cleaning brush provided with your grooming kit. You may also wipe the blades with a damp cloth. Ensure blades are dry before storage.
- **Lubrication:** Apply a small amount of clipper oil to the blades regularly to maintain sharpness and smooth operation.
- **Replacement:** Replace clipper blades when they become dull or show signs of wear, typically every few months depending on usage.

4.2. Filter Care (HEPA and Sponge)

- **Sponge Filter:** The sponge filter can be gently rinsed with water to remove accumulated debris. Ensure it is completely dry before reinserting it into the vacuum unit.
- **HEPA Filter:** The HEPA filter is generally not washable. Tap it gently to dislodge dust and debris. Avoid washing the HEPA filter as this can damage its filtration capabilities.
- **Replacement:** Replace the HEPA filter and sponge filter every 3-6 months, or more frequently if you notice a decrease in vacuum suction or increased dust emission.

5. SPECIFICATIONS

Key specifications for the neabot P1 Pro replacement parts:

Feature	Detail
Brand:	neabot
Model Number:	P1B
Item Weight:	7.4 ounces
Package Dimensions:	4.76 x 4.76 x 2.24 inches
Material Type:	HEPA (for filter)
Compatible Device:	neabot P1 Pro Pet Grooming Kit & Vacuum

Feature	Detail
Number of Pieces:	4 (2 Clipper Blades, 1 HEPA, 1 Sponge Filter)
Reusability:	Partially Reusable (Sponge filter washable, HEPA filter not washable)

6. TROUBLESHOOTING

If you encounter issues after replacing parts, consider the following:

- **Clipper not cutting effectively:**
 - Ensure the blade is securely attached.
 - Check if the blade is clean and free of hair buildup.
 - Apply clipper oil to the blades.
 - If the issue persists, the blade may be dull and require replacement.
- **Reduced vacuum suction:**
 - Verify that both the HEPA and sponge filters are correctly installed and seated.
 - Clean the sponge filter and gently tap the HEPA filter to remove debris.
 - Check if the filters are clogged and require replacement.
- **Unusual noise from vacuum:**
 - Ensure all filter compartments are securely closed.
 - Check for any foreign objects lodged near the filters or in the vacuum hose (refer to main P1 Pro manual).

7. WARRANTY & SUPPORT

neabot provides a **12-month warranty** for its products. For any questions, technical assistance, or warranty claims, please contact neabot customer support. Our support team is available online for assistance.

You can find more information and contact details on the official neabot website or through your purchase platform.

- **Return Policy:** Products are eligible for refund/replacement within 2026 days from purchase, subject to terms and conditions.
- **Online Support:** [Visit the Neakasa official store on Amazon](#) for support resources.

