

Manuals.plus /

- › Bosch /
- › Bosch AdvancedHedgeCut 65 Hedge Trimmer User Manual

Bosch 06008C0801

Bosch AdvancedHedgeCut 65 Hedge Trimmer User Manual

Model: 06008C0801

Brand: Bosch

1. INTRODUCTION

Thank you for choosing the Bosch AdvancedHedgeCut 65 Hedge Trimmer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new tool. Please read all instructions carefully before use and keep this manual for future reference.



Figure 1: The Bosch AdvancedHedgeCut 65 Hedge Trimmer, showcasing its ergonomic design and long blade.

2. IMPORTANT SAFETY INSTRUCTIONS

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these instructions may result in serious injury.

- **Read the entire manual:** Understand all operating instructions and safety warnings before using the hedge trimmer.
- **Wear appropriate personal protective equipment (PPE):** Always wear safety glasses, hearing protection, sturdy footwear, and gloves.
- **Inspect the area:** Before starting, check the work area for hidden wires, cables, or other objects that could be struck by the blades.
- **Maintain a firm grip:** Always hold the hedge trimmer with both hands during operation.
- **Keep bystanders away:** Ensure children and other people are at a safe distance from the work area.
- **Disconnect power:** Always unplug the hedge trimmer from the power supply before cleaning, maintenance, or when not in use.
- **Avoid wet conditions:** Do not operate the hedge trimmer in rain or damp conditions.
- **Check for damage:** Before each use, inspect the hedge trimmer for any damage to the blades, housing, or power cord. Do not use if damaged.

3. PRODUCT OVERVIEW

The Bosch AdvancedHedgeCut 65 is designed for efficient and comfortable hedge trimming, featuring Pro-Silence technology for reduced noise and an ergonomic design.

Key Features:

- **Pro-Silence Technology:** Significantly reduces noise levels (93dB), making operation quieter than older models.
- **Powerful 500 W Motor:** Ensures excellent cutting performance for large hedges.
- **65 cm Blade Length:** Ideal for covering large areas quickly.
- **34 mm Cutting Capacity:** Capable of cutting through thicker branches.
- **Perforated Hand Guard:** Provides a clear view of the cutting blades and the work area for precise trimming.
- **Multi-Position Handle:** Allows for comfortable and effortless work from various angles, reducing user fatigue.



Figure 2: Close-up view of the perforated hand guard, offering improved visibility during operation.



Figure 3: The multi-position handle, designed for ergonomic comfort and versatility in various cutting positions.

4. SETUP

Unboxing and Initial Inspection:

1. Carefully remove the hedge trimmer and all accessories from the packaging.
2. Check for any signs of damage during transit. If any damage is found, do not use the tool and contact customer support.
3. Ensure all components listed in the packaging are present: AdvancedHedgeCut 65 unit, blade cover, and cardboard packaging.

Preparing for Use:

1. Remove the blade cover before connecting to power.
2. Ensure the power cord is free from kinks or damage.
3. Connect the hedge trimmer to a suitable power outlet (500 W, 230V AC). Ensure the power supply matches the specifications on the tool's rating plate.

5. OPERATING INSTRUCTIONS

Starting and Stopping:

- To start the hedge trimmer, press and hold the safety switch, then squeeze the trigger switch.
- To stop the hedge trimmer, release the trigger switch.

Cutting Techniques:

For best results and safety, follow these cutting guidelines:

- **Horizontal Cutting:** Hold the hedge trimmer with the blade slightly angled upwards (5-10 degrees) and sweep along the top of the hedge.
- **Vertical Cutting:** Hold the hedge trimmer vertically and sweep upwards or downwards along the sides of the hedge.
- **Cutting Thicker Branches:** The 34 mm cutting capacity allows for thicker branches. Position the branch deep into the blade teeth for a clean cut.



Figure 4: The hedge trimmer blade effectively cutting through a branch, demonstrating its cutting capacity.



Figure 5: The hedge trimmer blade positioned against a wall, illustrating its ability to trim close to surfaces.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Bosch AdvancedHedgeCut 65.

Blade Care:

- **Cleaning:** After each use, disconnect the power and clean the blades with a stiff brush to remove sap and debris.
- **Lubrication:** Apply a light machine oil or blade lubricant to the blades after cleaning to prevent rust and ensure smooth operation.
- **Sharpening:** The blades are made of high-quality steel (Edelstahl) and are ground for precision. If the cutting performance decreases, the blades may need professional sharpening.



Figure 6: A close-up view of the precision-ground blades, highlighting their sharp cutting edges.

General Cleaning:

- Wipe down the exterior of the hedge trimmer with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure ventilation openings are clear of debris to prevent overheating.

Storage:

- Always attach the blade cover before storing.
- Store the hedge trimmer in a dry, secure place, out of reach of children.
- Avoid storing in direct sunlight or extreme temperatures.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your hedge trimmer.

Problem	Possible Cause	Solution
Hedge trimmer does not start.	No power supply; safety switch not engaged; damaged cord.	Check power outlet; ensure safety switch is pressed before trigger; inspect cord for damage and replace if necessary.
Blades are not cutting effectively.	Blades are dull or dirty; excessive debris caught in blades.	Clean and lubricate blades; have blades professionally sharpened if dull; remove debris (ensure power is disconnected).
Excessive vibration or noise.	Loose components; damaged blades; motor issue.	Check for loose screws and tighten; inspect blades for damage and replace if necessary; if problem persists, contact service center.
Tool overheats.	Blocked ventilation slots; continuous heavy use.	Clean ventilation slots; allow tool to cool down during prolonged use.

8. SPECIFICATIONS

Detailed technical specifications for the Bosch AdvancedHedgeCut 65.

Specification	Value
Brand	Bosch
Model Number	06008C0801
Power Source	Corded Electric
Motor Power	500 W
Blade Length	65 cm (25.6 inches)
Cutting Capacity (Max. Branch Diameter)	34 mm (1.33 inches)
No-load Cutting Rate	3400 strokes/min
Sound Power Level	93 dB
Item Weight	4 kg (8.8 pounds)
Product Dimensions (L x W x H)	9.45"L x 27.17"W x 0.98"H
Blade Material	Edelstahl (Stainless Steel)

9. WARRANTY AND SUPPORT

Warranty Information:

Bosch products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, or visit the official Bosch website for detailed warranty information.

The EU Spare Part Availability Duration for this product is 5 Years.

Customer Support:

For technical assistance, spare parts, or service, please contact Bosch customer support. You can find contact details on the official Bosch website or through your local retailer.

Visit the official Bosch Store on Amazon for more products and information.