Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bush Furniture ECH026MG

Bush Business Furniture Echo L Shaped Desk User Manual

Model: ECH026MG

1. Introduction

This manual provides instructions for the assembly, operation, and maintenance of your Bush Business Furniture Echo L Shaped Desk. Designed for professional use, this desk offers an elegant and functional workspace. Please read these instructions carefully before beginning assembly and retain them for future reference.

The Echo L Shaped Desk features a 60W Credenza Desk and a 36W Return, allowing for flexible left or right-handed configurations. Its durable thermally fused laminate finish protects against scratches and stains, ensuring longevity.



Image 1.1: The Bush Business Furniture Echo L Shaped Desk in a typical office environment, showcasing its modern gray finish and L-shaped configuration.

2. Safety Information

Please observe the following safety guidelines during assembly and use:

- Keep all small parts and packaging materials away from children.
- Ensure all fasteners are securely tightened before using the desk. Periodically check and re-tighten as necessary.
- Do not stand or sit on the desk.
- Distribute weight evenly across the desktop. The desktop supports up to 200 pounds (90.72 kg).
- Use caution when moving the assembled desk to prevent injury or damage.

3. Setup and Assembly

Assembly of the Bush Business Furniture Echo L Shaped Desk is required. Instructions are included with the product packaging. It is recommended that **two people** perform the assembly to ensure safety and ease of construction.

3.1 Package Contents

The bundle includes:

- 1 x 60W Credenza Desk
- 1 x 36W Return
- Assembly hardware (Quick-to-assemble hardware for faster and easier installation)

3.2 Assembly Steps

Refer to the detailed assembly instructions provided in the box for step-by-step guidance. The return can be attached to either side of the credenza desk to create a left or right-handed configuration, offering flexibility for your workspace layout.



Image 3.1: Features of the Echo L Shaped Desk, including quick-to-assemble hardware, built-in wire management grommets, a thick surface with durable laminate, and a finished back for versatile placement.




Image 3.2: Detailed dimensions of the L Shaped Desk, showing measurements in both inches and centimeters for width, depth, and height.

4. Operating and Usage

The Echo L Shaped Desk is designed for various office tasks, including drafting, gaming, working, and writing. Its spacious surface provides ample room for your computer, paperwork, and other essentials.

4.1 Weight Capacity

The desktop is engineered to support a maximum weight of**200 pounds (90.72 kg)**. Avoid exceeding this limit to prevent damage to the desk or injury.

4.2 Wire Management

The desk includes built-in wire management grommets to help keep your workspace tidy and organized. Route power cords and data cables through these grommets to maintain a clean aesthetic and prevent tangles.



Image 4.1: A close-up view of the desk's built-in wire management grommet, demonstrating how cables can be neatly routed through the desktop.

4.3 Placement Flexibility

With its fully finished back, the Echo L Shaped Desk can be placed against a wall or in the middle of a room, allowing for versatile office layouts.

5. Maintenance

Proper care will ensure the longevity and appearance of your desk.

5.1 Cleaning

To clean the desk surface, simply **wipe with a damp cloth**. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the thermally fused laminate finish.

5.2 Surface Protection

The desk features a durable thermally fused laminate finish designed to resist scratches and stains. However, it is advisable to use coasters for beverages and desk pads for writing or heavy objects to further protect the surface.




Image 5.1: A detailed view of the modern gray laminate finish, highlighting its texture and durability.

6. Troubleshooting

If you encounter any issues with your desk, consider the following common solutions:

- **Wobbly Desk:** Ensure all screws and fasteners are securely tightened. Check that the desk is on a level surface.
- **Missing Parts:** Carefully check all packaging materials. If parts are genuinely missing, contact customer support with your product model number and a description of the missing components.
- **Surface Damage:** For minor scratches, touch-up pens or kits may be available from the manufacturer. For significant damage, contact customer support.

7. Specifications

Feature	Detail
Brand	Bush Furniture
Model Number	ECH026MG
Shape	L-Shape
Desk Design	Credenza Desk
Product Dimensions (D x W x H)	152D x 152.4W x 76.2H centimetres (59.84D x 60W x 30H inches)
Colour	Modern Gray
Material	Engineered Wood
Finish Type	Thermally Fused Laminate
Item Weight	49.12 kg (108.29 lbs)
Maximum Weight Recommendation	90.72 kg (200 lbs)
Recommended Number of People for Assembly	2
Product Care Instructions	Wipe with Damp Cloth
Included Components	L Shaped Desk (60W Credenza Desk, 36W Return)

8. Warranty

The Bush Business Furniture Echo L Shaped Desk comes with a **3 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty documentation included with your product for full terms and conditions, or visit the Bush Furniture website for more details.

9. Support

For further assistance, questions, or to report missing/damaged parts, please contact Bush Furniture customer support. Have your model number (ECH026MG) and purchase information ready when contacting support.
You can find more information and contact details by visiting the official Bush Furniture store:

Visit the Bush Furniture Store on Amazon

© 2026 Bush Business Furniture. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09LNKZ1X7

More documents and user manuals: **https://manuals.plus/**