

[Manuals.plus](#) /

› [WACACO](#) /

› WACACO Exagram Coffee Scale User Manual

WACACO Exagram

WACACO Exagram Coffee Scale User Manual

Model: Exagram

1. INTRODUCTION

The WACACO Exagram Coffee Scale is a compact and precise digital scale designed for coffee enthusiasts. It features a built-in timer, tare function, and multiple unit conversions (grams, ounces, milliliters) to help you achieve consistent and accurate measurements for your coffee brewing. Its portable design makes it ideal for both home use and travel.



Figure 1: The WACACO Exagram Coffee Scale, held in hand, showcasing its compact size and sleek black design with a digital display.

2. WHAT'S IN THE BOX

Upon opening the package, you should find the following items:

- WACACO Exagram Coffee Scale
- Silicone Pad (removable)
- User Manual (this document)

Please note: **Batteries are not included.** The scale requires 2x AAA batteries.



Figure 2: The WACACO Exagram Coffee Scale, its removable silicone pad, and the user manual, as they appear when unboxed.

3. SETUP

1. **Install Batteries:** Locate the battery compartment on the underside of the scale. Open the cover and insert 2x AAA batteries, ensuring correct polarity. Close the battery compartment cover securely.
2. **Place on a Flat Surface:** Place the scale on a stable, flat, and level surface to ensure accurate readings.
3. **Attach Silicone Pad:** Place the removable silicone pad onto the weighing platform. This pad protects the stainless steel surface from heat transfer and liquid spills, and also provides a non-slip surface for your brewing equipment.



Figure 3: The WACACO Exagram Coffee Scale with its silicone pad detached, revealing the stainless steel weighing surface underneath.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

To power on the scale, press the **ON/OFF** button located on the underside of the unit. To power off, press and hold the **ON/OFF** button for approximately 5 seconds.

4.2. Unit Conversion (g/oz/ml)

The scale supports measurements in grams (g), ounces (oz), and milliliters (ml). To switch between units, double-tap the **TIMER** button.

4.3. Tare Function

The tare function allows you to reset the scale to zero after placing a container on it, so you can measure only the weight of the contents. Place your container on the weighing platform, then press the **TARE** button. The display will show "0.0", indicating the weight of the container has been subtracted.

4.4. Using the Built-in Timer

The built-in timer is ideal for pour-over coffee brewing. To start the timer, press the **TIMER** button. To pause/resume the timer, press the **TIMER** button again. To reset the timer, long-press the **TIMER** button.



Figure 4: The scale in use, accurately weighing coffee beans in a small wooden bowl, demonstrating its precision for brewing.



Figure 5: An espresso cup placed on the scale, illustrating its suitability for precise espresso preparation.

5. MAINTENANCE

To ensure the longevity and accuracy of your WACACO Exagram Coffee Scale, follow these maintenance guidelines:

- **Cleaning:** Wipe the scale surface with a soft, damp cloth. Do not immerse the scale in water or use abrasive cleaners. The silicone pad can be removed and washed with mild soap and water.
- **Storage:** Store the scale in a dry place away from extreme temperatures and direct sunlight.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Always use 2x new AAA batteries.
- **Handle with Care:** Avoid dropping the scale or subjecting it to strong impacts, as this can affect its accuracy.

INSULATION SILICONE PAD

Crafted with durability in mind, the Exagram coffee scale boasts a robust and safe design that's also a breeze to maintain. The added removable silicone pad offers surface protection, making the scale surface non-slippery, scratch-resistant, and heat-insulating.

Dimensions

3.0 X 4.9 X 0.9" / 77 X 124 X 24 MM



Figure 6: The removable silicone pad, designed for insulation and protection, shown on the scale.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Scale does not turn on.	Low or dead batteries; incorrect battery installation.	Replace batteries with new AAA batteries, ensuring correct polarity.
Inaccurate readings.	Scale not on a flat, stable surface; overloaded; damaged sensor.	Ensure scale is on a level surface. Do not exceed 2kg weight limit. If problem persists, contact support.
Display shows "Lo".	Low battery power.	Replace batteries.
Display shows "O-Ld".	Overload.	Remove items from the scale immediately to prevent damage.

7. SPECIFICATIONS

Feature	Detail
Model Number	Exagram
Brand	WACACO
Weight Limit	2 Kilograms (2000g)
Graduation	0.1 g / 0.0035 oz
Display Type	LCD
Power Source	2x AAA Batteries (not included)
Dimensions	7.28 x 5.28 x 1.93 inches (approx. 18.5 x 13.4 x 4.9 cm)
Materials	ABS, Stainless Steel, Silicone
Built-in Timer	Yes
Tare Function	Yes



CHARACTERISTICS

NET DIMENSIONS	3.0" x 4.9" x 0.9"	77 x 124 x 24 mm
NET WEIGH	6.0 oz	171 g
WEIGHING RANGET	0.01~70 oz	0.3 g~2 kg
SCALE INTERVAL	0.3~999.9 g d=0.1 g, 1~2 kg d=1 g	
MAX. COUNT UPTIME	29 minutes and 59 seconds	
AUTO. POWER OFF	After 5 minutes	
DISPLAY	Backlight LCD. Dim light after 30 seconds	
UNITS	g/oz/ml	
POWER SOURCE	1.5Vx2 AAA batteries [*Batteries not included]	
MATERIALS	ABS, Stainless Steel, Silicone	

Figure 7: A visual representation of the scale's key characteristics and specifications.

8. SUPPORT

For any problems with your WACACO Exagram Coffee Scale or if you require assistance, please contact WACACO customer support through Amazon. We are committed to providing timely responses and satisfactory solutions. You can typically find contact information on the product's Amazon listing page or by visiting the official WACACO store on Amazon: [WACACO Amazon Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question