



[Manuals.plus](#) /

> [HOUSUIT](#) /

> HOUSUIT 4-Drawer Dresser Instruction Manual (Model B09LR44Y6H)

HOUSUIT B09LR44Y6H

HOUSUIT 4-Drawer Dresser Instruction Manual

Model: B09LR44Y6H

1. INTRODUCTION

Thank you for choosing the HOUSUIT 4-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The HOUSUIT 4-Drawer Dresser in Dark Brown.

2. SAFETY INFORMATION

- **Anti-Toppling Device:** It is crucial to install the included anti-toppling device to prevent accidental tipping, especially in households with children. Follow the instructions provided for secure installation.
- **Weight Limit:** Do not overload drawers or the top surface. Exceeding weight limits can compromise stability and cause damage.
- **Age Recommendation:** This dresser is suitable for individuals aged 12 and above. Adult supervision is recommended for younger users.
- **Placement:** Place the dresser on a flat, stable surface. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.



Image 2.1: Key safety and design features, including the anti-toppling device.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. Refer to the included parts list in your packaging. If any items are missing or damaged, contact customer support.



Image 3.1: Example of assembly hardware components.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Follow the numbered steps carefully. A power drill may expedite the process, but avoid overtightening screws.

1. **Prepare the Side Panels:** Attach the drawer slides (CL) to the left side panel and drawer slides (CR) to the right side panel using the specified screws. Ensure the ball retainers are at the front end of the rails.
2. **Assemble the Frame:** Connect the top and bottom panels to the side panels using cam locks and dowels. Secure the back panel.
3. **Construct Drawers:** For each drawer, attach the side pieces to the front and back panels. Insert the drawer bottom into the grooves. Secure the drawer slides to the drawer sides.
4. **Install Drawers:** Carefully align each assembled drawer with its corresponding slides on the main frame and push it in until it clicks into place.
5. **Attach Knobs:** Secure the knobs to the front of each drawer.
6. **Install Anti-Toppling Device:** Attach the anti-toppling device to the back of the dresser and to a wall stud, following the specific instructions provided with the device.

Assembly Video Guide

Your browser does not support the video tag.

Video 4.1: A detailed installation guide for a similar 5-drawer dresser, demonstrating the general assembly process.

5. OPERATING INSTRUCTIONS

The HOUSUIT 4-Drawer Dresser is designed for smooth and efficient storage.

- **Drawer Usage:** Pull drawers gently using the knobs. The premium metal slides ensure smooth opening and closing.
- **Storage Capacity:** The four wide drawers provide ample space for various items, from clothing and accessories to documents and toys.
- **Top Surface:** The spacious tabletop can be used for decorative items, lamps, or other personal belongings.

Rounded Corner ●



● Waterproof Paint

Anti-toppling Device ●




Image 5.1: An open drawer demonstrating storage potential.

Drawer Operation Video

Your browser does not support the video tag.

Video 5.2: A demonstration of the 4-drawer dresser's smooth drawer operation.

6. MAINTENANCE

- **Cleaning:** Wipe the dresser surface with a dry cloth. The environmentally friendly paint is waterproof and easy to clean. Avoid abrasive cleaners.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain stability.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the slides.

7. TROUBLESHOOTING

- **Wobbly Dresser:** Ensure the dresser is on a level surface. Check all assembly screws and tighten them. Verify the anti-toppling device is securely installed.
- **Drawers Not Closing Smoothly:** Check for any obstructions in the drawer slides. Ensure the drawer slides are correctly aligned and not bent. Re-lubricate if needed.
- **Missing Parts:** If any parts were missing upon delivery, contact HOUSUIT customer service for replacements.

8. SPECIFICATIONS

Brand	HOUSUIT
Model Number	B09LR44Y6H
Product Dimensions	29"W x 15.7"D x 37"H
Color	Dark Brown
Material	High-grade MDF, Metal Slides
Item Weight	54 Pounds
Assembly Required	Yes



Image 8.1: Visual representation of dresser dimensions.

9. WARRANTY AND SUPPORT

The HOUSUIT 4-Drawer Dresser comes with a limited warranty. For warranty claims, replacement parts, or any other support inquiries, please refer to the contact information provided with your purchase documentation or visit the official HOUSUIT website.