

## Ipro EPro A25

# Ipro EPro A25 Cell Phone User Manual

Model: EPro A25

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Ipro EPro A25 cell phone. Please read it thoroughly before operating your device.

The Ipro EPro A25 is a compact cellular phone designed for daily use, featuring dual SIM card slots, a memory card slot for expanded storage, and an integrated camera to capture moments.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- Ipro EPro A25 Cell Phone
- Battery
- Charger
- User Manual (this document)
- (Other accessories may vary by region)

## 3. DEVICE LAYOUT

Familiarize yourself with the physical components of your Ipro EPro A25 phone.



**Figure 3.1:** Front and rear view of the Ipro EPro A25 cell phone. The front displays the screen and keypad, while the rear shows the speaker and IPRO branding.

- **Front:** Display screen, navigation keys, alphanumeric keypad.
- **Rear:** Speaker, IPRO branding.
- **Sides:** (Implied, but not visible in image) Charging port, headphone jack.

## 4. SETUP

---

### 4.1. Installing the SIM Card(s)

Your phone supports dual SIM cards. Ensure the phone is powered off before installation.

1. Remove the back cover of the phone.
2. Carefully remove the battery.
3. Insert the SIM card(s) into the designated slot(s) with the gold contacts facing down.
4. Ensure the SIM card(s) are securely seated.

### 4.2. Installing the Memory Card

To expand storage for photos and other files, install a memory card (MicroSD).

1. With the back cover and battery removed, locate the memory card slot.
2. Insert the memory card into the slot until it clicks into place.

### 4.3. Installing the Battery and Charging

1. Place the battery into its compartment, aligning the contacts.
2. Replace the back cover.
3. Connect the charger to the phone's charging port and plug it into a power outlet.
4. Allow the phone to charge fully before first use.

## 5. BASIC OPERATION

---

### 5.1. Power On/Off

- **To Power On:** Press and hold the Power key (usually the red 'End Call' key) until the screen lights up.
- **To Power Off:** Press and hold the Power key until the power-off options appear, then select 'Power Off'.

### 5.2. Making and Receiving Calls

- **To Make a Call:** Enter the phone number using the keypad and press the 'Call' key (usually the green 'Send Call' key).
- **To Receive a Call:** Press the 'Call' key when the phone rings.
- **To End a Call:** Press the 'End Call' key.

### 5.3. Messaging (SMS)

- Navigate to the 'Messages' menu.
- Select 'Write Message' or 'New Message'.
- Enter your message using the keypad.
- Enter the recipient's number or select from contacts, then send.

### 5.4. Using the Camera

- Access the camera application from the main menu.
- Frame your shot using the screen.
- Press the designated 'Capture' or 'OK' key to take a photo.
- Photos are saved to the phone's memory or the installed memory card.

## 6. CONNECTIVITY

---

### 6.1. Bluetooth

The phone supports Bluetooth for wireless connection to compatible devices like headsets or other phones.

1. Go to 'Settings' > 'Connectivity' > 'Bluetooth'.
2. Turn Bluetooth 'On'.
3. Search for available devices and pair with the desired device.

### 6.2. USB Connection

Connect your phone to a computer using a USB cable to transfer files or charge the device.

- Connect one end of the USB cable to the phone's USB port and the other to your computer.
- The phone may prompt you to select a connection mode (e.g., Mass Storage, Charge Only).

## 7. MAINTENANCE AND CARE

---

- Keep the phone dry. Moisture can damage electronic circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone.
- Use a soft, dry cloth to clean the phone's surface.

- Handle the phone with care. Do not drop, knock, or shake it.

## 8. TROUBLESHOOTING

| Problem                       | Possible Solution  |
|-------------------------------|--|
| Phone does not power on.      | Ensure the battery is correctly installed and charged. Try charging the phone for at least 30 minutes.                           |
| Cannot make or receive calls. | Check if the SIM card is properly inserted. Verify network signal strength. Contact your service provider if the issue persists. |
| Poor camera image quality.    | Ensure the camera lens is clean and free from smudges. Check lighting conditions.  |
| Memory card not detected.     | Reinsert the memory card. Ensure it is compatible with the phone. Try formatting the card (this will erase all data).            |







## 9. SPECIFICATIONS

| Feature                 | Detail                |
|-------------------------|-----------------------|
| Model                   | EPro A25              |
| Manufacturer            | lpro                  |
| Screen Size             | 2.4 Inches            |
| Cellular Technology     | 2G                    |
| Connectivity Technology | Bluetooth, USB, Wi-Fi |
| Color                   | Black                 |
| SIM Card Slot Count     | Dual SIM              |
| Form Factor             | Bar                   |
| Camera Description      | Rear                  |
| Date First Available    | 19 April 2022         |

## 10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact your retailer. Keep your purchase receipt as proof of purchase.



|   |   |
|---|---|
|    | <p><a href="#">IPRO S501 Quick Start Guide</a></p> <p>A concise guide to getting started with the IPRO S501 mobile phone, covering device location, battery charging, SIM card insertion, dual SIM functionality, safety information, cell broadcast, and FCC compliance.</p>   |
|    | <p><a href="#">IPRO S501 Quick Starter Guide</a></p> <p>A concise guide to the IPRO S501 mobile phone, covering device setup, battery charging, SIM card insertion, dual SIM functionality, safety information, and FCC compliance.</p>   |
|    | <p><a href="#">IPRO S401 Quick Starter Guide - Setup and Safety Information</a></p> <p>A concise guide to setting up and safely using the IPRO S401 mobile phone, covering device overview, battery charging, SIM card installation, dual SIM functionality, and important safety and FCC compliance information.</p>   |
|    | <p><a href="#">IPRO Senior F188 Feature Phone - 2G GSM, 1000mAh, Dual SIM, Black-Gray</a></p> <p>Discover the IPRO Senior F188, a durable 2G GSM feature phone offering essential mobile communication. Features include a 1.77-inch display, 1000mAh battery, Dual SIM capability, FM radio, and MP3 playback. Ideal for users seeking simplicity and reliability.</p> |
|   | <p><a href="#">IPRO Mobile Phone User Manual: Features, Operation, and Safety Guide</a></p> <p>Comprehensive user manual for the IPRO mobile phone. Covers essential functions like calling, messaging, multimedia, connectivity, safety precautions, and maintenance for optimal device usage.</p>   |
|  | <p><a href="#">IPRO F183 Mobile Phone User Manual and FCC Compliance</a></p> <p>User manual and FCC compliance information for the IPRO F183 mobile phone, detailing features like 3D stereo sound, cell broadcast, and RF exposure guidelines.</p>   |