

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Kimberly-Clark](#) /

› [Kimberly-Clark Jumbo Jr. Toilet Paper Dispenser \(Model B09LRHJ73N\) User Manual](#)

Kimberly-Clark B09LRHJ73N

Kimberly-Clark Jumbo Jr. Toilet Paper Dispenser

Model: B09LRHJ73N (Compatible with Jumbo Jr. Rolls 90531/90509)

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your Kimberly-Clark Jumbo Jr. Toilet Paper Dispenser. Designed for high-traffic areas, this dispenser helps minimize cross-contamination, promoting a more hygienic environment. Its compact and aesthetic design is suitable for various commercial settings such as restaurants, gyms, offices, schools, hotels, and cafeterias.

SETUP AND INSTALLATION

The Kimberly-Clark Jumbo Jr. Toilet Paper Dispenser is designed for wall-mounted installation. An installation kit and a Z-type security key are included for your convenience.

- Unpack Contents:** Carefully remove the dispenser, installation kit (screws and wall anchors), and security key from the packaging.
- Select Location:** Choose a suitable wall location, ensuring it is at an appropriate height and clear of obstructions.
- Mark Drilling Points:** Use the back of the dispenser as a template to mark the desired drilling points on the wall. Ensure the dispenser is level before marking.
- Drill Holes:** Drill pilot holes at the marked points. Insert the wall anchors if necessary, depending on your wall material.
- Mount Dispenser:** Align the dispenser's mounting holes with the drilled holes and secure it to the wall using the provided screws.
- Test Security:** Ensure the dispenser is firmly attached to the wall and does not wobble.



Image: The Kimberly-Clark Jumbo Jr. Dispenser shown with its included installation kit (screws and wall anchors) and a Z-type security key. This image illustrates all components necessary for mounting the dispenser.



Image: A detailed view of the back of the Kimberly-Clark Jumbo Jr. Dispenser. This image highlights the molded plastic structure and the designated mounting points for secure wall installation.

OPERATING INSTRUCTIONS

This dispenser is designed for easy loading and features a multi-directional paper cutting mechanism for user convenience.

1. **Open the Dispenser:** Insert the Z-type security key into the lock mechanism on the side of the dispenser and turn it to unlock. The front cover will swing open.
2. **Load Toilet Paper Roll:** Place a new Jumbo Jr. toilet paper roll (models 90531/90509) onto the internal spindle. Ensure the paper feeds from the bottom of the roll.
3. **Thread Paper:** Pull the leading edge of the toilet paper through the dispenser's opening, ensuring it is accessible for users.
4. **Close the Dispenser:** Swing the front cover back into place until it clicks securely. Lock the dispenser with the key to prevent unauthorized access and ensure hygiene.
5. **Dispensing Paper:** Users can pull the paper downwards from the opening. The integrated serrated edge allows for easy, multi-directional tearing.



Image: The Kimberly-Clark Jumbo Jr. Dispenser shown with its front cover swung open, revealing the internal mechanism designed to hold a large toilet paper roll. This view demonstrates how to load the paper.



Image: A close-up view of the lower front section of the Kimberly-Clark Jumbo Jr. Dispenser. This image highlights the serrated edge for efficient paper cutting and the 'Kimberly-Clark PROFESSIONAL' logo.

MAINTENANCE

The dispenser is constructed from durable and resistant plastic, making it easy to maintain.

- **Cleaning:** Regularly wipe the exterior of the dispenser with a damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Interior Cleaning:** Periodically, open the dispenser and wipe down the interior surfaces to remove any dust or paper residue.
- **Inspection:** Check the dispenser regularly for any signs of wear or damage. Ensure the lock mechanism functions correctly.

TROUBLESHOOTING

- **Paper Not Dispensing:**

- Ensure the toilet paper roll is correctly loaded onto the spindle and not jammed.
- Check if the paper is properly threaded through the dispenser opening.
- Verify that the roll is not empty.

- **Dispenser Door Not Closing/Locking:**

- Ensure no part of the toilet paper roll is obstructing the door's closing path.
- Check the lock mechanism for any debris or damage.

- **Dispenser Loose on Wall:**

- Tighten the mounting screws. If the issue persists, inspect the wall anchors and consider repositioning if the wall material is compromised.

SPECIFICATIONS

Brand	Kimberly-Clark
Model Number	B09LRHJ73N
Material	Plastic
Color	Smoke
Finish Type	Matte
Installation Type	Wall Mounted
Package Dimensions	31.2 x 28.4 x 17.4 cm
Item Weight	1.06 kg
Batteries Required	No

WARRANTY INFORMATION

For specific warranty details regarding your Kimberly-Clark Jumbo Jr. Toilet Paper Dispenser, please refer to the documentation provided with your purchase or contact Kimberly-Clark customer service directly. General return policies may apply as per the retailer's terms.

CUSTOMER SUPPORT

If you require further assistance, have questions about installation, operation, or maintenance, please contact Kimberly-Clark customer support. Visit the official Kimberly-Clark website for contact information and additional resources.