

TechniSat DR 570

TechniSat DIGITRADIO 570 CD IR Stereo Internet Radio User Manual

Model: DR 570

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your TechniSat DIGITRADIO 570 CD IR. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your listening experience. Keep this manual for future reference.

The TechniSat DIGITRADIO 570 CD IR is a versatile stereo internet radio offering a wide range of audio sources including DAB+, FM, Internet Radio, CD playback, Bluetooth audio streaming, Spotify Connect, and USB media playback with charging capabilities. It features a clear 2.4-inch TFT color display and can be controlled via the included remote control or a dedicated app.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- TechniSat DIGITRADIO 570 CD IR Unit
- Remote Control (requires 2 AAA batteries, included)
- Integrated Telescopic Antenna
- External Power Supply Unit
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your DIGITRADIO 570 CD IR.



Front view of the TechniSat DIGITRADIO 570 CD IR, showcasing the display, control buttons, volume knobs, and extended telescopic antenna.



Rear view of the TechniSat DIGITRADIO 570 CD IR, highlighting the connectivity ports: 1. AUX Input, 2. Headphone Jack (3.5 mm), 3. USB Port (MP3 Playback & Charging), 4. Power Connection, 5. Easy operation via front buttons and rotary controls.

4. SETUP

4.1 Power Connection

1. Connect the external power supply unit to the DC IN port (4) on the rear of the radio.

2. Plug the power supply into a standard wall outlet.

4.2 Antenna

For optimal DAB+ and FM radio reception, fully extend the integrated telescopic antenna. Adjust its position to improve signal strength if needed.

4.3 Initial Setup Wizard

Upon first power-on, the device will guide you through an initial setup wizard. Follow the on-screen prompts to set language, time, date, and network connection.

4.4 Network Connection (Wi-Fi)

A stable Wi-Fi connection is required for Internet Radio, Spotify Connect, and app control.

1. During the initial setup or via the system settings menu, select "Network" or "Wi-Fi Setup".
2. The radio will scan for available Wi-Fi networks. Select your network from the list.
3. Enter your Wi-Fi password using the controls on the radio or the remote control.
4. Confirm the password to establish the connection.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

- **Power Button:** Press to turn the unit on or off (standby).
- **Mode Button:** Cycle through available audio sources (DAB+, FM, Internet Radio, CD, Bluetooth, AUX, USB).
- **Info/Menu Button:** Access information about the current track/station or enter the main menu.
- **Volume Knobs:** Adjust the audio output level.
- **Tuning/OK Knob:** Navigate menus, select options, or tune radio stations.
- **Preset Buttons (1-5+):** Store and recall favorite radio stations.
- **Scan/Play/Pause Button:** Initiate station scan or control media playback.
- **Back/Stop Button:** Go back in menus or stop media playback.

5.2 Radio Modes (DAB+, FM, Internet Radio)




DAB+ ET FM/UKW

Diversité de programmes radio nationaux
et régionaux en qualité numérique.

The TechniSat DIGITRADIO 570 CD IR supports DAB+ and FM radio, offering a wide variety of national and regional digital radio programs.



A close-up of the 2.4-inch dimmable TFT color display, showing current Internet Radio station information and track details for clear visibility.



Radio Internet

Une variété musicale illimitée venant d'internet.

An image symbolizing the unlimited musical variety available through Internet Radio on the DIGITRADIO 570 CD IR.

Press the **Mode** button to select your desired radio mode. Use the **Tuning/OK** knob to navigate through stations or lists. Press **Scan** to automatically find available stations.

- **DAB+:** Offers high-quality digital radio broadcasts.
- **FM:** For traditional analog radio reception.
- **Internet Radio:** Access thousands of radio stations worldwide via your Wi-Fi connection.

5.3 CD Playback




Lecteur CD avec fonction MP3

Joue vos CDs favoris encore et encore.

The integrated CD player with MP3 function allows you to enjoy your favorite audio CDs.

Insert an audio CD or an MP3 CD into the CD slot. The radio will automatically switch to CD mode and begin playback. Use the playback controls (Scan/Play/Pause, Back/Stop, Skip buttons) to manage your music.

5.4 Bluetooth Streaming



Plaisir Musical Sans Fil
Avec le streaming audio
Bluetooth et Spotify Connect.

Enjoy wireless music streaming from your smartphone or tablet via Bluetooth.

Select Bluetooth mode using the **Mode** button. On your mobile device, enable Bluetooth and search for "DIGITRADIO 570 CD IR" to pair. Once connected, you can stream audio wirelessly from your device to the radio.

5.5 Spotify Connect

To use Spotify Connect, ensure your radio is connected to Wi-Fi and you have an active Spotify Premium account.

1. Open the Spotify app on your smartphone, tablet, or computer.
2. Play a song and tap the "Devices Available" icon.
3. Select your DIGITRADIO 570 CD IR from the list of devices.

5.6 USB Playback and Charging



Lecture USB

Branchez un support de stockage USB via l'interface USB pour jouer la musique directement.



Fonction de Chargement USB
 Vous pouvez charger des appareils tels que des smartphones ou des lecteurs de musique via le port USB.



The USB port allows for direct music playback from a USB storage device and also functions as a charging port for compatible devices like smartphones.


Insert a USB storage device (e.g., USB stick) containing MP3 files into the USB port (3) on the rear. Select USB mode to browse and play your music. The USB port also provides a charging function for external devices.

5.7 Alarm Clock and Sleep Timer

The DIGITRADIO 570 CD IR includes an alarm clock with snooze function and a sleep timer.

- **Alarm:** Set up to two independent alarms with customizable sources (buzzer, radio, CD) and volume. Access alarm settings via the main menu.
- **Sleep Timer:** Set a timer for the radio to automatically turn off after a specified duration. This is typically found in the system settings or by pressing the sleep button on the remote.
- **Snooze:** When an alarm sounds, press the snooze button to temporarily pause the alarm.

5.8 App Control



Control your DIGITRADIO 570 CD IR conveniently using a dedicated smartphone app via Wi-Fi.

Download the UNDOK app (or equivalent recommended by TechniSat) from your device's app store. Ensure your smartphone and the radio are connected to the same Wi-Fi network. The app allows for remote control of all radio functions, including source selection, volume, station tuning, and settings management.

6. MAINTENANCE

6.1 Cleaning

- Always disconnect the power supply before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- For stubborn marks, lightly dampen the cloth with water. Avoid abrasive cleaners or solvents.
- Do not allow liquids to enter the device.

6.2 CD Player Care

- Handle CDs by their edges to avoid fingerprints and scratches.
- Clean CDs with a soft, lint-free cloth, wiping from the center outwards.
- Do not use scratched or damaged CDs, as they may damage the player mechanism.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty	Check power cable connection; try a different outlet.
No sound	Volume too low; mute activated; incorrect source selected	Increase volume; check mute status; select correct audio source.
Poor radio reception (DAB+/FM)	Antenna not extended; weak signal	Fully extend and adjust the telescopic antenna; try repositioning the unit.
Internet Radio not working	No Wi-Fi connection; incorrect Wi-Fi password	Check Wi-Fi connection in settings; re-enter Wi-Fi password; restart router.

Problem	Possible Cause	Solution
CD not playing	CD inserted incorrectly; CD scratched/damaged; CD format not supported	Ensure CD is inserted correctly; try a different CD; verify CD format (audio CD or MP3 CD).
Bluetooth pairing issues	Radio not in Bluetooth mode; device too far; device already paired	Select Bluetooth mode on radio; ensure device is within range; unpair and re-pair if necessary.

8. SPECIFICATIONS







Feature	Detail
Model	DIGITRADIO 570 CD IR
Brand	TechniSat
Color	Black
Tuning Technology	Internet Radio / DAB / DAB+ / FM
Connectivity	WLAN (Wi-Fi), Bluetooth
Special Features	DAB+ digital radio, Favorite memory, FM radio, Internet radio, Audio streaming, 2.4" TFT color display, CD player with MP3 playback, USB interface with charging function, App control, Alarm clock, Sleep timer, Equalizer
Audio Output	2 x 5 W Stereo Speakers
USB Ports	1 (for playback and charging)
Compatible Devices	Headphones, Smartphone, Tablet
Power Source	External Power Supply Unit
Remote Control Batteries	2 x AAA (included)
Product Dimensions (L x W x H)	29.1 cm x 21.7 cm x 14.5 cm

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official TechniSat website. Keep your proof of purchase for warranty claims.

Note: Spare parts availability and software update guarantees are not specified in the product information provided. Please contact TechniSat customer service for the most current information regarding these aspects.

Related Documents - DR 570

	<p>TechniSat DIGITRADIO 570 CD IR User Manual</p> <p>Comprehensive user manual for the TechniSat DIGITRADIO 570 CD IR, a DAB+/FM/Internet stereo radio with CD player, Bluetooth, and Spotify Connect. Includes setup, operation, features, troubleshooting, and technical specifications.</p>
	<p>TechniSat DIGITRADIO 140 Instruction Manual</p> <p>Comprehensive instruction manual for the TechniSat DIGITRADIO 140, covering setup, operation, features like Internet Radio, DAB+, FM, Bluetooth, CD/MP3 playback, and troubleshooting.</p>
	<p>TechniSat DIGITRADIO 217 Operating Instructions</p> <p>Comprehensive operating instructions for the TechniSat DIGITRADIO 217, detailing its features, setup, functions, and safety guidelines for DAB+/UKW radio with Bluetooth audio streaming and alarm clock functionality.</p>
	<p>TechniSat DIGITRADIO 217 Operating Instructions</p> <p>User manual for the TechniSat DIGITRADIO 217, a DAB+/UKW radio featuring Bluetooth audio streaming and an alarm clock function. Learn about setup, operation, safety, and technical specifications.</p>
	<p>TechniSat DIGITRADIO 11 IR Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für das TechniSat DIGITRADIO 11 IR. Entdecken Sie Funktionen wie Internetradio, DAB+, UKW, Bluetooth-Streaming, Spotify Connect und Amazon Music. Enthält Installationsanleitungen, Sicherheitshinweise und Fehlerbehebung.</p>
	<p>TechniSat DIGITRADIO 143 CD Instruction Manual</p> <p>Comprehensive instruction manual for the TechniSat DIGITRADIO 143 CD, covering setup, operation, features like internet radio, DAB+, FM, Bluetooth, and CD playback, along with troubleshooting and technical data.</p>