

Ameriwood Home 6762341COM

Ameriwood Home Merritt Avenue Electric Fireplace TV Console User Manual

Model: 6762341COM

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Ameriwood Home Merritt Avenue Electric Fireplace TV Console. This unit is designed to accommodate flat-screen televisions up to 74 inches and 120 lbs, offering both media storage and an electric fireplace for supplemental heating and ambiance.



Image: The Ameriwood Home Merritt Avenue Electric Fireplace TV Console in Ivory Oak finish.



Image: The console integrated into a living room setting with a television.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and operation. Failure to follow these instructions may result in electric shock, fire, or personal injury. Retain this manual for future reference.

Electrical Safety

- Ensure the electric fireplace is plugged into a standard 120V outlet.
- Do not overload electrical circuits. Avoid plugging other high-wattage appliances into the same circuit as the fireplace.
- Do not run the power cord under carpeting or other floor coverings.
- Always plug the unit directly into a wall outlet. Do not use extension cords or power strips.
- If the power cord is damaged, it must be replaced by the manufacturer or a qualified service agent to avoid a hazard.

Best Practice



Image: Proper electrical connection to a wall outlet.

General Safety

- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains, at least 3 feet (0.9 m) from the front of the heater.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Do not block air intakes or exhaust openings in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

ASSEMBLY INSTRUCTIONS


The Ameriwood Home Merritt Avenue Electric Fireplace TV Console ships flat and requires assembly. Two adults are recommended for assembly and moving the unit. The assembly process involves 24 steps and includes 23 boards.

Required Tools (Not Included)

- Phillips head screwdriver
- Hammer

Assembly Steps Overview

1. Unpack all components and verify against the parts list.
2. Follow the step-by-step diagrams provided in the included assembly manual.
3. Ensure all cam locks and screws are securely fastened.
4. Install the electric fireplace insert according to its specific instructions.
5. Attach cabinet doors and adjust hinges for proper alignment.



Medium Assembly Level

1-2 adults recommended to assemble

Item ships in

1
BOX

24

Steps inside the
assembly manual

23

Boards inside
the box



1 Year Limited Warranty
for Manufacturer Defects



To Clean:

Wipe with a dry cloth
or duster

Image: Assembly level indicator, showing 'Medium' difficulty, recommending 1-2 adults.



Image: Console with an open cabinet door, illustrating internal storage.

OPERATING INSTRUCTIONS

The electric fireplace insert provides both heat and realistic flame effects. It can be controlled via the included remote control or the touch panel on the unit.

Fireplace Controls

- **Power Button:** Turns the fireplace on or off.
- **Heat Setting:** Adjusts the temperature output. The 23-inch fireplace insert is capable of warming a room up to 400 square feet.
- **Flame Setting:** Adjusts the intensity and style of the flame effect. Multiple flame options are available.
- **Flame Only Mode:** Allows the flame effect to operate without heat, providing ambiance year-round.

Refer to the specific instructions provided with the electric fireplace insert for detailed button functions and remote control pairing.



Image: Close-up of the electric fireplace insert with illuminated flames and control panel.

MAINTENANCE

To maintain the appearance and functionality of your TV console and electric fireplace, follow these simple guidelines:

Cleaning

- For the console surfaces, wipe with a dry cloth or duster. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- For the electric fireplace glass and vents, ensure the unit is off and cool before cleaning. Use a soft, damp cloth for the glass and a vacuum cleaner with a brush attachment for the vents to remove dust.

General Care

- Periodically check all hardware connections to ensure they remain tight.
- Avoid placing hot items directly on the console surface without protection.

TROUBLESHOOTING

If you encounter issues with your Ameriwood Home Merritt Avenue Electric Fireplace TV Console, consider the following common solutions:

Fireplace Not Turning On

- Check if the power cord is securely plugged into a working 120V outlet.
- Ensure the wall outlet is receiving power (test with another appliance).
- Verify the power switch on the fireplace insert itself is in the 'ON' position.
- Replace remote control batteries if using the remote.

No Heat Output

- Confirm the heat setting is activated and adjusted to a desired temperature.

- Check for any obstructions blocking the heater's air intake or exhaust vents.

Unstable or Wobbly Console

- Ensure all assembly hardware (screws, cam locks) are tightened.
- Verify the console is placed on a flat, level surface.

SPECIFICATIONS

Feature	Detail
Brand	Ameriwood Home
Model Name	Merritt Avenue
Model Number	6762341COM
Color	Ivory Oak
Material	Engineered Wood
Product Dimensions (D x W x H)	19.69" x 59.61" x 29.88"
Item Weight	122 Pounds
TV Size Capacity	Up to 74 inches
TV Weight Capacity	Up to 120 lbs
Power Source	Corded Electric
Heat Output	5100 British Thermal Units
Heating Coverage	Up to 400 square feet
Power Consumption	1.74 Kilowatts
Installation Type	Freestanding
UPC	029986676214



Ivory Oak

120 lbs (54.4 kg)
 30 lbs (13.6 kg)
 Each Shelf: 15 lbs (6.8 kg)

Additional Finishes



Black Oak

Image: Detailed dimensions and weight capacities of the console.

WARRANTY INFORMATION

The Ameriwood Home Merritt Avenue Electric Fireplace TV Console comes with a **1 Year Limited Warranty** for manufacturer defects. Please retain your proof of purchase for warranty claims.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accident, or unauthorized repairs.

CUSTOMER SUPPORT

For further assistance, missing parts, or warranty claims, please contact Ameriwood Home customer service. You can find more information and contact details by visiting the official Ameriwood Home store page:

[Visit the Ameriwood Home Store](#)

© 2025 Ameriwood Home. All rights reserved.