

Universal 768494810665

Universal Stainless Steel Skull Watch for Men

Model: 768494810665

1. PRODUCT OVERVIEW

This manual provides instructions for the Universal Stainless Steel Skull Watch, a quartz wristwatch designed for men. It features a distinctive skull dial, luminous hands for visibility in low light, and a durable stainless steel construction.

Key Features:

- **Movement:** Precise Quartz movement for accurate timekeeping.
- **Dial:** Unique stereoscopic skull design with clear time markers.
- **Hands:** Luminous hands for enhanced visibility in the dark.
- **Material:** Stainless steel case and strap for durability.
- **Water Resistance:** 30m (3ATM) for daily use.



Figure 1: Front view of the Universal Stainless Steel Skull Watch. This image displays the watch face with its prominent skull design and stainless steel strap.

2. SETUP

2.1 Setting the Time

1. Pull the crown (the small knob on the side of the watch case) gently outwards to the first position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

2.2 Adjusting the Strap

The stainless steel strap can be adjusted by removing links to achieve a comfortable fit. It is recommended to have this procedure performed by a professional watchmaker to avoid damage to the strap or watch.

3. OPERATING INSTRUCTIONS

This watch operates on a quartz movement, providing accurate timekeeping. The luminous hands absorb light and glow in the dark, allowing for easy time reading in low-light conditions.



Figure 2: Close-up view of the watch dial, highlighting the stereoscopic skull design and the luminous hour and minute hands.

4. MAINTENANCE

4.1 Cleaning

Regularly clean the watch strap and case with a soft, dry cloth to remove dirt and oils. For stubborn grime, a slightly damp cloth can be used, followed by immediate drying.

4.2 Water Resistance

The watch is rated for 30 meters (3ATM) water resistance. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water. However, it is **not** suitable for:

- Bathing or showering
- Swimming
- Diving or snorkeling
- Sauna or hot baths (extreme temperature changes can affect seals)

Excessive contact with water, especially hot water, can reduce the lifespan of the watch's water resistance seals.

4.3 Battery Replacement

The watch uses a standard watch battery. When the watch stops or the time becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and function.

5. TROUBLESHOOTING

If you experience issues with your watch, consider the following:

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Inaccurate time:** Reset the time as described in Section 2.1. If the issue persists, the battery may be low or the movement may require servicing.
- **Condensation under crystal:** This indicates a breach in water resistance. Avoid further contact with water and seek professional service immediately.

For issues not covered here, please contact customer support.

6. SPECIFICATIONS

Feature	Specification
Model Number	768494810665
Movement Type	Quartz
Case Material	Stainless Steel
Strap Material	Stainless Steel
Mirror Material	Mineral Reinforced Glass
Case Diameter	4.4 cm
Case Thickness	1.2 cm

Strap Length	24 cm
Strap Width	2.0 cm
Water Resistance	30m (3ATM)
Weight	160 g



Figure 3: Rear view of the watch, displaying the stainless steel case back and the clasp mechanism of the stainless steel strap.



7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

© 2023 Universal. All rights reserved.

Related Documents - 768494810665

[illegible]

	<p>Universal Two Channel Garage Door Opener Wireless Keypad JP-LT Instructions</p> <p>This document provides instructions for programming and installing the Universal Two Channel Garage Door Opener Wireless Keypad JP-LT. It covers setup for different opener types, PIN code management, and battery replacement.</p>
	<p>3.5 FT Animated LED Scarred Chucky Use and Care Guide Universal Halloween Decoration</p> <p>Official use and care guide for the 3.5 FT Animated LED Scarred Chucky decoration by Universal. Includes assembly instructions, operation settings, warnings, and care tips.</p>