

[Manuals.plus](#) /

› [COLSUR](#) /

› Wireless Charging Station, 7 in 1 Charging Station, Alarm Clock with Wireless Charger, Night Light, iPhone 12/13/14/15/16 Pro/Pro Max/13 Mini/13 Pro Max/12 pro, AirPods White

COLSUR S28-W

COLSUR Wireless Charging Station User Manual

Model: S28-W

1. INTRODUCTION

Thank you for choosing the COLSUR Wireless Charging Station. This 7-in-1 device combines a wireless charger, alarm clock, and night light, designed to simplify your charging needs and enhance your bedside experience. It supports fast wireless charging for compatible smartphones, smartwatches, and earbuds, while also offering an additional USB port for other devices. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Image 1: The COLSUR Wireless Charging Station, showcasing its ability to charge a smartphone, smartwatch, and earbuds simultaneously, alongside its integrated alarm clock and night light features.

2. SAFETY PRECAUTIONS

To ensure safe and proper operation, please read and follow these precautions:

- Use only the provided QC3.0 adapter and charging cable.
- Do not disassemble, modify, or repair the device yourself.
- Keep the device away from water, moisture, and high temperatures.
- Avoid placing metal objects or magnetic cards on the wireless charging pad, as this may interfere with charging or damage the device.
- Ensure proper ventilation around the device during operation.
- This device is designed for indoor use only.

ADVANCED SAFETY FEATURES



Night light



Alarm clock



Wireless charger



Cable receiver box




Image 2: An internal view of the charging station, illustrating its advanced safety features including over-current, over-voltage, and over-temperature protection, along with foreign object detection.

3. PACKAGE CONTENTS

Please check the package for the following items:

- COLSUR Wireless Charging Station (Model: S28-W)
- QC3.0 Power Adapter
- USB-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the different parts of your COLSUR Wireless Charging Station:

MULTIFUNCTIONAL WIRELESS CHARGING



Image 3: A detailed diagram labeling the key components of the charging station, including the LED light area, alarm clock area, earphone charging area, watch charging area, mobile phone wireless charging area, alarm function button area, and USB output interface.

- **Wireless Charging Pad:** For smartphones.
- **Earbud Charging Area:** For wireless earbuds (e.g., AirPods).
- **Watch Charging Area:** For smartwatches (e.g., Apple Watch).
- **Alarm Clock Display:** Digital time display with adjustable brightness.
- **Night Light:** Integrated LED light with adjustable brightness and color modes.
- **USB Output Port:** Additional port for wired charging of other devices.
- **Control Buttons:** For setting time, alarm, and adjusting light settings.

5. SETUP

Follow these steps to set up your charging station:

1. **Connect Power:** Plug the provided USB-C charging cable into the USB-C port at the rear of the charging station. Connect the other end of the cable to the QC3.0 power adapter, then plug the adapter into a wall outlet. The clock display will light up, indicating power is connected.
2. **Install Watch/Earbud Cables (Optional):** For charging smartwatches and earbuds, you will need to use your own charging cables. Route these cables through the designated channels within the accessory box. Ensure the cables are less than 3 feet long to fit properly within the storage case.
3. **Initial Clock Setting:**
 - Press and hold the "SET" button to enter time setting mode.
 - Use the "+" and "-" buttons to adjust hours and minutes.
 - Press "SET" again to confirm each setting and move to the next.
 - The clock supports 12-hour and 24-hour display modes.
4. **Adjust Clock Brightness:** The clock display has 3 levels of brightness. Press the "DIMMER" button to cycle through brightness levels or turn off the display.



Image 4: The charging station ready for use, demonstrating its compact design and integrated charging areas for multiple devices.

6. OPERATING INSTRUCTIONS

6.1 Wireless Charging

Place your Qi-compatible smartphone on the wireless charging pad. Ensure the phone is centered on the pad for optimal charging. The charging indicator light will confirm charging status.

- **15W Charging Mode:** Compatible with iPhone 16/15/14/13/13 Pro/Pro Max/13 Mini/12, Samsung S21/S20/Note 10/10 Plus/S10/S10 Plus/S10E.
- **5W Charging Mode:** Works with Google Pixel 3/3XL/4XL and other Qi-enabled phones.
- **Case Compatibility:** The wireless charging pad is case-friendly and can charge through phone cases up to 5mm thick. Remove cases with magnets, metal, or credit cards as they may interfere with charging.




Image 5: A smartphone placed on the wireless charging pad, showing the charging icon on its screen, indicating active wireless charging.

6.2 Earbud and Smartwatch Charging

Place your earbuds case or smartwatch on their respective charging areas. Ensure they are properly aligned with their charging connectors. These areas require your own charging cables to be installed within the portable cable storage box.



Image 6: A close-up of the portable cable storage box, designed to neatly house watch and earbud charging cables, keeping the charging area tidy.

6.3 Night Light Operation

The night light offers adjustable brightness and three color modes:

- **Turn On/Off:** Short press the light control button to turn the light on or off.
- **Change Color Mode:** While the light is on, short press the light control button to cycle through White, Warm White, and Warm light modes.
- **Adjust Brightness:** Long press the light control button to infinitely dim the light from 10% to 100%. Release at your desired brightness.



Image 7: The integrated night light, demonstrating its soft illumination and adjustable settings for various ambient lighting needs.

6.4 Alarm Clock Function

The device features a dual alarm clock design with simplified setting process:

- **Set Alarm:** Press the "ALARM" button to enter alarm setting mode. Use "+" and "-" to set the desired alarm time. Press "ALARM" again to confirm.
- **Activate/Deactivate Alarm:** Press the "ALARM" button briefly to toggle the alarm on or off. An alarm icon will appear on the display when active.
- **Snooze Function:** When the alarm sounds, press any button (except "OFF") to activate snooze. The alarm will sound again after 9 minutes.
- **Turn Off Alarm:** Press the "OFF" button to completely turn off the alarm for the day.

7. MAINTENANCE

To keep your COLSUR Wireless Charging Station in optimal condition:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface. Do not use abrasive cleaners or solvents.
- **Storage:** If not in use for an extended period, store the device in a cool, dry place away from direct sunlight.
- **Cable Management:** Regularly check and organize the cables within the portable storage box to prevent tangling and damage.

8. TROUBLESHOOTING

If you encounter issues with your charging station, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging wirelessly.	◦ Device not Qi-compatible. ◦ Phone not centered on charging pad. ◦ Thick phone case or foreign object. ◦ Incorrect power adapter used.	◦ Ensure device supports Qi wireless charging. ◦ Re-position phone to center it on the pad. ◦ Remove phone case or any foreign objects. ◦ Use the provided QC3.0 adapter.
Clock display is off or dim.	◦ Brightness set to minimum or off. ◦ Power not connected.	◦ Press the "DIMMER" button to adjust brightness. ◦ Check power connection.
Night light not working.	◦ Light is off. ◦ Power not connected.	◦ Short press the light control button to turn on. ◦ Check power connection.
Alarm not sounding.	◦ Alarm is deactivated. ◦ Alarm time not set correctly.	◦ Ensure alarm is activated (alarm icon visible). ◦ Re-set the alarm time.

If the problem persists, please contact customer support.

9. SPECIFICATIONS

Model Number	S28-W
Product Dimensions	6.8 x 7.8 x 6.3 inches
Item Weight	1.67 pounds
Input Voltage	220 Volts (AC)

Wireless Charging Output	Up to 15W (Adaptive)
USB Output	Standard USB Port
Light Modes	White, Warm White, Warm
Clock Brightness	3 levels + Off
Manufacturer	Zhongshan Master Light Source Electronic Co., Ltd
Country of Origin	China

10. WARRANTY AND SUPPORT

COLSUR products come with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official COLSUR website.

For technical support, troubleshooting assistance, or any inquiries regarding your product, please contact COLSUR customer service:

- **Email:** [Insert Manufacturer Email Here, if available]
- **Phone:** [Insert Manufacturer Phone Here, if available]
- **Website:** [Visit the COLSUR Store on Amazon](#)

Please have your model number (S28-W) and purchase date ready when contacting support.

