

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

## SHOKZ S661PK

# SHOKZ OpenMove Bluetooth Bone Conduction Sports Headphones User Manual

Model: S661PK

## PRODUCT OVERVIEW

The SHOKZ OpenMove Bluetooth Bone Conduction Sports Headphones offer an unparalleled listening experience with an open-ear design, ensuring comfort and situational awareness. Utilizing advanced bone conduction technology, these headphones deliver clear, balanced audio without covering your ears, making them ideal for sports and outdoor activities. Key features include:

- **Open Ear Design:** For greater perception and comfort, allowing you to stay aware of your surroundings.
- **Bone Conduction and PremiumPitch 2.0:** Delivers clear, balanced sound, optimal volume, and rich bass.
- **Titanium Band:** Ensures a snug, secure, and comfortable fit during various activities.
- **6 Hour Battery Life:** Provides extended listening time on a single charge.
- **Dual Noise Cancelling Mics:** For crystal-clear calls, even in noisy environments.



Image: The SHOKZ OpenMove headphones, showcasing their unique open-ear design and flexible titanium band.

## WHAT'S INCLUDED

Your SHOKZ OpenMove package includes the following items:

- SHOKZ OpenMove Bone Conduction Sports Headphone
- USB-C Charging Cable
- Carrying Bag
- User Guide (this manual)
- 5 Pairs of Stickers (for personalization)



- OpenMove Bone Conduction Sports Headphone
- 5 Pairs of Stickers
- USB-C Charging Cable
- Carrying Bag
- User Guide

Image: All items included in the SHOKZ OpenMove package: headphones, charging cable, carrying bag, and stickers.

## 1. Charging the Headphones

Before first use, fully charge your OpenMove headphones. Connect the included USB-C charging cable to the charging port on the headphones and plug the other end into a compatible USB power source. A full charge takes approximately 2 hours.

The LED indicator will show charging status (e.g., solid red while charging, solid blue when fully charged).

## 2. Powering On/Off

- **To Power On:** Press and hold the Power/Volume+ button for 2 seconds until the LED indicator flashes blue and Audrey says "Welcome to Shokz."
- **To Power Off:** Press and hold the Power/Volume+ button for 3 seconds until the LED indicator flashes red and Audrey says "Power off."

## 3. Pairing with a Bluetooth Device

The OpenMove headphones use Bluetooth 5.1 for a stable connection up to 10 meters (33 feet).


1. Start with the headphones powered off.
2. Press and hold the Power/Volume+ button for 5 seconds until the LED indicator flashes red and blue alternately, and Audrey says "Pairing."
3. On your device (smartphone, tablet, laptop), enable Bluetooth and select "OpenMove by Shokz" from the list of available devices.
4. Audrey will say "Connected" when pairing is successful.

The headphones will automatically reconnect to the last paired device when powered on, if it's within range.

## OPERATING INSTRUCTIONS

### Wearing the Headphones

Place the transducers on your cheekbones, just in front of your ears. The band should rest comfortably behind your head. Ensure the transducers are in full contact with your skin for optimal sound quality.



# Open-Ear Comfort

Enjoy bud-free listening all day with a lightweight and secure fit.

Image: A woman wearing the OpenMove headphones, highlighting the comfortable open-ear fit.

## Controls

The OpenMove headphones feature intuitive media controls located on the right transducer:

- **Power On/Off / Volume Up:** Press and hold for power, single press for volume up.
- **Volume Down:** Single press the Volume- button.
- **Play/Pause:** Single press the Multi-function button (center button).

- **Skip Forward:** Double press the Multi-function button.
- **Skip Backward:** Triple press the Multi-function button.
- **Answer/End Call:** Single press the Multi-function button during a call.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold the Multi-function button for 2 seconds when not on a call.




# Easy Controls

Answer calls, play, pause, and skip audio with just a tap of a finger.

Image: A detailed view of the control buttons on the SHOKZ OpenMove headphones.

## Situational Awareness

The open-ear design allows you to hear your music and your surroundings simultaneously. This is a key safety feature, especially when running, cycling, or walking in urban environments.



# Safety & Connection

Enjoy your favorite audio while also being aware of your surroundings.

Image: A woman wearing the OpenMove headphones while cycling, illustrating the benefit of situational awareness.

## MAINTENANCE

### Cleaning

Wipe the headphones with a soft, damp cloth after each use, especially after workouts, to remove sweat and dirt. Do not use abrasive cleaners or submerge the headphones in water.

## Storage

Store the headphones in the included carrying bag when not in use to protect them from dust and scratches. Avoid storing in extreme temperatures.

## Water Resistance

The SHOKZ OpenMove headphones are water-resistant, designed to withstand sweat, light rain, and splashes. They are not intended for swimming or submersion.

## TROUBLESHOOTING

- No Power:** Ensure the headphones are fully charged. Connect to the USB-C charging cable and check the LED indicator.
- Cannot Pair:**
  - Make sure the headphones are in pairing mode (LED flashing red and blue).
  - Ensure Bluetooth is enabled on your device and it's within 10 meters of the headphones.
  - Forget "OpenMove by Shokz" from your device's Bluetooth settings and try pairing again.
- Poor Sound Quality / Low Volume:**
  - Adjust the volume on both your headphones and your connected device.
  - Ensure the transducers are positioned correctly on your cheekbones.
  - Move closer to your connected device to improve signal strength.
- Microphone Issues:**
  - Ensure the microphone is not obstructed.
  - Check your device's audio input settings to ensure OpenMove is selected.

If issues persist, please refer to the Warranty & Support section for contact information.

## SPECIFICATIONS

Feature	Detail
Brand	SHOKZ
Model Name	OpenMove
Model Number	S661PK
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.1
Bluetooth Range	10 Meters
Audio Driver Type	Bone Conduction Driver
Battery Life	6 Hours
Charging Time	2 Hours
Water Resistance Level	Water Resistant

Feature	Detail
Item Weight	29 Grams
Material	Titanium
Control Type	Media Control
Special Feature	Noise Cancellation (Mics)

## WARRANTY & SUPPORT

### Warranty Information

The SHOKZ OpenMove headphones come with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

### Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official SHOKZ website or contact their customer service team:

- **SHOKZ Official Website:** [www.shokz.com](http://www.shokz.com)
- Refer to the contact information provided on the SHOKZ website for your region.

© 2025 SHOKZ. All rights reserved.

Documents - SHOKZ – S661PK

 słuchawki Shokz OpenMove Pink  
Indeks: 292910 Producent: Shokz Kod producenta: **S661PK**  
Cena: 417.20 zł

**Opis**  
słuchawki Shokz OpenMove Pink  
Producent: SHOKZ

**Waga i rozmiary**

- Waga produktu: 29 g

**Wydajność**

- Czysty dźwięk: Tak
- Typ produktu: Słuchawki
- Styl noszenia: Nauszny
- Zastosowanie: Polaczanie z muzyką
- Wysokość: 10 mm
- Cechy zabezpieczeń: Wodoodporne
- Stopień ochrony IP: IP55
- Typ zasilania: Akumulator
- Typ zasilania słuchawkowego: Stereofoniczny

**Dane opakowania**

- Rodzaj opakowania: Pudełko

**Zawartość opakowania**

- Skuteczną miarąka obuż: Tak
- Wielkość: Ta
- Pomiary: 150x80x30 mm
- Waga: 100 g

**Porty i interfejsy**

- Zasięg bezprzewodowego: 10 m
- Złącze USB: USB Type-C
- Wysokość: 10 mm
- Bluetooth: Tak
- Profile Bluetooth: A2DP, HFP, AVRCP, HSP
- Wymiary słuchawek: 5,1
- Sposób ładowania: Przewodowy i bezprzewodowy

**Barwy**

- Złotawe bateryjne: Tak
- Typ odbieranych bateryj: Włokienka

[\[pdf\]](#)

słuchawki Shokz OpenMove Pink Sklep internetowy stylem pl słuchawki shokz openmove pink 292910  
upload files product |||

słuchawki Shokz OpenMove Pink Indeks: 292910 Producent: Shokz Kod producenta:

**S661PK** Cena: 417.20 zł Opis słuchawki Shokz OpenMove Pink Producent: SHOKZ

Waga i rozmiary Waga produktu: 29 g Wydajno Czysty dwik: Tak Typ produktu:

Słuchawki Styl noszenia: Nauszny Zastosowanie: Polczenia/muzyka Kolor pr...

lang:pl **score:30** filesize: 147.23 K page\_count: 3 document date: 2023-10-15