

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Olla](#) /

› [Olla 16929Y Horizontal Canvas Painting User Manual](#)

## Olla 16929Y

# Olla 16929Y Horizontal Canvas Painting User Manual

Model: 16929Y | Brand: Olla

## 1. INTRODUCTION

This manual provides detailed instructions for the Olla 16929Y Horizontal Canvas Painting. Designed to enhance your living or working space, this high-quality canvas features a striking model/mannequin visual with vibrant colors. Please read this manual carefully to ensure proper installation, care, and longevity of your canvas painting.

## 2. PRODUCT FEATURES

The Olla 16929Y Canvas Painting is crafted with attention to detail, offering several key features:

- Ultra Violet Digital Print:** Ensures vibrant, long-lasting colors and sharp image detail.
- First Class Canvas Frame Stretcher Bar:** Provides a sturdy and durable foundation for the canvas.
- Non-Woven Fabric Backing:** The back surface of our paintings is covered with non-woven fabric for a clean finish and added protection.
- Optimal Edge Thickness:** Features a 3CM edge thickness for a substantial look (2CM for canvases under 70CM).
- Pre-attached Hanging Apparatus:** Comes with a hanging apparatus already attached for easy installation.

## 3. SPECIFICATIONS

Detailed specifications for the Olla 16929Y Canvas Painting:

Size	90 X 60 CM
Orientation	Landscape (Horizontal)
Shape	Rectangular
Frame Type	Frameless
Wall Art Form	Painting

## 4. SETUP AND INSTALLATION

The Olla 16929Y Canvas Painting is designed for straightforward installation. Follow these steps for proper setup:

- 1. Unpack the Painting:** Carefully remove the canvas painting from its packaging. Inspect it for any signs of damage during transit.
- 2. Choose a Location:** Select a suitable wall location that is clean, dry, and away from direct sunlight or excessive humidity to prevent fading or damage.
- 3. Prepare the Wall:** Identify the exact spot where you wish to hang the painting. Use a level to ensure the hanging point will result in a straight display.
- 4. Install Wall Hook/Nail:** Since the painting comes with a pre-attached hanging apparatus, you will need to install a suitable wall hook or nail at the chosen spot. Ensure the hook/nail is strong enough to support the weight of the painting.
- 5. Hang the Painting:** Carefully lift the painting and align the pre-attached hanging apparatus with the wall hook/nail. Gently lower the painting until it is securely resting on the hook.
- 6. Adjust and Level:** Step back and check if the painting is level and centered as desired. Make minor adjustments if necessary.




Image 1: The Olla 16929Y Horizontal Canvas Painting, showcasing its vibrant digital print and frameless design.

## 5. OPERATING (DISPLAY)

Once installed, the Olla 16929Y Canvas Painting requires no further operation. It is designed for static display. To maximize its visual impact and preserve its quality, consider the following:

- Lighting:** Position the painting where it receives adequate, but not direct, light. Avoid direct sunlight, which can cause colors to fade over time.

- **Environment:** Maintain a stable room temperature and humidity level. Extreme fluctuations can affect the canvas and frame.
- **Viewing Distance:** Experiment with different viewing distances to find the optimal perspective for appreciating the artwork's details and overall composition.

## 6. MAINTENANCE

Proper maintenance will help preserve the beauty and longevity of your Olla 16929Y Canvas Painting:

- **Dusting:** Gently dust the surface of the canvas regularly using a soft, dry cloth or a feather duster. Avoid abrasive materials.
- **Cleaning:** For minor smudges or dirt, lightly dampen a soft, lint-free cloth with plain water and gently wipe the affected area. Do not use chemical cleaners, solvents, or excessive moisture, as these can damage the print and canvas.
- **Handling:** When moving or re-hanging the painting, always handle it by the frame edges to avoid touching the canvas surface directly.
- **Storage:** If storing the painting, ensure it is in a dry, cool place, protected from dust and physical damage. Wrap it in a breathable material like a cotton sheet, not plastic, to prevent moisture buildup.

## 7. TROUBLESHOOTING

This section addresses common concerns you might encounter with your canvas painting:

Problem	Possible Cause	Solution
Painting appears crooked.	Improperly installed wall hook or uneven hanging.	Remove the painting, re-level the wall hook/nail, and re-hang. Use a spirit level for accuracy.
Dust accumulation on canvas.	Normal environmental dust.	Gently dust with a soft, dry cloth or feather duster as described in the Maintenance section.
Colors appear faded over time.	Exposure to direct sunlight or harsh lighting.	Relocate the painting to an area with indirect light. Ensure it is not exposed to prolonged direct sunlight.
Canvas appears loose or warped.	Extreme temperature or humidity fluctuations.	Ensure the painting is in a stable environment. Minor warping may self-correct in stable conditions. For significant issues, contact support.

## 8. WARRANTY AND SUPPORT

For any questions, concerns, or issues not covered in this manual, please contact the seller or manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims. Specific warranty terms and conditions may vary and are typically provided at the time of purchase.

For support, please refer to the contact information provided by your retailer or the Olla brand's official channels.