

[Manuals.plus](#) /

› [YESHOMY](#) /

› YESHOMY Modern Farmhouse TV Stand User Manual

YESHOMY YH-TS103DWA

YESHOMY Modern Farmhouse TV Stand User Manual

Model: YH-TS103DWA | Brand: YESHOMY

PRODUCT OVERVIEW

The YESHOMY Modern Farmhouse TV Stand is designed to enhance your living space with its stylish appearance and practical storage solutions. This entertainment center console table is suitable for televisions up to 65+ inches, offering ample space for media devices and other items.

Key Features:

- **TV Stand Size:** Measures 24" H x 15.75" D x 58" L, accommodating TVs up to 65+ inches.
- **Convenient Design:** Features adjustable shelves to meet diverse storage needs, optimizing living room space.
- **Round Cable Hole:** Equipped with a drilling design at the back for easy and neat connection of electronic equipment power supplies.
- **Large Storage Space:** Provides generous storage for electronic devices and other accessible items.
- **Variety of Styles:** Offers decorative functions to complement various living room styles, creating a welcoming environment.

IMPORTANT SAFETY INFORMATION

Warning: This product requires proper assembly to prevent tip-over risks. Keep electrical components away from children and liquids. Do not overload the shelves to prevent structural damage.

SETUP GUIDE

Unboxing and Component Check

Carefully unpack all components from the packaging. Verify that all parts listed in the manual are present and undamaged before beginning assembly.

Package includes: A tool kit, A TV stand, A manual of installation and usage.



Image: All components and hardware included in the package for assembly.

Assembly Instructions

For detailed step-by-step assembly instructions, please refer to the included installation manual (PDF) or the official user guide available online. Ensure all connections are secure and follow the diagrams carefully to prevent misalignment.

The TV stand measures approximately 58 inches in length, 15.75 inches in depth, and 23.9 inches in height. These dimensions are crucial for proper assembly and placement.

Product size




Table material



Table load
300lbs


Image: Detailed product dimensions for accurate assembly and placement.



Proection Edge



Round Line Hole



Magnet Design



Adjustable Shelf

Image: Key features of the TV stand, including the protection edge, round line hole for cables, magnetic door closure, and adjustable shelf mechanism.

OPERATING INSTRUCTIONS

Placing Your TV and Devices

This TV stand is designed to safely hold televisions up to 65+ inches. Place your TV centrally on the top surface. Utilize the central open shelves for media devices such as soundbars, gaming consoles, or streaming boxes.



Image: The TV stand with a television and media devices, showcasing its functional design.

The integrated round cable hole at the back of the stand allows for organized cable management, keeping wires tidy and out of sight.



Image: Rear view of the TV stand, highlighting the circular cable management hole for neat wiring.

Utilizing Storage

The TV stand features two barn-style doors that slide to reveal spacious storage cabinets. The shelves within these cabinets are adjustable, allowing you to customize the storage space to fit items of various sizes, from books to decorative pieces.



Image: The TV stand with its barn doors open, displaying the internal storage compartments and adjustable shelves.



Image: A detailed view of the adjustable shelf, demonstrating how its height can be modified to suit different items.

Product Demonstration Video

Your browser does not support the video tag.

Video: An official product video showcasing the YESHOMY Farmhouse TV Stand in a living room setting, demonstrating its features and aesthetic appeal.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your TV stand, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust with a soft, dry cloth.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood finish.
- **Load Capacity:** Do not exceed the maximum recommended load of 136.08 Kilograms (approximately 300 pounds)

to prevent structural damage.

- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration.

TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following common troubleshooting tips:

- **Assembly Difficulties:** If pieces do not fit together or holes are misaligned, double-check the assembly manual diagrams and ensure you are using the correct parts for each step. Sometimes, slight adjustments or re-orientation of parts can resolve fitting issues.
- **Stability Issues:** Ensure all screws and fasteners are tightened securely. Uneven flooring can also affect stability; consider using furniture pads or shims if necessary.
- **Damaged or Missing Parts:** If any parts are damaged or missing upon arrival, please contact customer support immediately for assistance.

For further assistance, please refer to the comprehensive user manual (PDF) or contact YESHOMY customer support.

PRODUCT SPECIFICATIONS

Attribute	Value
Brand	YESHOMY
Color	Walnut
Product Dimensions	15.75"D x 58"W x 23.9"H
Special Feature	Adjustable Shelf
Mounting Type	Floor Mount
Room Type	Living Room
Door Style	Shaker
Included Components	A TV Stand
Size	Large
Item Weight	74 Pounds
Base Type	Legs
Assembly Required	Yes
UPC	768492965367
Manufacturer	YESHOMY
Country of Origin	China
Item model number	YH-TS103DWA
Maximum recommended load	136.08 Kilograms

Care instructions	Hand Wash (Note: This is likely a generic placeholder from the source data, actual care is wiping)
Batteries required	No

WARRANTY AND SUPPORT

This product is eligible for 30-day easy returns. Additionally, protection plans are available for extended coverage:

- 2-Year Protection Plan: \$27.99 (one-time)
- 3-Year Protection Plan: \$34.99 (one-time)
- Complete Protect: \$16.99/month (covers all eligible past and future purchases)

For customer support, inquiries, or to report issues, please visit the [YESHOMY Store on Amazon](#) or refer to the contact information provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question