

Beast Kingdom DS-030

Beast Kingdom Lilo & Stitch: Stitch Surfing DS-030 D-Stage Series Statue Instruction Manual

INTRODUCTION

This manual provides essential information for the proper handling, display, and care of your Beast Kingdom Lilo & Stitch: Stitch Surfing DS-030 D-Stage Series Statue. This collectible item is designed for display and is not intended as a toy. Please read these instructions carefully to ensure the longevity and preservation of your statue.

UNBOXING AND INITIAL INSPECTION

- Careful Removal:** Gently remove the statue from its packaging. Avoid using sharp objects that could scratch or damage the product.
- Inspect for Damage:** After removal, carefully inspect the entire statue for any signs of damage, such as cracks, chips, or detached parts.
- Retain Packaging:** It is recommended to retain the original packaging for future storage or transportation.



Image: Front view of the Stitch Surfing DS-030 D-Stage Series Statue, showing Stitch and Scrump on a surfboard atop a wave, with a sandy base.

DISPLAY GUIDELINES

- **Stable Surface:** Place the statue on a flat, stable, and level surface to prevent accidental falls.

- **Environmental Conditions:** Avoid direct sunlight, extreme temperatures, and high humidity, as these can cause fading, discoloration, or material degradation over time.
- **Keep Away from Children and Pets:** This is a collectible item and contains small parts that could pose a choking hazard. Keep it out of reach of young children and pets.



Image: Side view of the Stitch Surfing DS-030 D-Stage Series Statue, showcasing the dynamic wave and the detailed sandy base.

CARE AND MAINTENANCE

- **Dusting:** Regularly dust the statue with a soft, dry brush or a microfiber cloth to prevent dust buildup.
- **Cleaning:** For more thorough cleaning, lightly dampen a soft cloth with water and gently wipe the surface. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the paint or finish.
- **Handling:** Always handle the statue by its base to minimize contact with painted surfaces and delicate parts.



Image: Close-up view of Stitch on the surfboard, highlighting the character's details and the surfboard's design.

TROUBLESHOOTING AND COMMON CONCERNS

While this statue is designed for durability, minor issues may arise. Here are some common concerns and recommendations:

- **Loose Parts:** If a small, non-structural part becomes loose, it may be reattached using a small amount of hobby-grade super glue. Apply sparingly and carefully.
- **Dust Accumulation:** If dust is difficult to remove from crevices, use a can of compressed air (held upright and at a distance) or a very soft, fine-tipped brush.
- **Fading Colors:** Fading is typically caused by prolonged exposure to direct sunlight. Ensure the statue is displayed in a location away from direct UV light.



Image: Rear view of the Stitch Surfing DS-030 D-Stage Series Statue, showing the back of the wave and the base.

PRODUCT SPECIFICATIONS

Model Number	DS-030
Brand	Beast Kingdom
Product Dimensions	8 x 6 x 6 inches
Item Weight	11.2 ounces
Recommended Age	15 years and up
ASIN	B09LTWS9Q2

SAFETY INFORMATION

- This product is a collectible statue, not a toy.
- Not suitable for children under 15 years due to small parts and potential for breakage.
- Avoid dropping or subjecting the statue to impact, as this can cause irreparable damage.

CUSTOMER SUPPORT

For further assistance, inquiries about your product, or to report significant damage upon receipt, please contact Beast Kingdom customer support or the retailer from whom the product was purchased. You can find more information about Beast Kingdom products on their official website or [visit the Beast Kingdom store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09LTWS9Q2>

More documents and user manuals: <https://manuals.plus/>