

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Perlegear](#) /

› [PERLEGEAR PGTVS16 Universal Swivel Table Top TV Stand Instruction Manual](#)

Perlegear PGTVS16

PERLEGEAR PGTVS16 Universal Swivel Table Top TV Stand Instruction Manual

Model: PGTVS16 | Brand: Perlegear

INTRODUCTION

Thank you for choosing the PERLEGEAR PGTVS16 Universal Swivel Table Top TV Stand. This manual provides essential information for safe and proper assembly, operation, and maintenance of your new TV stand. Please read all instructions carefully before installation and retain this manual for future reference.

SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 99 lbs (45 kg).
- **TV Size:** Designed for 13-50 inch flat/LCD/LED TVs. Ensure your TV's size and weight are within these limits.
- **Stable Surface:** Always place the TV stand on a stable, level, and sturdy surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the TV stand during assembly and ensure the TV is securely mounted to prevent accidents.
- **Proper Installation:** Follow all assembly instructions carefully. Improper installation can result in serious injury or damage.
- **Tools:** Use appropriate tools as specified in the assembly guide.

Superb TV Security



Image: A TV mounted on the stand, highlighting its superb security and ability to hold up to 99 lbs.

PACKAGE CONTENTS

Please check to ensure all parts are present and undamaged before beginning assembly. If any parts are missing or defective, contact customer support.



Image: All components and mounting hardware included in the PERLEGEAR PGTVS16 package, illustrating hassle-free installation.

COMPATIBILITY

- **TV Size:** 13-50 inches
- **Weight Capacity:** Up to 99 lbs (45 kg)
- **VESA Patterns:** 200x200mm, 200x100mm, 100x100mm, 75x75mm



Image: Visual guide for TV and monitor compatibility, showing supported screen sizes (13"-43") and VESA patterns (200x200mm, 200x100mm, 100x100mm, 75x75mm).

SETUP & ASSEMBLY

1. **Attach the Base:** Secure the main support column to the tempered glass base using the provided screws.
2. **Install TV Brackets:** Attach the two vertical TV brackets to the back of your television using the appropriate VESA screws and spacers. Ensure screws are flush against the TV.
3. **Mount TV to Stand:** Carefully lift the TV and hook the attached brackets onto the main support column. Ensure the brackets are securely seated in the desired height slots.

4. **Secure TV:** Use the safety screws to lock the TV brackets to the main support column, preventing accidental lifting or dislodgement.

Your browser does not support the video tag.

Video: A demonstration of assembling the TV stand and mounting a TV, highlighting the ease of installation and secure attachment.

OPERATING INSTRUCTIONS

Height Adjustment:

The PERLEGEAR PGTVS16 offers multiple height settings. To adjust the TV height, carefully lift the TV off the support column, reposition the brackets into the desired slots, and re-secure with the safety screws. There are 3 main height settings available.



Image: Illustration showing a person adjusting the height of a monitor on the stand, indicating 3 available height settings.

Swivel Function:

The TV stand features a swivel function, allowing you to rotate your TV up to ± 45 degrees left or right for optimal viewing angles. Gently push the TV to the desired angle. Ensure the base remains stationary.

Customize Your Height



Image: A TV on the stand swiveling, illustrating the ±45 degree flexible viewing angle.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the stand. Avoid abrasive cleaners or solvents that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight and secure.
- **Cable Management:** Utilize the integrated cable management system to keep cables tidy and prevent damage.



Image: Close-up of the TV stand's central pillar showing cables neatly routed along it, demonstrating the cable management feature.

TROUBLESHOOTING

- **TV is not level:** Ensure the TV brackets are installed evenly on the back of the TV and are seated correctly in the stand's slots. Re-adjust if necessary.
- **Stand feels unstable:** Verify all screws are tightened securely. Ensure the stand is placed on a flat, stable surface. Check that the TV weight does not exceed the stand's capacity.
- **Difficulty swiveling:** Check for any obstructions around the base or TV. Ensure the TV is not overtightened to the stand, allowing for smooth rotation.

SPECIFICATIONS

Brand:	Perlegear
Model:	PGTVS16
Material:	Alloy Steel, Tempered Glass
TV Size Compatibility:	13-50 inches
Weight Capacity:	99 lbs (45 kg)
VESA Compatibility:	200x200mm, 200x100mm, 100x100mm, 75x75mm
Movement Type:	Swivel ($\pm 45^\circ$), Height Adjustable
Item Weight:	6.78 pounds

Sturdy Glass Base



PERLEGEAR

- Tempered Glass Base
- Stable Centered Support



Other

- Flimsy Plastic Legs
- Separated Support Points



Image: A TV on the PERLEGEAR stand with a sturdy tempered glass base, providing stable centered support.

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the official Perlegear website. Keep your purchase receipt as proof of purchase.